



Perle IRG5410/5410+ Hardware Installation Guide



Updated: June 2023
Version A.06.13.2023
Document Part#:5500447-10

Preface

Audience

This guide is for the network or computer technician responsible for installing the Perle IRG5410/5410+ router also generically referred to as the IRG5410 within this document. Familiarity with the concepts and terminology of Cellular Networks, GNSS, Ethernet, and LAN (local area networks) is required.

Purpose

Perle routers provide users, networking equipment, as well as M2M & IoT appliances with network connectivity for fixed locations (i.e. buildings, POS, Kiosks, ...etc.) and mobile (i.e. vehicle, trains, robots) applications. In vehicular applications, the router provides connectivity and does not interact with the vehicle's operation or vehicle operators.

This document describes the hardware and physical characteristics of the Perle IRG5410 router. It covers hardware features as well as installation and operation. This document does not cover how to configure your Perle IRG5410 router. Information to configure your Perle router can be found in the Perle IRG7000/5000 5G/LTE Router User's Guide and the Perle IRG7000/5000 5G/LTE Router Command Line Reference Guide on the Perle website. Quick Start information can be found in the 5410 that comes with your product.

Key Features

- Supports bridging/switching, and routing
- LTE coverage spanning 21 frequency bands in North America/EMEA
- LTE coverage spanning 30 frequency bands for global coverage (IRG5541/5541+)
- Fully automatic network switching supporting dual network SIMs
- Routing with Primary/Backup route
- LTE and VPN Fail-over
- Provides network connectivity via LTE, Ethernet, and USB-C
- Active GPS for tracking equipment
- Low voltage Standby function to prevent battery drain
- One GPIO pin for remote monitoring/control and one IGN (Ignition) pin
- Security via remote authentication (Radius/RadSec and TACACS+)
- Processor Power Saving Mode—this feature optimizes idle power consumption, saving energy by reducing performance where possible
- Power Saving Features including; LED power saving mode, Smart Standby Mode, Power saving strategies such as turning off unused interfaces (USB, Serial, Ethernet), turning off GPS and adjusting the Ethernet rate
- Meets industry-grade certifications

Additional Documentation

Document	Description
Perle IRG7000/5000 5G/LTE Router User's Guide	User's guide explaining how to configure the IRG5410 features using the Web Manager application. New users should use this method to configure the router.
Perle IRG7000/5000 5G/LTE Router Command Line Reference Guide	Command Line Interface Reference Guide using CLI commands to configure the IRG5410 (this is an advanced way to configure the router).

Document Conventions

This document contains the following conventions:

Most text is presented in the typeface used in this paragraph. Other typefaces are used to help you identify certain types of information. The other typefaces are:

Note: *Means reader take note:* notes contain helpful suggestions.

Caution: Means reader be careful. In this situation, you might perform an action that could result in equipment damage or loss of data.

Warning: IMPORTANT SAFETY INSTRUCTIONS

Means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when cellular devices such as the Perle IRG5410 Series Routers are used in a normal manner with a well-constructed network. The Perle IRG5410 Series Routers should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Perle accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using our products.

Safety and Hazards

The driver or operator of any vehicle should not operate the IRG5410 while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. The IRG5410 is Listed to UL121201 and CSA C22.2 No. 213 and are suitable for use in Class I, Division 2, Groups A, B, C and D Hazardous Locations.

The following warnings and instructions apply:

Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Perle for any and all direct, indirect, special, general, incidental, consequential, punitive or exemplary damages including, but not limited to loss of profits or revenue or anticipated profits or revenue arising out of the use or inability to use any Perle IRG5410 series router even if Perle has been advised or the possibility of such damages or they are foreseeable or for claims by any third party.



Notwithstanding the foregoing, in no event shall Perle aggregate liability arising under or in connection with the Perle product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Perle product.

Copyright © 2023 Perle. All rights reserved.

Windows® is a registered trademarks of Microsoft Corporation.

Other trademarks are the property of their respective owners

General cautions and warnings

13		IEC 60417-5041 (2002-10)	“WARNING: HOT SURFACE. DO NOT TOUCH.” / ATTENTION: Surface chaude. Ne pas toucher.”
14			Refer to manual/safety

Warning: Power sources must be off prior to beginning the power connection steps. Read the installation instructions before you connect the unit to its power source.

Avertissement: Les sources d'alimentation doivent être éteintes avant de commencer les étapes de connexion d'alimentation. Veuillez lire les instructions d'installation avant de connecter l'appareil à sa source d'alimentation.

Warning: Ensure that the voltage and current ratings of the intended power source are appropriate for the IRG5410 Series of Routers as indicated on the product label.

Avertissement: Assurez-vous que les valeurs nominales de tension et de courant de la source d'alimentation prévue conviennent aux routeurs de la série IRG5410, comme indiqué sur l'étiquette du produit.

Warning: Ensure that the installation and electrical wiring of the equipment is performed by trained and qualified personnel and that the installation complies with all local and national electrical codes.

Avertissement: Assurez-vous que l'installation et le câblage électrique de l'équipement sont effectués par du personnel formé et qualifié et que l'installation est conforme à tous les codes électriques locaux et nationaux.

Warning: This equipment must be used in the matter specified by the manufacturer.

Avertissement: Cet équipement doit être utilisé dans les matières spécifiées par le fabricant.

Warning: In case of malfunction or damage, no attempts at repair should be made by the user. Do not dismantle this product. In case of malfunction or damage, contact Perle Technical support at

https://www.perle.com/support_services/support_request.aspx

or email at

https://www.perle.com/support_services/support_request.aspx#form

Avertissement: En cas de dysfonctionnement ou de détérioration, aucune tentative de réparation ne doit être effectuée par l'utilisateur. Ne démontez pas ce produit. En cas de dysfonctionnement ou de dommage, contactez le support technique de Perle à l'adresse

https://www.perle.com/support_services/support_request.aspx

ou par courrier électronique à

https://www.perle.com/support_services/support_request.aspx#form

Warning: “Equipment is intended for installation in Restricted Access Area when equipment is installed in ambient exceeding 50°C (122°F)”. The unit should be installed in a restricted access loca-

tion where access can only be gained by service personnel or users who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken; and access is through the use of a tool or lock and key, or any means of security, and is controlled by the authority responsible for the location.

Avertissement: L'équipement est destiné à être installé dans une zone d'accès restreint lorsque l'équipement est installé dans une température ambiante supérieure à 50 °C (122 °F). L'unité doit être installée dans un emplacement à accès restreint, auquel seul le personnel de service ou les utilisateurs informés des raisons des restrictions appliquées peuvent accéder. sur le lieu et sur les précautions à prendre; et l'accès se fait au moyen d'un outil ou d'un verrou et d'une clé, ou de tout moyen de sécurité, et est contrôlé par l'autorité responsable du lieu.

Warning: The working voltage inputs are designed for operation with Safety extra low Voltage (SELV). Connect only to SELV circuits with voltage restrictions in line with IEC/EN 62368-1.

Avertissement: Les entrées de tension sont conçues pour fonctionner avec une tension de sécurité très basse (SELV). Connectez uniquement aux circuits SELV avec des restrictions de tension conformes à IEC / EN 62368-1.

Warning: For equipment installed within the same end-product enclosure ensure leads are segregated or insulated the leads from different circuits.

Avertissement: Pour les équipements installés dans le même boîtier de produit final, assurez-vous que les conducteurs sont séparés ou isolés des conducteurs de circuits différents.

Hazardous Location Warnings

Specific Conditions of Use

1. The IRG5410/5410+ Routers are intended for installation into an IECEx/ATEX certified and IP54 minimum rated enclosure in accordance with IEC/EN IEC 60079-0 and accessible only by the use of a tool. Les modèles de routeurs IRG5410/5410+ sont destinés à être installés dans un boîtier certifié IECEx/ATEX qui conforme à la norme IP54 conformément à la norme IEC/EN IEC 60079-0 et accessible uniquement à l'aide d'un outil.
2. The Routers shall only be used in an area of not more than pollution degree 2, as defined in IEC/EN 60664-1. L'équipement ne doit être utilisé que dans une zone où le degré de pollution n'est pas supérieur à 2, tel que défini dans la IEC/EN 60664-1.

Warning: These devices are open-type devices that are to be installed in an enclosure with tool removable cover or door, suitable for the environment.

Avertissement: Ces périphériques sont des périphériques de type ouvert à installer dans un boîtier avec un couvercle ou une porte amovible pour outils, adapté à l'environnement.

Warning: This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D, or only non hazardous locations.

Avertissement: Cet équipement est adapté à une utilisation dans les zones non dangereuses de classe I, division 2, groupes A, B, C, D

Warning: WARNING-EXPLOSION HAZARD - Do not connect or disconnect equipment unless power has been removed or the area is known to be non-hazardous.

Avertissement: DANGER D'EXPLOSION ET D'AVERTISSEMENT - Ne pas connecter ou déconnecter l'équipement tant que l'alimentation n'est pas débranchée ou que la zone n'est pas dangereuse.

Warning: WARNING-EXPLOSION HAZARD - Substitution of any components on this unit may impair suitability for Class I, Division 2.

Avertissement: DANGER DANGER D'EXPLOSION - La substitution de tout composant de cet appareil peut compromettre l'adéquation à la Classe I, Division 2.

Warning: Power supply of the equipment must be rated appropriately (see Appendix for specifications) with limited power. Limited power means complying with one of the following requirements.

Class 2 circuit according to Canadian Electrical Code, Part 1, C22.1

Class 2 circuit according to National Electrical Code, NFPA-70

Limited Power Supply (LPS) according to EN/IEC 60950-1;

Limited-energy circuit according to EN/IEC 61010-1

Avertissement: l'alimentation de l'équipement doit être correctement dimensionnée (voir annexe pour les spécifications) avec une puissance limitée. Une puissance limitée signifie que vous vous conformez à l'une des exigences suivantes.

Circuit de classe 2 selon le code électrique Canadien, partie 1, C22.1

Circuit de classe 2 selon le code électrique national NFPA-70

Alimentation électrique limitée (LPS) selon EN / IEC 60950-1;

Circuit à énergie limitée selon EN / IEC 61010-1

Warning: If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Avertissement: Si cet équipement est utilisé d'une manière non spécifiée par le fabricant, la protection fournie par l'équipement peut être altérée.

Warning: In case of malfunction or damage, no attempts at repair should be made. Do not dismantle the product. All repairs need to be made by a qualified Perle representative. Contact Perle Systems Technical support at https://www.perle.com/support_services/support_request.aspx or email at https://www.perle.com/support_services/support_request.aspx#form

Avertissement: En cas de dysfonctionnement ou de dommage, aucune tentative de réparation ne doit être effectuée. Ne démontez pas le produit. Toutes les réparations doivent être effectuées par un représentant qualifié de Perle. Contactez le support technique de Perle Systems à l'adresse https://www.perle.com/support_services/support_request.aspx ou par courrier électronique à https://www.perle.com/support_services/support_request.aspx#form

Warning: This router is not intended for use close to the human body. The unit should be mounted in such that Antennas are at least 20cm (8 inches) away from any person.

Avertissement: Ce routeur n'est pas destiné à être utilisé à proximité du corps humain. L'appareil devrait être monté de façon à ce que les antennes soient à au moins 20 cm (8 po) de toute personne.

Warning: Explosion hazard. Do not connect or disconnect while the circuit is live or unless the area is free of ignitable concentrations.

Avertissement: Risque d'explosion. Ne pas connecter ou déconnecter le circuit est sous tension ou à moins que la zone ne présente aucune concentration inflammable.

Warning: Do not use the USB connector unless the area is free of ignitable concentrations.

Avertissement: N'utilisez pas le connecteur USB à moins que la zone ne soit exempte de concentrations inflammables.

Warning: Do not use the reset button unless the area is free of ignitable concentrations.

Avertissement: N'utilisez pas le bouton de réinitialisation à moins que la zone ne soit exempte de concentrations inflammables.

RF Exposure

In accordance with FCC/IC requirements of human exposure to radio frequency fields, the radiating element shall be installed such that a minimum separation distance of 20 cm should be maintained from the antenna and the user's body.

Conformément aux exigences de la FCC/IC relatives à l'exposition humaine aux champs de radiofréquences, l'élément de rayonnement doit être installé de manière à ce qu'une distance de séparation minimale de 20 cm soit maintenue par rapport à l'antenne et au corps de l'utilisateur.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS GUIDE ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS GUIDE ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with this hardware guide may cause harmful interference to radio communications.

Modifications to this product not authorized by Perle could void the FCC approval and negate your authority to operate the product.

Perle reserves the right to make changes without further notice, to any products to improve reliability, function, or design.

Perle, the Perle logo, and IRG5410 Series of Routers are trademarks of Perle.

Copyright ©2023 Perle.

60 Renfrew Drive, Markham, Ontario, L3R 0E1, Canada

All rights reserved. No part of this document may be reproduced or used in any form without written permission from Perle.

Publishing History

Date	Revision	Update Details
March 2020	A.03.23.2020	Initial release.
Dec 2020	A.12.31.2020	Updates
June 2021	A.03.06.2021	Update to label
Jan 2022	A.01.30.2022	Added IRG7440 model (5G) and updates to other models
March 2022	A.03.17.2022	Updated Hot warning
April 2022	A.04.08.2022	Updated Restricted Access Area warning
June 2023	A.06.13.2023	Added DHCP/BOOTP (ZTP mode) support for factory default mode

Table Of Contents

Preface	I
Overview	1
What's Included	1
What You Need to Supply	1
Hardware	2
Front View	2
SIM Card/s	6
Back View (Antenna/s)	7
USB-C Port	7
Ethernet LAN Port	7
Ethernet Link Status	7
GNSS Connector	8
Connecting the Power	8
Installation	10
Inserting the SIM card	10
Connecting to the Ethernet Port	11
Connecting to the Serial Port	11
Female Serial Pin out	12
Connecting to the USB-C port in Console Mode	12
Connecting to the USB-C port as an Ethernet over USB Port	12
Connecting the Power	13
Operation	14
Reset / Factory Default / Safe Mode / DHCP/BOOTP (ZTP mode)	14
Fast Setup	15
Managing the IRG5410	16
WebManager	16
CLI	16
SNMP	16
Fast Setup Mode	16
PerleView	16
Power Management	17
Power Modes	17
Power Saving Options	18
Power Saving Scenarios	18
Low Voltage Standby	21
Overheat Standby	21
IRG Router Deployment Modes	22
Fixed Installation without I/O	22
Recommended Vehicle Installation (Ignition Mode)	22
Fixed Installation with Analog Input	23
I/O Configurations	24
Pulse Counter / Digital Input	24
High Side Pull-up / Dry Contact Switch Input	24
Digital Output / Low Side Current Sink	25

Digital Output / Open Drain	26
Appendix A—Technical Specifications	27
Appendix B—Sample Labels	34
Appendix C—Mounting the IRG5410	35
Appendix D—Mechanical	37
Appendix E—Maintaining and Troubleshooting	38

Overview

The IRG5410/5410+ router is a compact, rugged, fully featured communications platform for real-time wireless capabilities. It has multiple communication ports including Serial, Ethernet, and a USB port that can be used as a console port or as an additional Ethernet port. It supports LTE/4G wireless solutions for both fixed and mobile applications (IoT). The IRG5410 supports Cat-12 technology with peak download rates of 600 Mbps and uploads speeds of 150 Mbps. It offers global coverage of frequency bands, supports Cat-12 technology with automatic fall-back to 3G (HSPA+, UMTS) networks. The IRG5410+ also includes integrated GNSS receiver (GPS, GLONASS, Beidou, and Galileo) satellite support.

Application uses:

- Monitoring and controlling remote equipment such as pipelines, meters, pumps, and valves in energy, utility, or industrial applications
- Tracking the location of heavy equipment and assets in the field
- Providing reliable Internet access to a mobile workforce

What's Included

The following components **may** be included with your product. Components will vary depending for each model. See the Perle website for updates.

- The router
- Quick Start Guide that came with your product
- LTE SMA antenna pack (#08000120)
- GPIO Cable with 4 Pin plug (#2500468)
- GPIO Cable with 8 Pin plug (#2500476)
- 12VDC/2A 4 Pin (NA-#08000150, EU #08000160, UK #08000170, #08000180) power supply
- GNSS PASV RP-Antenna SMA/CA (#08000130) order-able from Perle


What You Need to Supply

Before you can begin, you need to have the following:


- A SIM card/s (provided by your mobile network operator)
- #1 Phillips screwdriver (if you are installing the SIM card)
- Computer or laptop computer with Ethernet interface and cable
- An Ethernet CAT5e or CAT6 10/100/1000BASE-T cable/to connect the router to the network

Hardware

Front View






LEDs







LTE only models

Models including WiFi

Power LED	Function	Normal	Low Power Mode	Meaning
	No Power	Off	N/A	
	Boot	Red—solid	N/A	
	Green— Blip	N/A	N/A	
	Powering up	Amber—flashing	N/A	
	Normal Operation	Green—solid	Green—blip starting after a boot is complete	
	Normal operation but no config	Green—flashing		Unit is powered up normally—unit has no config. Unit is in Safe mode or Factory default mode.
	Fatal error	Red—solid	Red—solid	

	Setup Mode	Amber—solid	Amber—solid	When you press and hold the reset button for 5 seconds. The solid amber led indicate the time to release to initiates setup mode.
	Factory Reset	Red—solid	Red—solid	When you press and hold the reset button for 20 seconds. The solid red indicates the time to release to imitate reset to factory.
	Overheat Standby	Red—blip	Red—blip	Overheat caused the unit to go into Standby mode. Router will restart when temp is below the threshold.
	No Config	Green-flashing	N/A	Unit is powered up normally—unit has no config. Unit is in safe mode or factory default mode.
Serial 	Function	Normal	Low Power Mode	Meaning
	Disabled or not in use	Off	Off	Always off in power saving mode.
	Serial port/s TX/RX	Green—flashing	Off	
WWAN 	Function	Normal	Low Power Mode	Meaning
	Disabled	Off	Off	

	Connected—good signal	Color—solid	Off—once a connection is established, it will come on for 5 secs then go off	Colour will depend on signal strength. Green = Good signal— >= -80dBm Amber = Fair signal— >-94dBm <-80dbm red="Poor" signal—<="94dBm" < body>
GNSS 	Function	Normal	Low Power Mode	Meaning
	Disabled	Off	Off	No GPS activated or in power saving mode.
	Initializing	Green—blip	Off	
	Attempting to get a fix or unable to get a fix	Amber—flashing	Amber—blip	
	GPS fix	Green—solid	Off—green solid for 5 seconds then off	
VPN 	Function	Normal	Low Power Mode	Meaning
	No VPN	Off	Off	No VPN configured or enabled
	VPN established	Green—solid	Off	VPN established—at least 1 VPN connection is up.
	VPN failed	Red—solid	Red—blip	Internet is up, but VPN failed
WLAN 	Function	Normal	Low Power Mode	Meaning

	5.0GHz	Green—solid	Off	Client mode connected—AP Radio mode.
	5.0 TX/RX	Green—flashing	Off	Client or AP activity.
	2.4GHz	Amber—solid	Off	Client mode connected—AP-radio active.
	2.4 TX/RX	Amber—flashing	Off	Client or AP activity.
	No connection	Off	Off	Client mode—no connection; AP mode not enabled.
Internet 	Function	Normal	Low Power Mode	Meaning
	Disconnected	Off	Off	No connection by intention <ul style="list-style-type: none"> • disabled or radio off • disconnect requested
	Connected	Green—solid	Off	<ul style="list-style-type: none"> • LTE primary if no WAN • Primary connection if WAN
	Backup mode	Amber—solid	Off	Backup connection if WAN.

	Connection failure	Red—solid	Red—blip	<p>A connection was attempted, but it failed.</p> <ul style="list-style-type: none"> • APN incorrect • SIM card missing • insufficient signal • no service • modem failure • data connection failed—waiting to retry • Pin incorrect SIM blocked, bad unlock code • SIM locked • SIM blocked, unblock code incorrect
--	--------------------	-----------	----------	---

SIM Card/s

The IRG5410 supports two SIM cards. See [Inserting the SIM card](#) for the installation procedure.



SIM/ Interface 1.8V/3V

Back View (Antenna/s



The IRG5410 has three SMA antenna connectors, Main, Div/GNSSL1, and GNSS. For more information on connecting the antennas see the Technical Specifications section [Connecting the Antenna/s](#).

USB-C Port


In console mode, the IRG5410 USB port provides direct access to the Command Line Interface (CLI) as well as provides statuses, logging, and troubleshooting information. Alternative, this port can be set as an Ethernet over USB port.

See [Connecting to the Serial Port](#) and [Connecting to the USB-C port as an Ethernet over USB Port](#).



Ethernet LAN Port

Once the port are connected and the link is established, the speed LED will turn on. The LED indicates a 10, 100, or 1000 Mbps link on the Ethernet port.



Ethernet Link Status

Link/Speed Indicator		Description
Left LED Green	Link + Flashing with activity	1000 Mbps
Both LEDs	Link + Flashing with activity	100 Mbps
Right LED Green	Link + Flashing with activity	10 Mbps
Off	Off	No LAN connected

GNSS Connector



GPS+GLONAS+GAILEO


Passive Antenna—SMA(M) straight connector

See [Appendix A—Technical Specifications](#) for electrical details.

Connecting the Power

Some models ship with a DC power cable or a pigtail cable.

The GPIO connector can be configured as a high side pull-up/dry contact digital input, analog input, low side current sink output, digital output/open drain, or pulse counter depending on your application. Pin 3—IGN can be configured as vehicle ignition sense or as analog input.



Warning: Before servicing this product ensure the power source has been disconnected.

Pin	Name	Associated DC Cable Wire color	Description	Type
1	Power	Red	Main power supply for device. <i>Note:</i> If you want to turn the IRG5410 on/off using a control line, such as a vehicle ignition line, we recommend that you connect the control/ignition line to Pin 3 and apply continuous power On Pin 1	PWR
2	Ground	Black	Main device ground.	GND

Pin	Name	Associated DC Cable Wire color	Description	Type
3	IGN	White	Connect to the vehicle ignition or an external switch. This input can be configured to put the router into a Standby mode when the signal goes low and take it out of Standby mode when it goes high. Alternatively it can be used simply as an analog input.	IGN
4	GPIO	Green	User configurable digital input/output or analog voltage sensing input. Connect to switch, relay or external device.	GPIO

Note: Use copper conductors only.

Installation

The steps for a typical installation are:

1. Inserting the SIM card/s. See [Inserting the SIM card](#).
2. Connecting the antenna/s. See [Connecting the Antenna/s](#).
3. Connecting the Ethernet Ports. See [Ethernet LAN Port](#).
4. Connecting the Serial Port. See [Connecting to the Serial Port](#).
5. Connecting to the Console Port in Console Mode. See [Female Serial Pin out](#).
6. Using the Console port as a virtual Ethernet port. See [Connecting to the USB-C port as an Ethernet over USB Port](#).
7. Connecting the power. See [Connecting the Power](#).
8. Logging into the IRG5410 See [Fast Setup](#) or [Female Serial Pin out](#).

Inserting the SIM card

The IRG5410 comes with two SIM sockets for 2mini-SIM (2FF) cards.

Note: Ensure the power is disconnected before you insert the SIM card/s.

1. Using your Phillips screwdriver, removed the two screws cover from the panel covering the SIM slot.

Gently pry the cover loose from the opening.

2. Align the SIM card so that the SIM card will slide into the top slot (slot#1). The SIM card has a notched corner for orientation and the SIM card can only be inserted the correct way. You will hear an audible click when the SIM is inserted correctly. Always populate slot#1 first. Add a second SIM card if your network setup requires it.
3. Align the SIM cover plate and secure the plate with the screws.



Note: Do not force the SIM card in or you may damage the card or your IRG5410 router.

Connecting the Antenna/s

1. Connect your cellular antenna to the SMA cellular antenna connector labeled **Main**.
 2. Connect your GPS antenna to the SMA GPS antenna connector labeled **GNSS**.
 3. Mount the GPS antenna where it has a good view of the sky (at least 90°).
 4. Connect the diversity antenna to the SMA diversity antenna labeled **Diversity**.
- For models that have WLAN connectors, connect the WLAN antennas to **WLAN-1** and **WLAN-2**.

When attaching the antennas to the SMA connectors, line the inner hole within the antenna, then slide onto the pin encased in the connector on the router, gently push to connect, then turn only the securing ring and not the antenna to secure it to the router.



Warning: For Zone 2 and/or Class I, Division 2 hazardous location applications. Antennas intended for use with the product must be installed within the end use enclosure. For remote mounting of the antennas in unclassified or classified locations, routing and installation of the antennas shall be in accordance with the appropriate location regulations.

Connecting to the Ethernet Port


The Ethernet RJ45 port provides the standard Ethernet interface speeds of 10/100/1000 Mbps through twisted pair (UTP) cables of up to 100 meters (328ft) in length. Cat5e or Cat6 cables are recommended for 1000 Mbps connections.

Connecting to the Serial Port

The serial port has a 9-pin female port connector allowing you to directly connect to most computers or devices with a standard serial straight-through cable.

It is used for:

- Connect a serial device
- Connect as a console port
- As a GNSS output device



Note: When connecting to a DCE device, a crossover cable is needed.

Female Serial Pin out

Name	Pin	Description	Type
DCD	1	Data Carrier Detect	OUT
TXD	2	Transmit Data	OUT
RXD	3	Receive Data	IN
DTR	4	Data Terminal Ready	IN
GND	5	Ground	GND
DSR	6	Data Set Ready	OUT
RTS	7	Request to Send	IN
CTS	8	Clear to Send	OUT
RI	9	Not Connected	-

Connecting to the USB-C port in Console Mode

By default, the USB-C port is set to console mode.

In this mode, the USB-C port acts as a console port.

1. Connect the power. See [Connecting the Power](#).
2. Allow the router to complete the boot up sequence.
3. Connect a USB cable to the PC's USB port, then connect the other end of the cable to the router's USB-C connector.
4. On the PC Choose Start -> Control Panel -> Hardware and Sound (or equivalent) on the Windows Operating System. Choose the Device Manager, and expand the Ports section. The assigned COM port can be identified.
5. Start a terminal emulation program (such as Putty or SecureCRT) on the com port where you have connect the cable to the PC.
6. Press the Enter key on the keyboard and the prompt will display.

See the Perle IRG7000/5000 5G/LTE Router CLI Reference Guide for more information on using CLI commands.

Warning: If you connect or disconnect the console cable with the power applied to the router or any device on the network, an electrical arc can occur. This could cause an explosion when installed in a hazardous location. Ensure the power is removed from all devices prior to making any cable connections.

Warning: Do not use the USB port in a potentially explosive environment.


Connecting to the USB-C port as an Ethernet over USB Port

In this mode, the USB-C port behaves like a PC is connected to the Ethernet port, allowing access to networks and the Internet.

See the Perle IRG7000/5000 5G/LTE Router User's Guide and the Perle IRG7000/5000 5G/LTE Router CLI Reference Guide for more information on setting this parameter.

Connecting the Power

The wire colors shown are for the power/GPIO cable that is included with the IRG5410. Other wiring setups may have different colors. See [Appendix A—Technical Specifications](#).



Molex part number 2451320420 or equivalent
Rectangular socket to socket 6.56' (2.00m)

Note: Before servicing this product ensure the power source has been disconnected. Electrical installations should be performed by personnel thoroughly trained in safe electrical wiring procedures.

Operation

Reset / Factory Default / Safe Mode / DHCP/BOOTP (ZTP mode)

This table below shows how the reset button is used.

Reset Button



Mode	Description	LEDs	System Status
Restart	In router normal running state, press and Release the Reset button	Power LED will begin to blink amber	Reboots. All configuration and files will remain the same.
Factory Default	In router normal running state, press the Reset button and Hold for 10 seconds	When all LEDs flash Amber, release the Reset button, Power LED flashes Amber	Reboots and resets the configuration to the Perle factory default configuration. All configuration, User IDs, passwords, and security certificates are deleted.
DHCP/BOOTP (ZTP mode)	Set router in factory default mode, press and hold the reset button for 5 seconds	All LEDs will flash green, then release the reset button	Reboots the router into Fast setup DHCP/BOOTP (ZTP mode) running config will be copied to startup configuration router sends out DHCP client requests until it get a DHCP offer
Safe Mode	Press the Reset button while powering up	All LEDs, except Power blink Amber	<ul style="list-style-type: none"> • Saves the startup config • Boots with no config file • Allows you to do setup mode

Fast Setup

Fast Setup mode allows you to quickly configure basic operating parameters on your router.

Your Perle router has been shipped to you in Factory Default mode. On power up, your router is in “Fast Setup” mode with the Power LED flashing green. Make a connection to your router via the console port or a Web browser, then answer basic setup operating parameters such as your initial user ID and password.

To connect to the console port, follow the instructions provided in—*Connecting to the Serial Port*.

To connect using a Web browser, connect your PC’s Ethernet cable directly to an Ethernet port on the router. Configure the PC to use DHCP for obtaining its IP address. The router will act as a DHCP server and assign an IP address to the PC. Next, launch the Web browser and browse to “http://192.168.0.1”. The Fast Setup screen appears.

Refer to the Quick Start Guide or the Perle IRG7000/5000 5G/LTE Router User’s Guide for more information on setup instructions.

Managing the IRG5410

The IRG5410 can be configured, operated, and monitored using any of the following methods. See the Perle IRG7000/5000 5G/LTE Router User's Guide for more details on these methods.

WebManager

The Perle WebManager—an embedded Web based application provides an easy to use browser interface for configuring and managing the IRG5410. The WebManager is accessible through any standard desktop web browser. Configured a valid IP address on the IRG5410 before connecting with the WebManager.

CLI

A text-based Command Line Interface based on industry standard syntax and structure. The CLI is accessed from the console port. Once a valid IP address is configured on the IRG5410, Telnet, SSH, or the WebManager interface is used to access the IRG5410 for administration purposes. See the Perle IRG7000/5000 5G/LTE Router CLI Reference Guide for more information.

SNMP

The IRG5410 can be managed with an SNMP compatible management station that is running platforms such as HP OpenView.

Fast Setup Mode

If your router is in “Factory Default” mode, when you first connect, you will be in “Fast setup mode”. For more details, see—[Fast Setup](#).

PerleView

A Windows server-based centralized management package that simplifies the configuration, administration, monitoring, and troubleshooting of Perle Managed Media Converters, Ethernet Copper Extenders, Industrial Switches, IOLAN SCR/SCG and the IRG Series of Perle Routers. Your internet browser can securely access PerleVIEW and manage 10's, 100's or 1000's of Perle devices from a centralized server.

Power Management

Power Modes

The router has three operating power modes:

- Standard Mode
- Ignition Mode
- Smart Standby Mode

Standard Mode (default mode)

When power is applied to the router, it powers up. Both GPIO and IGN power inputs are ignored.

Ignition Mode

This mode monitors the ignition voltage input. When the voltage on the ignition input goes below a set pre-defined threshold, the router powers down into Standby mode. When the voltage on the ignition input goes above the router's pre-defined value it returns to normal operating mode (Wakeup).

Smart Standby Mode

You can configure a combination of one or two user defined conditions to determine when the router is powered up and when it goes into Standby mode.

Power Saving Options

Feature	Notes
Processor power savings	This feature optimizes idle power consumption, saving energy by reducing performance where possible.
LED power savings	Minimize use of LEDs, showing only alerts.
USB power saving	USB shutdown.
Ethernet power savings	Ethernet port savings can be achieved by; 1) Lowering Ethernet speed. 2) Ensuring EEE (Energy Efficient Ethernet) is enabled. 3) Shutting down unused Ethernet ports.
Serial Power savings	Shutting down serial port if it is not being used.
GNSS power savings	Shutting down GNSS if it is not being used.
Ignition shutdown delay	When powered by battery (car battery), the router can use the ignition sense pin on the DC power cable to shutdown after a user configured delay (i.e. once the ignition is turned off)
Low voltage standby	The router will enter standby mode if the voltage reaches a user defined threshold. This is intended as a battery saving feature.
Standby	When the router is not required for a specific time period or when the analog/digital inputs are in a particular state, it can be put into standby where minimal power will be consumed. When these conditions change, the router will automatically wake up and resume normal operations.

Power Saving Scenarios

Idle Mode setup

- Cellular connected (no activity)
- Ethernet connected (no activity)
- Serial disabled •USB connected (no activity)
- GPS enabled - active antenna
- CPU power savings mode disabled
- LED power savings mode disabled

Typical Mode setup

- Cellular connected
- Ethernet connected
- WIFI active
- Serial disable
- USB enabled
- GPS enabled - active antenna
- CPU power savings mode disabled
- LED power savings mode disabled

Standby mode setup

Cellular disconnected

- Ethernet disconnected
- Serial disabled •
- USB disconnected •
- GPS disconnected •
- CPU power savings mode enabled
- LED power savings mode enabled

Power consumption was measured at 12 V.

Sample Power Saving Scenarios

Model	Idle Mode		Typical Use		Standby	
	Current (A)	Power (W)	Current (A)	Power (W)	Current (mA)	Power (mW)
IRG5410 (1 Eth, LTE-A)	0.23	2.70	0.24	2.88	3.9	46.8
IRG 5410+ (1 Eth, LTE-A Pro)	0.25	2.70	0.24	2.88	3.9	46.8

Power consumption was measured at 12 V.

Note: up to 0.08A 1W more in power savings can be achieved through shutting down the USB port, LEDs, GPS as well as turning down router processor speed.

Note: To configure Power Modes, more information can be found in the Perle IRG7000/5000 5G/LTE Router User's Guide found on the Perle website.

Low Voltage Standby

This feature is intended to monitor the voltage being provided to the router in order to avoid a depletion of the battery. Should the voltage go below a user defined threshold condition, the router will enter Low Voltage Standby. When the voltage increases above the threshold, power will be resumed. This is a battery protection feature and therefore will override Ignition Mode and Smart Standby Mode. The feature can measure voltage either with the IGN pin or the GPIO (analog) pin. See the Perle IRG7000/5000 5G/LTE Router User's Guide how to configure this feature.

Overheat Standby


The internal ambient temperature of the router is continuously monitored and if the temperature remains above the router's primary high threshold alarm (default is 95°C/203°F) setting for 5 minutes, then your router will enter into Standby mode and remain in standby until the temperature returns to 5°C/9°F is below the primary high threshold value for 5 minutes. The high threshold can be configured within Alarm Manager /Primary/High Threshold menu.

Note: that any value below 60°C/140°F set for this threshold will be ignored and the value of 60°C/140°F will be used for the monitoring for overheat standby.

IRG Router Deployment Modes

Fixed Installation without I/O


For fixed installations, connect the wires as shown in the figure below. You configure Low Voltage Standby Mode (LVS) to force the IRG into Standby mode on low voltage. Voltage is monitored on Pin 3 and 4.



- Pin 1 (Power)—Use the Red wire in the DC cable to connect Pin 1 to the power source. Include a 4.0A fast acting fuse to the input line. A continuous (unswitched) DC power source is recommended.
- Pin 2 (Ground)—Use the Black wire in the DC cable to connect Pin 2 to Ground.
- Pin 3 (IGN–Ignition)—Connect to Power for voltage sensing.


Recommended Vehicle Installation (Ignition Mode)

For vehicle installations, connect the white IGN wire to the vehicle’s ignition switch as shown in the diagram below. This allows the IRG to operate with the vehicle. When the vehicle’s ignition is off the IRG enters Standby mode. Configure a time delay between the vehicle’s ignition shut off, and the time the IRG goes into Standby mode. A delayed Standby is used if you want to maintain a network connection while the vehicle’s engine is shut off for short periods of time—such as in a delivery vehicle.



- Pin 1 (Power)—Use the Red wire in the DC cable to connect Pin 1 to the power source. Include a 4.0A fast acting fuse in the input power line. continuous (unswitched) DC power source is recommended.
- Pin 2 (Ground)—Use the Black wire in the DC cable to connect Pin 2 to Ground.
- Pin 3 (IGN–Ignition)—It is recommended to use the IGN wire (Pin 3) to initiate Standby mode on the IRG.

Fixed Installation with Analog Input



- Pin 1 (Power)—Use the Red wire in the DC cable to connect Pin 1 to the power source. Include a 4.0 fast acting fuse in the input power line. continuous (unswitched) DC power source is recommended.
- Pin 2 (Ground)—Use the Black wire in the DC cable to connect Pin 2 to Ground.
- Pin 3 (IGN—Ignition)—Connect to Power.
- Pin 4 (GPIO)— In this example, the GPIO (green) used as an analog input to enter and exit Standby Mode.

For more information on configuring Standby Mode, Timed Standby Mode and Event Handling see the Perle IRG7000/5000 5G/LTE Router User's Guide.

I/O Configurations


You can configure Pin 4 (GPIO) green wire as:

- Pulse counter
- Digital input
- Analog input
- Digital Output / Low Side Current Sink
- Digital Output/Open Drain

Pulse Counter / Digital Input


You can connect pin4—GPIO:

- a pulse counter to monitor frequencies up to 512 Hz, with duty cycle between 25%-75%
- a digital input to detect the state of a switch
- a monitor to an external device such as a motion detector, a remote solar panel, or a remote camera.



Input Range	State
0 - 1V	Low
2.7 - 36V	High

High Side Pull-up / Dry Contact Switch Input




The voltage on Pin 4 when the high side pull-up is enabled (depends on the V_{in} and power consumption).

	Minimum	Typical	Maximum	Units
Source Current	0.6 $V_{in} = 7 \text{ V}$	1.1 $V_{in} = 12 \text{ V}$	3.5 $V_{in} = 36 \text{ V}$	mA

Analog Input


Connect the green wire—GPIO to an analog source. The router monitors voltages from the input source and transform them into analog values. Pin 4 can detect inputs of 0.5–36 V referenced to ground. By transforming the voltages, with the user defined formulas, the GPIO Pin can monitor measurements such as temperatures, sensors, or input voltages.



	Minimum	Maximum
Analog Input Range	0.5V	36V

Digital Output / Low Side Current Sink


Use Pin 4 - GPIO as a low side current sink.



State	Minimum	Typical	Maximum	Comments
On	200mA	500	850mA	$I_{\text{Typical}} = 25^{\circ}\text{C}$ $I_{\text{Min}} = 70^{\circ}\text{C}$ $I_{\text{Max}} = -40^{\circ}\text{C}$
Off	—	0	—	$V_{\text{in}} = 12$

Digital Output / Open Drain

You can use Pin 4—GPIO as an open drain to drive an external digital device.



Pull-up	State	Minimum	Typical	Maximum	Units
Off	Off	Open Circuit	—	—	—
	Active Low	—	—	0.5	V

Appendix A—Technical Specifications

Technical Specifications		
Cellular		
LTE	IRG5410 LTE-A CAT6 300Mbps downlink and 50Mbps uplink speeds	IRG5410+ LTE-A Pro CAT12, 600Mbps downlink and 150Mbps uplink speeds
Frequency Bands Data & SMS Operation over 4G LTE with fallback networks DC-HSPA+ / HSPA+ / HSPA / UMTS (WCDMA)Frequency Bands	4G/LTE Bands (15) 2100(B1), 1900(B2), 1800(B3), AWS(B4), 850(B5), 2600(B7), 900(B8), 700(B12), 700(B13), 800(B20), 1900(B25), 850(B26), 700(B29), 2300(B30), TDD B41 3G HSPA/HSPA+ Bands (6) 2100(B1), 1900(B2), 1800(B3), AWS(B4), 850(B5), 900(B8) Public Safety Band Band 26	4G/LTE Bands (24) 2100(B1), 1900(B2), 1800(B3), AWS(B4), 850(B5), 2600(B7), 900(B8), 1800(B9) 700(B12), 700(B13), 850(B18), 850(B19), 800(B20), 850(B26), 700(B28), 700(B29), 2300(B30), 1500(B32), TDD (B41), TDD (B42), TDD (B43), TDD (B46), CBRS B48, 1700(B66) 2100(B1), 1900(B2), 1800(B3), AWS(B4), 850(B5), 800(B6), 900(B8), 1700(B9) Public Safety Band Bands 26,28

Technical Specifications			
SIM	Dual Mini-SIM 15 x 25mm (or 2FF)		
GPS/GNSS			
GPS/GNSS	Wide-band GNSS: 1559-1606 MHz GPS: 1575.42 MHz / GLONASS: 1602 MHz / BeiDou: 1561.098 MHz / Galileo: 1575.42 MHz / QZSS: 1575.42 MHz Active GNSS antenna support Reports: NMEA 0183 V3.0, TAIP		
GPS / GNSS Passive Antenna	GNSS Applications: GPS, Glonass, Galileo, Beidou Frequency Range: 1561MHz~1606 MHz Gain: 4 dBi (typical) Impedance: 50 Ohm Voltage Standing Wave Ratio: 2.0 (typical) Polarization: RHCP SMA (M) (straight) Dimensions: 41.9 x 47.3 x 16.3 mm / 1.65 x 1.86 x 0.64 in RG-174 Cable length: 5m / 16ft		
Wi-Fi	IRG5000	IRG5500+	IRG5500+ FN
Models with Intergrated Wi-Fi	IRG5521 IRG5541	IRG5521 IRG5541+	IRG5521+ IRG5541+ FN
LAN standards	IEEE 802.11ac complaint & backward compatible with 802.11a/b/g/n		
Power/Current Consumption Standby Mode (no Activity with all ports shutdown)	All models: 3.9mA / 46.8mW		
One GPIO Input	Digital Input & Pulse Counting VDC: 0 for $\leq 1V$, 1 for $\geq 2.7V$ Dry Contact Max Current range: min 0.6mA @ 7V and max 3.5mA @ 36V Current Sink Output: 0.5A @ 12v		
Ignition Sense	Analog Input: 0.5V to 36V		

Technical Specifications			
Ethernet Port	1 Ethernet 10/100/1000 MBPS Ethernet RJ45 copper Auto-neg Isolation 1.5 kV IEEE 802.3 for 10Base-T IEEE 802.3u for 100Base-TX and 100Base-FX IEEE 802.3ab for 1000Base-T IEEE 802.3x for Flow Control		
USB	1 x USB, Type-C Can be used as a console or additional Ethernet port.		
RS232 Serial	1 DB9 Female connector Speeds 300bps-230Kbps or custom 15Kv ESD protection		
RS485	half-duplex		
Power and Auxiliary Connectors			
GPIO	Digital Input & Pulse Counting VDC: 0 for $\leq 1V$, 1 for $\geq 2.7V$ Dry Contact Max Current range: min 0.6mA @ 7V and max 3.5mA @ 36V Current Sink Output: 0.5A @ 12V		
Power/Current Consumption	Standby (no activity / all ports shutdown): 3.9mA / 46.8mW Idle Mode (connected/no Activity): 0.23A / 2.70W Typical Use (connected/with Activity): 0.24A / 2.88W	Standby (no activity / all ports shutdown): 3.9mA / 46.8mW Idle Mode (connected/no Activity): 0.25A / 2.94W Typical Use (connected/with Activity): 0.28A / 3.30W	
Note: up to 0.05A / 0.6W more in power savings can be achieved through shutting down the USB port, LEDs, GPS, as well as turning down router processor speed			
Two Digital Inputs	Digital Input & Pulse Counting VDC: 0 for $\leq 1V$, 1 for $\geq 2.7V$		
One Alarm Relay	Normally Open (NO) dry contact: 1A @ 24VDC		















Technical Specifications	
External Power Supply (optional)	110/220 VAC Power supply
Power Input	12/24 VDC Nominal (7-36 VDC range)
Vehicle Transient voltage protection	Built-in protection against voltage transient including 5 VDC engine cranking and +200 VDC load dump
Power Line Protection	Surge: 8V (EN61000-4-5 common mode), 2KV (EN61000-4-5 differential and common modes)
Ignition Sense	VDC voltage variation with On/Off timer
Reverse polarity protection	YES
Environmental Specifications	
Operating Temperature Ranges	-40°C to 70°C (40°F to 158°F)
Storage Temperature	-40°C to 85°C (40°F to 185°F)
Operating Humidity Ranges	0% to 95% non-condensing
Storage Humidity Ranges	0% to 95% non-condensing
Operating Altitude	Up to 3,048 meters (10,000 feet)
Cooling	EN 60068-2-1
Dry heat	EN 60068-2-2
Damp	EN 60068-2-30
MTBF	MTBF (no Wi-Fi): > 234,435 hours MTBF (with Wi-Fi): > 192,137 hours (Calculation model based on MIL-HDBK-217-FN2 @ 30°C/86°F)
Regulatory Approvals	
Cellular/Telecom	FCC/ICES, RED, PTCRB/CTIA,CE
Cellular Certifications	Verizon, AT&T
Shock and Vibration	EN 61373 (Shock, Vibration long-life / functional-random) MIL-STD-810G (Shock: test method 516.6. Operational Vibration: test method 514.6) SAE J1455 (Vibration: Section 4.10.4.1 and 4.10.4.2 Cab Mount, Shock: Section 4.11.3.4 Operational Shock)
Hazloc	IECEX/IECx, ATEX Class 1 Zone 2, Directive 2014/34/EU ANSI/ISA 12.12.01, Class 1 Division 2 Groups A-D, ISA 12.12.01-2015















Technical Specifications	
Vehicle Usage	E-Mark (UN ECE Regulation 10.04, ISO 7637-2:2011 and ISO 16750-2:2012)
Velocity	< 100m/s
Railway	EN 50155: 2017 Clause 4.3.6 EN 50121-1: 2017 EN 50121-3-2: 2016 EN 50121-4: 2016 IEC 60571:2012 For Clause 12.2.8 & 12.2.9 IEC 62236-1: 2018 IEC 62236-3-2: 2008 IEC 62236-4: 2018
Emissions	FCC 47 Part 15, Subpart B, Class A ICES-003 Issue 6 Class A (Canada) FCC Part 15.247 Subpart C (2.4 Ghz) FCC Part 15.407 Subpart E (5 Ghz) ANSI C63.4 Class A (Radio-Noise Emissions from Low-Voltage Electrical and Electronic Equipment in the Range of 9 kHz to 40 GHz) EN61000-3-2: 2014 (Limits for Harmonic Current Emissions) EN61000-3-3: 2013 (Limits of Voltage Fluctuations and Flicker) EN 61000-6-4:2007 + A1:2011 CISPR 32:2015/EN 55032:2015 Class A (Electromagnetic compatibility of multimedia equipment - Emission requirements)

Technical Specifications	
Immunity	CISPR 25:2016/EN55025: (Vehicles, boats and internal combustion engines - RDC) CISPR 35:2016/EN 55035:2017 (IR) EN 61000-4-2:2009 (ESD) +/-2 kV, +/-4 kV, +/-6 kV, +/-8 kV (Contact) +/-15 kV (Air) EN 61000-4-3: 2006 + A1:2007 + A2:2010(RS) EN 61000-4-4:2012 (EFT) 2 KV (Criteria A) EN 61000-4-5:2014+AMD1:2017 (Surge) 2KV (line to earth), 1.5KV (line to line) EN 61000-4-6: 2013 (CS) EN 61000-4-8: 2009 (PFMF) EN 61000-4-9: 2016 (PMF) EN 61000-4-11: 2004 + A1:2017 EN 61000-4-16 EN 61000-6-4: 2007 + A1: 2011 ISO 7637-2:2004
Safety	UL/ULC/EN 62368-1 (including CB) CE Mark CAN/CSA-C22.2 No. 62368-1-14 UL 61010-1 and 61010-2-201
Cellular / WWAN Radio Standards	EN 301 489-1 (V2.1.1:2017-02), ETSI EN 301 489-1 V2.1.1 (2017-02) EN 301 489-17 (V3.2.0:2017-03), ETSI EN 301 489-17 V3.1.1 (2017-02) EN 301 489-19 (V2.1.1:2019) EN 301 908-1 v11.1.7:2018-12, ETSI EN 301 908-1 V7.1.1 (2015-03) (Radiated emissions RF control and monitoring) EN 301 908-2 v11.1.2:2017-08, ETSI EN 301 908-2 V11.1.2 (2017-08) (RF conducted) EN 301 908-13 v11.1.2:2017-07, ETSI EN 301 908-13 V11.1.2 (2017-07) (RF Conducted) EN 62311:2019, IEC 62311 Ed. 1.0 b:2007 (Human exposure restrictions for radio frequency electromagnetic fields)
Environment Testing	
IP rating	Complaint to IP54
Drop	ISTA 2A 2001 test categorizes 1, 4,5, and 6

Technical Specifications	
Bandwidth	45 MHz
Impedance	50 Ohm
VSWR	2.0 Typical
Gain	RHCP
Polarization	4 dBic (typical)
Axial Ratio at elevation	5 dB (typical)
Vehicle Usage	E-Mark (UN ECE Regulation 10.04, ISO 7637-2:2011 and ISOk 16750-2:2012)
Vehicle Velocity	224 mph for cellular connectivity

Appendix B—Sample Labels

	IRG5410 P/N: 08000000	Contains: FCC-ID: N7NEM7455 IC: 2417C-EM7455
	S/N: 350-001319T00001 	 
IMEI: 861824563918001 	DEMKO 19 ATEX 2287 X II 3 G Ex ec IIC T4 Gc -40c ≤ Tamb. ≤ 70c 60 Rentrew Drive, Markham, Ontario, Canada. L3R 0E1	
MAC : 004002930000 		
Input : 7-36VDC, 1000mA max. 	I.T.E. E466997 IND. CONT. EQ. Surrounding Air Temp: Max. 70 Deg.C Min. -40 Deg.C Made in Taiwan	
    	LISTED E465984 IND. CONT. EQ. FOR HAZ. LOC. Class I, Division 2, Groups A,B,C and D Temp Code:T4A Max. Ambient 70 Deg.C Min. Ambient -40 Deg.C	

	IRG5410+ P/N: 08000010	Contains: FCC-ID: N7NEM75 IC: 2417C-EM75
	S/N: 350-011319T00001 	 
IMEI: 861824563918001 	DEMKO 19 ATEX 2287 X II 3 G Ex ec IIC T4 Gc -40c ≤ Tamb. ≤ 70c 60 Rentrew Drive, Markham, Ontario, Canada. L3R 0E1	
MAC :00400293000D 		
Input : 7-36VDC, 1000mA max. 	I.T.E. E466997 IND. CONT. EQ. Surrounding Air Temp: Max. 70 Deg.C Min. -40 Deg.C Made in Taiwan	
    	LISTED E465984 IND. CONT. EQ. FOR HAZ. LOC. Class I, Division 2, Groups A,B,C and D Temp Code:T4A Max. Ambient 70 Deg.C Min. Ambient -40 Deg.C	

Appendix C—Mounting the IRG5410

Option One

1. Attached the two DIN Rail screws to the holding plate. The DIN rail can be positioned either with the snap on connector in the down or up position on the holding plate in the up position.



2. Position the router so that the top hooks of the DIN rail clip attach onto the top of the DIN rail.
3. Rotate the bottom of the router towards the rail to snap the bottom hooks of the DIN rail clip onto the bottom of the DIN rail.

Option Two

1. Attached the two DIN Rail screws to the holding plate. The DIN rail can be positioned either with the snap on connector in the down or up position on the holding plate in the up position.




2. Slide the two screws into the holding plate, then attach that holding plate to the router. Slide the two screws into the holding plate, then attach that holding plate to the router.



3. Position the router such that the top hooks of the DIN Rail clip attach onto the top of the DIN Rail.
4. Rotate the bottom of the router towards the rail. This will snap the bottom hooks of the DIN Rail clip into the bottom of the DIN Rail.

Appendix D—Mechanical



Appendix E—Maintaining and Troubleshooting

Maintaining

- Ensure easy access to the cables
- Ensure cables are not bent, constricted, close to high amperages, or exposed to extreme temperatures
- Check that the Front panel LEDs are easily visible
- Wipe case clean with a dry cloth—do not use solvents or cleaning agents