



IOLINK-SOHO
Ethernet Bridge/Router

PPP Menus Reference Manual

Issue 5

Software Version 05P.03.06.xx and 05P04.01.xx

Throughout this manual, information that is presented by the router and entered into the router will be shown in a bordered box, as shown here.

```
Screen information being displayed or entered.
```

Initial Router & Management Console Power-Up

The following screen information will be seen on the console connected to the router when it is first powered on:

```
Terminals supported:
teletype ansi, avt, ibm3101, qvt109, qvt102, qvt119, tvi925, tvi950,
vt52,vt100, wyse-50, wyse-vp
Enter terminal type:
```

As the terminal type is not yet defined at the very first power-up, this screen may be slightly mixed up. Enter at least one <RETURN> (up to three if necessary) on the Network Console in order for the router to determine the baud rate of the terminal used for the console (i.e. auto-baud) and then proceed.

Select your terminal if listed and enter its name in lower case at the prompt, or choose the terminal type **teletype** if your terminal is not listed. The **teletype** terminal type operates in scroll mode and may be used successfully until a custom terminal definition is created.


Menu Command Entry

Once the terminal type is specified, the MAIN (LOGIN) MENU will be displayed.

The IOLINK SOHO Ethernet router uses a hotkey Menu. A menu option is chosen by selection of the desired option number.

Entry of parameters is from the > prompt. When a parameter is required, enter the necessary string and end it with a <Return>. If the entry is not accepted, an error message will be reported and the parameter will have to be re-entered. Should you make an error, the <BACKSPACE> key (for most terminals) deletes the most recently entered characters.

Menu Structure



The Menu Screens are structured with 11 primary elements:

1. Device Name
2. Software Version
3. Menu Name
4. Option Number and Option Name
5. Option Value
6. Option Description
7. Choosing an Option
8. Returning to the Main Menu
9. Returning to the Previous Menu
10. Command Prompt
11. ALARM display for a just-happened alarm event

Elements of the Menu Screens:

- 1. Device Name**

A default Device Name in the format DEVxx-xx-xx is supplied by the system for each router. (xxxxxx are the last 6 digits of the MAC address of the router). The Device Name may be changed in the Device Set-Up Menu.
- 2. Software Version**

The version of the software currently installed in the router is shown in the upper right-hand corner of each menu display.
- 3. Menu Name**

Each MENU is named to indicate its grouped Options..
- 4. Option Number and Option Name**

Choosing the number for the Option makes the selection. If you prefer a command-style interface, typing the first few unique letters of the desired Option is enough to identify the Option. Enter the selection with a <Return>.
- 5. Option Value**

The Value of an Option may indicate several parameters for example:

State	[enabled], [disabled], [present], [not_present], ...
Setting	[5 sec.], [5 min.], ...
Path	menu indicates a sub-menu
Name	[vt100], [Bridge_5], [none]
- 6. Option Description**

This is a single-line description of the Option.
- 7. Choosing an Option**

Select the Option by entering its number or unique first letters at the prompt.
- 8. Returning to the Main Menu**

The equals (=) sign returns you to the Main Menu. (All major menu paths start at the Main Menu. If you want to switch to the Main Menu, enter =).
- 9. Returning to the Previous Menu**

To go back to the previous higher level menu, enter a <TAB>.
- 10. Command Prompt >**

All data entry is made at the Command Prompt.
- 11. ALARM display for an occurring event**

The display of an ALARM notifies a viewing router manager that an event of significance has occurred. Since not every ALARM can be viewed as it occurs, the latest 199 ALARMS are recorded and can be viewed from the Network Events Menu.

Note: Depending on the configuration setting of this device, some options are not always displayed and some menus will have different options. Display lines with these options are in italics in this manual. If the option may appear on the menu screen with various numbers, the possible numbers are listed in the write up for the option, for example:

3/4 ISDN Set-Up.

Login Menu

```
                                LOGIN MENU

  Option          Description
  1. Login        - Initiate operator session
  2. Help         - Read menu introduction

Enter option number

>
```

This is the **LOGIN MENU** seen when powering up a console connected to the router.

1 - Login

The Login option allows entry of the password for the router. The default password is `BRIDGE` ; change it if security is desired. See the Installation & Applications Guide for information on restoring the default password to the router.

Action to Take:

Choose the Login Option and use the default password `BRIDGE`. The characters will not be echoed on the screen. Once the password is accepted, you will be given the expanded MAIN MENU for full access to router management features.

2 - Help

The Help option provides a brief description of menu format and usage.

Main Menu

MAIN MENU		
Option	Value	Description
1. Quick start	menu	- Quick start configuration menu
2. Configuration	menu	- Define operating parameters
3. Statistics	menu	- Device LAN and WAN statistics
4. Diagnostics	menu	- Access troubleshooting tools
5. Network events	menu	- View network event history
6. Save configuration		- Save configuration immediately
7. Logout		- End operator session
8. Help		- Read menu introductio

Enter option number
>

The **MAIN MENU** is a starting and ending point for management of the router. This menu allows access to menus and provides the Logout Option. Options 1-4 are major paths. To switch major paths, return to the MAIN MENU by entering = .

1 - Quick Start

The Quick Start option takes you to the Quick Start Menu, where a directly dialed ISDN call may be placed without having to configure a large number of parameters. The configuration parameters required to establish a direct dial ISDN call are definable within the Quick Start menu.

2 - Configuration

The Configuration option takes you to the Configuration Menu, where all the various router parameters can be defined. Take this path to define the operating parameters of the terminal used for the router console.

3 - Statistics

The Statistics option takes you to the Statistics Menu, where statistics can be examined to evaluate router, LAN, and link performance.

4 - Diagnostics

The Diagnostics option takes you to the Diagnostics Menu, where special diagnostic functions can be used to analyze LAN, link, and router problems.

5 - Network Events

The Network Events option takes you to the Network Events Menu, where the 199 latest Alarms can be examined.

6 - Save Configuration

The Save Configuration option performs an immediate save of the configuration to flash memory.

7 - Logout

The Logout option terminates your session and secures the router. The next user must log in and enter the correct password to view or change the router configuration.

8 - Help

The Help option provides a brief, one-screen description of menu format and usage.

Quick Start Menu

QUICK START MENU		
Option	Value	Description
1. ISDN set-up	menu	- Configure ISDN
2. Device name	"DEV050607"	- Name this device
3. Security level	[none]	- Set security protocol
4. IP address	[none]	- Define IP address and mask
5. Default gateway	[none]	- Define default gateway
6. Force disconnect		- Disconnect a call
7. Link status		- View status of link
8. Soft reset		- Reset device (retain configuration)

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **QUICK START MENU** provides configuration options to make an ISDN direct dial connection.

1 - ISDN set-up

The ISDN set-up option takes you to a menu where the switch type, dial prefix number and directory number(s) may be set. Depending on the switch type selected, Service Profile ID(s) may also be entered.

2 - Device name

The Device Name option allows you to name (or rename) this device for identification purposes. The router name will be displayed in both the Value column of this option and in the upper left-hand corner of all menu screens. If the router has not been named, the device name defaults to a prefix of DEV followed by the last six digits of the LAN port MAC address (eg. DEV050607).

3 - Security level

The Security Level option allows you to choose the type of security authentication to request from remote site PPP routers. The choices are none, PAP or CHAP.

Default: [none]

```
Enter :  
  none, PAP, CHAP  
  
>
```


4 - IP Address

The IP Address option allows the definition of an Internet Protocol (IP) address and corresponding subnet size for the router. The router requires an IP address.

The IP address consists of 4 octets and is represented by 4 fields separated by periods (.), where each field is specified by a decimal number (e.g. 92.3.1.10). Each decimal number must be less than or equal to 255, that is the maximum value of each 8-bit field.

The Subnet Size variable partitions the host field of an IP address into two parts: a *subnet number* and a *host number*. This is used when a site uses multiple logical networks within a single IP network address. The subnet size must be the same as the subnet mask used on the subnet this router is connected to. The subnet mask is defined as a series of contiguous bit locations from the start of the IP address.

Default: [none]

```
Enter :
  none, internet address (up to 15 characters)
>

Enter :
  size of subnet mask (from 8 to 32)
>
```

5 - Default gateway

The Default Gateway option allows the identification of a default gateway (i.e. *router*). Messages destined for hosts not on this (sub-)network are forwarded to the default gateway. The default gateway may be located on the local LAN or may be one of the remote site peer IP routers.

If the IP address of the remote site peer IP router is not known, the default gateway may be defined as the remote site ID. This will cause the default gateway to become whatever device is currently connected at that remote site.

When an SNMP message is to be sent to an NMS, first the routing table is checked for a known route. If a route to the NMS is unknown, the SNMP message will then be sent to the default gateway. If the default gateway cannot provide the best route, it will send the message to the gateway that can provide the best route. After the default gateway sends the message to the other gateway for delivery, the default gateway will send an ICMP Redirect message back to the router that points to the best route gateway. In this manner, the router is informed of the best route for future SNMP message delivery.

A configured Default Gateway will override a default route learned from RIP.

If there are more than one default gateways defined within the routing table, the default gateway with the lowest cost will be used and displayed in this option.

Default: [none]

```
Enter :
  none, gateway IP address, remote site ID or alias (up to 18 characters)
>
```

6 - Force Disconnect

The Force Disconnect option will cause the chosen link to be disconnected.

```
Enter :  
      Link to disconnect (1 or 2), all  
>
```

7 - Link Status

The Link Status option displays the status of the links, either individually (more statistics), or together (provides overview).

Please refer to the Link Status displays for more detailed information.

8 - Soft Reset

Selecting the Soft Reset option resets the router software and restarts the router. The current configuration is retained. Note that a hardware (and software) reset may be performed by toggling the switch behind the small access hole at the bottom of the faceplate on the right side.

ISDN Menu

ISDN MENU		
Option	Value	Description
1. Switch type	[Net3]	- Set switch type
2. Dial Prefix	[none]	- Set dial prefix
3. Directory number 1	[none]	- Set directory number
4. Directory number 2	[none]	- link 2 directory number
5. SPID 1	[none]	- link 1 service profile identifier
6. SPID 2	[none]	- link 2 service profile identifier

Enter option number, "=" - main menu, <TAB> - previous menu

>

The ISDN MENU

This menu allows the ISDN switch type to be set and connection numbers to be entered. For switch types NET3, 5ESS-PP, KDD, NTT and TPH1962, only a single directory number option is shown. For types DMS-100, NI-1, NI-2 and 5ESS-MP, the Directory number for a second link and Service profile identifier numbers for both links may be entered.

1 - Switch type

Choosing this option defines the ISDN switch (signaling) type that the router is connected to. When the switch type is changed, a **Soft Reset** must be performed before the change will take effect.

Default: [NET3]

Choises: DMS-100, NI-1, NI-2, 5ESS-MP, NET3, TPH1962, KDD, SWEDEN, and NTT

2 - Dial prefix

If the ISDN Orbiter is attached to an ISDN PBX and a dialing prefix is required to connect to an outside line, this option must be filled in with the required number. Enter the dial prefix code of the B-channel (up to 5 characters).

Default: [none]

3 - Directory number 1

Enter the ISDN number of the B-channel (up to 15 characters). The ISDN number is available from the ISDN circuit provider.

When the Directory Number is changed, a **Soft Reset** must be performed for this to take effect. The router will be reset and begin operation with the new directory number.

Default: [none]

The following options appear when a switch type DMS-100, NI-1, NI-2, or 5ESS-MP is selected:

4 - Directory number 2

Enter the ISDN number assigned to this B-channel. The ISDN number is available from the ISDN circuit provider.

When the Directory Number is changed, a **Soft Reset** must be performed for this to take effect. The router will be reset and begin operation with the new directory number.

5 - SPID 1

Enter the ISDN Service Profile Identifier (SPID) number assigned to this B-channel. The SPID number is available from the ISDN circuit provider.

6 - SPID 2

Enter the ISDN Service Profile Identifier (SPID) number assigned to this B-channel. The SPID number is available from the ISDN circuit provider.

When the SPID is changed, a **Soft Reset** must be performed for this to take effect. The router will be reset and begin operation with the ne

Configuration Menu

CONFIGURATION MENU		
Option	Value	Description
1. Access set-up	menu	- Establish access parameters
2. Internet set-up	menu	- Define IP environment
3. Applications set-up	menu	- Configure Internet applications
4. WAN set-up	menu	- Configure WAN operation
5. Bridging set-up	menu	- Define bridging environment
6. IP routing set-up	menu	- Define IP routing environment
7. IPX routing set-up	menu	- Define IPX environment
8. Filter set-up	menu	- Filter operations

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **CONFIGURATION MENU** provides paths to menus for total device configuration.

1 - Access Set-Up

The Access Set-up option takes you to the Access Set-Up Menu, where passwords, names, dates, and times are set and viewed. From this menu, you can save or restore the router configuration and connect to another router in the network of routers.

2 - Internet Set-Up

The Internet Set-up option takes you to the Internet Set-Up Menu, where the parameters for the Internet configuration are selected.

3 - Applications Set-Up

The Applications Set-up option takes you to the Applications Set-up Menu, where a number of internet connection management applications may be accessed.

4 - WAN Set-Up

The WAN Set-up option takes you to the WAN Set-Up Menu, where the Wide Area Network links are configured and controlled.

5 - Bridging Set-Up

The Bridging Set-up option takes you to the Bridging Set-Up Menu, where the parameters for bridging are selected.

6 - IP Routing Set-Up

The IP Routing Set-up option takes you to the IP Routing Set-Up Menu, where the parameters for IP routing are selected. IP routing may be enabled or disabled in this menu.

7 - IPX Routing Set-Up

The IPX Routing Set-up option takes you to the IPX Routing Set-Up Menu, where the parameters for IPX routing are selected. IPX routing may be enabled or disabled in this menu.

8 - Filter Set-Up

The Filter Set-up option takes you to the Filter Set-Up Menu, where you can create filters based on protocol types and custom specifications.

Access Set-Up Menu

ACCESS SET-UP MENU		
Option	Value	Description
1. Terminal set-up	menu	- Define operator's console
2. Device set-up	menu	- Set security/time/names
3. Telnet set-up	menu	- Set up remote communications
4. Upgrade device	menu	- Perform feature upgrade
4. Load FLASH set-up	menu	- Prepare for software update
5. Console	menu	- Dump/restore configuration from console
6. Hardware status		- Display hardware information
7. TFTP access	[disabled]	- Allow TFTP configuration saves/loads

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **ACCESS SET-UP MENU** provides options for saving and restoring the router configuration as well as paths to menus for terminal, device, and remote access configuration.

1 - Terminal Set-Up

The Terminal Set-up option takes you to the Terminal Set-Up Menu, where the terminal parameters used for the router console are selected.

2 - Device Set-Up

The Device Set-up option takes you to the Device Set-Up Menu, where the device name, password, dates, and times are set and viewed.

3 - Telnet Set-up

The Telnet Set-up option takes you to the Telnet Access Menu, where you can connect to another router in the network of routers.

4 - Upgrade Device

The Upgrade Device option takes you to the Upgrade Device Menu, where you can upgrade this device. Options include unlimited station count, data compression, firewall security and IPX routing. This menu option does not appear on routers with all functions enabled.

4/5 - Load FLASH Set-Up

The Load FLASH Set-up option takes you to the Load FLASH Set-Up Menu, where you can update the software in this device using TFTP or console Z-modem transfers.

Note: this operation cannot be performed from a secondary IP address.

5/6 - Console

The Console option takes you to the Console Menu, where a dump of the present configuration to the console computer for storage or a stored configuration uploaded from the console computer for restoration of the router configuration can be performed.

6/7 - Hardware Status

The Hardware Status option displays the status of the router hardware.

Hardware Status			
Boot Code version	: 05B1.3.1.2	System Code revision	: 2b10
Boot Code revision	: 0	Service reference	: 0/0
MAC address	: 02-03-04-05-06-07	RAM size	: 4 MB
MAC check code	: b9876d23	ROM size	: 1 MB
LAN interface type	: 10BaseT		
Link interface type	: BRIST		
Compression	: enabled		
Voice interface	: installed		

Boot Code version	The software boot code version currently installed in this IOLINK SOHO. This is the number that is displayed in the upper right of the menu screens when in console load mode.
Boot Code revision	The software boot code revision number currently installed in this IOLINK SOHO. A control number for tracking minor software revisions.
System Code revision	The system code software revision number currently installed in this IOLINK SOHO.
Service Reference	Internal factory reference number.
MAC Address	The MAC Address of the LAN port for this router.
MAC Check Code	Check code used for feature upgrades.
RAM size	The amount of RAM in this router.
ROM size	Indicates the size of the FLASH EEPROM installed.
LAN Interface Type	The type of LAN interfaces available for use on this router.
Link Interface Type	The type of link interface of this router installed in positions 1 and 2. Note: if a BRI interface module is installed, it must be in slot 1.

Compression	Indicates whether data compression is enabled or disabled.
Voice interface	Indicates the presence of the optional voice interface module.

7/8 - TFTP Access

The TFTP Access option determines whether a remote LAN device will be allowed to make a TFTP connection to this router to dump (get) or restore (put) the configuration.

The TFTP application must be in `netascii` or `ascii` mode for configuration transfers.

When you need to change the battery, you can dump the configuration to a PC disk. Then, when the new battery is installed, you can reload the configuration.

Default: [disabled]

Procedures for performing a Configuration Dump using TFTP:

- 1) Start the TFTP application to be used for transfers to the router.
(The IP address of the router may be found in the Internet Set-Up menu.)
- 2) Get the file `config.txt` from the router.
- 3) Use a text editor to check the configuration file saved to the PC disk to confirm that the information is still in order. If minor errors occurred, they may be corrected with the text editor. If errors were major, get the configuration file again.

Procedures for performing a Configuration Load using TFTP:

- 1) Start the TFTP application to be used for transfers to the router.
(The IP address of the router may be found in the Internet Set-Up menu.)
- 2) Put the file `config.txt` to the router.
- 3) When the transfer is complete, the configuration will have been restored to the router.

Terminal Set-Up Menu

TERMINAL SET-UP MENU		
Option	Value	Description
1. Terminal	[vt100]	- Define console terminal type
2. Show		- Display terminal definitions
3. Add		- Create a custom terminal definition
4. Remove		- Delete a terminal definition

Enter option number, "=" - main menu, <TAB> - previous menu

>

From the **TERMINAL SET-UP MENU**, the terminal used for the router console is defined. A custom definition can be added if the terminal to be used is not presently supported by the router.

1 - Terminal

The Terminal option defines the terminal type to be used for the router console. The current terminal type is displayed in the Value column for this option. When this option is selected, the available terminal types are displayed.

Default: Terminal type chosen at first power-up

Choices: ansi, avt, ibm3101, qvt109, qvt102, qvt119, tvi925, tvi950, vt52, vt100, wyse-50, wyse-vp, teletype

Considerations:

If your terminal is not listed:

- 1) Choose another of the same make to try the features it provides; or,
- 2) Choose the terminal type **teletype**. This terminal type operates in scroll mode and does not offer the highlighting that may be provided with the pre-defined or custom terminal types. Operating in this mode does not prevent any of the operations of the router.
- 3) For a complete solution, create your own custom terminal type and add it to the types supported by the router using the Add option.

2 - Show

The Show option displays all terminal definitions. This listing may be of use if you need to create a custom terminal definition.

3 - Add

The Add option allows you to define a custom terminal type if you will be using a terminal that is not supported as one of the Terminal option choices.

4 - Remove

The Remove option deletes a terminal definition. This will delete a newly created definition. To delete a terminal definition, enter the name of the terminal as shown when the Add or Show option is selected.

Device Set-Up Menu

DEVICE SET-UP MENU		
Option	Value	Description
1. Password		- Change login password
2. Device name	"DEV050607"	- Name this device
3. Show time		- Display current date and time
4. Set time		- Set date and time

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **DEVICE SET-UP MENU** allows the definition of the Device name, and a password to control local/remote access to the router management console. You can also set the real-time clock and date. Note that the clock is a 24-hour real-time clock.

1 - Password

The Password option allows you to change the router's login password. (The characters will **not** be echoed on the screen.) (If you have no need for a password, enter <NONE> in CAPS, and the entry of a password will be bypassed.) The password is case sensitive and must be entered precisely. An example is given below:

```
Enter:
  new password (1 to 8 characters)
> EURRNO\1

Enter:
  verification of new password (1 to 8 characters)
> EURRNO\1
New password installed
```

2 - Device Name

The Device Name option allows you to name (or re-name) this device for identification purposes. The router name will be displayed both in the Value column of this option and in the upper left-hand corner of all menu screens. If the router has not been named, the device name in the upper left-hand corner of the screen and the information in the Value column will show a prefix of DEV followed by the last six characters of the LAN port MAC address (e.g. DEV006045).

```
Enter:
  Device name string (up to 16 characters)
> Router5
```

3 - Show Time

The Show Time option allows you to view the current day of the week, date and time.

```
Wednesday 1998-08-05 15:16:16
```

4 - Set Time

Use the Set Time option to set the date and 24-hour Time Clock. Note that if your network uses the Bandwidth-On-Demand features of the IOLINK SOHO Ethernet router across time zones, you must standardize on one time zone on the routers.

```
Enter:  
  Date in format yyyy-mm-dd, no_change  
1998-09-27
```

```
Enter:  
  Time in format hh:mm:ss  
14: 25: 00
```

Telnet Set-Up Menu

TELNET SET-UP MENU		
Option	Value	Description
1. Telnet access	[enabled]	- Allow incoming Telnet connection
2. Telnet		- Connect to a remote device
3. Telnet port	[default]	- Alternate remote device port
4. Show names		- Display known device names
5. Add name		- Add a remote device name
6. Remove name		- Delete remote device name

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **TELNET SET_UP MENU** allows telnet connections to be made to other routers in the network.

1 - Telnet Access

The Telnet Access option allows LAN/WAN network devices to make Telnet connections to this router for management. Once the connection is established, the network device will be presented with the menu interface for configuration management and statistics viewing.

Default: [enabled]

Considerations:

When a Telnet connection is made to a router, ensure that the Telnet session is in character mode, and carriage return padding (or translation) is set to NULL (or no translation). The extra character sent when carriage return padding is on will cause some displays to behave erratically.

Note: A Telnet connection from another IP address is allowed three attempts to login with the correct password. After three failures, that IP address will be rejected for the following ten minutes if any further attempts are made and the following alarm message is logged and displayed on the console:

```
Alarm: Possible intruder 192.168.89.65 exceeded password attempts limit
```

Menus Reference Manual: Telnet Access Menu

2 - Telnet

Choosing the Telnet option, and specifying the name or IP address of the router you wish to connect to, connects to the other router for configuration purposes and viewing of statistics.

Noting the Device name at the top left of each Menu may identify the router being controlled.

If there is no data transmitted or received for a period of 5 minutes, the Telnet session will be disconnected. This time limit cannot be modified.

To disconnect from the router being controlled, enter Control-C (**^C**).

Considerations:

If the Internet Address of a remotely connected router is changed, immediately disconnect from the remote router by entering a Control-C (**^C**) and re-establish a new Telnet connection using the new Internet Address of the remote router.

3 - Telnet Port

The Telnet port option allows you to choose an alternate port number that a remote device can use for Telnet access to this router. This is necessary when Telnet is one of the exported services offered under Network Address Translation (NAT), as the well known port number will be used for the network Telnet server. An alternate port number must be supplied to Telnet to this router.

4 - Show Names

The Show Names option displays a listing of device names, their IP addresses and a user entered note of up to 75 characters.

```
Device Name          IP Address          Notes
-----
Tokyo                92.0.0.1            current device
Kyoto                92.0.0.2            on link 1
Amsterdam            92.0.0.5            on link 2

Type: [s] to redraw, [=] main menu, any other key to end.
```

5 - Add Name

Use the Add Name option to add a device name, IP address and any desired notes. Note that when a note is added, if spaces are desired within the note, you must enclose the note in quotations (). Ensure that the note is not more than 75 characters in length.

```
Enter:
  Device name (up to 16 characters)
>

Enter:
  IP address
>

Enter:
  Notes
>
```

6 - Remove Name

The Remove Name option allows you to remove a selected name. Note that the removal of a name also automatically removes the IP address and any notes associated with the name.

```
Enter:
  all, Device name
>
```


Load FLASH Set-Up Menu

```
                                LOAD FLASH SET-UP MENU

Option                          Description
1. Console (ZMODEM)            - Load through serial port
2. Network (TFTP)              - Load through IP network

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

From the **LOAD FLASH SET-UP MENU**, the software in the router may be updated to the latest version. The download file, referred to in this section as `###.all`, will be found in the directory with the new software release number `###` (e.g. 05P.03.06.02).

Considerations:

When installing a new version of operating software in a router, ensure that the current configuration is backed up before the installation process is started (see Access Setup Menu: Dump and Restore options).

Note: this operation cannot be performed from a secondary IP address.

1 - Console (ZMODEM)

Resets the router and places it in Console load mode. Once the router is in Console load mode, the `###.all` file may be sent using the ZMODEM transfer protocol. The Console load mode may only be used with a direct connection to the serial management port of the router.

The ZMODEM application **must** be in 32 bit CRC mode for software upgrade transfers. This option must be confirmed before operation by typing `yes` when prompted.

Procedures for performing a Console ZMODEM Flash Load to upgrade the operating software of the router:

- 1) Save the current configuration of the router (Main menu: option 6).
- 2) Execute the Console (ZMODEM) command from the Load FLASH Set-Up menu.
Confirmation is required. Enter `yes` to proceed.
- 3) After the router restarts, the router will be in receive ZMODEM mode. The router will display the following messages on the console port.

```
System startup
Receiving ZMODEM ...
**B0100000023be50
```

- 4) Start the ZMODEM transfer and send the file `###.all` from the Operational Code diskette.
- 5) Once the ZMODEM transfer is complete, the router will verify the file `###.all` in memory, program and verify the FLASH, clear the configuration to default values (except the password), and then reset. After the reset, the router will operate normally using the newly upgraded software. A byte status message will be displayed on the console port during the programming of the FLASH.

On the rare occasion that during the programming of the FLASH something happens to the bridge/router (power hit or hardware reset), causing the FLASH to become corrupted, the bridge/router will restart in ZMODEM receive mode only. If the bridge/router does not start in ZMODEM receive mode: power down the bridge/router, remove the case cover, remove the jumper on pins 3-4 of strap J2, power up the bridge/router, power down the bridge/router, re-install jumper on J2 pins 3-4, replace the case cover and power up the bridge/router. The bridge/router should now restart and be in ZMODEM receive mode. Please refer to the Servicing Information section of the Installation & Applications Guide for information on removing the case and changing the strap settings.

The ZMODEM Load Flash operation may be aborted (by aborting the ZMODEM transfer and then entering 5 control-X characters `^X` from the console keyboard. After the control-X characters are sent, the router will display a limited menu system. Choose the Abort Load option from the Load FLASH Set-Up menu. This will cause the router to reset and return to normal operations operating from the existing software.

If the ZMODEM transfer operation needs to be restarted after it has been canceled or after loading the first file, simply choose the Console (ZMODEM) option from the Load FLASH Set-Up menu once again.

Considerations:

When the router is placed in Console load BOOT mode, the LAN and WAN interfaces will be disabled. The router will only accept information from the console management port.

The BOOT code of the IOLINK SOHO may be upgraded by performing a load of the `###.all` file from the BOOT Code directory on the upgrade disk.

Maximum connection speed for ZMODEM transfer on an IOLINK SOHO is 9600 Bps.

2 - Network (TFTP)

Resets the router and places it in Network Load mode. Once the router is in Network Load mode, a TFTP connection may be made to the router to upgrade to a new version of software. Make sure to disconnect any telnet sessions to the router before starting the TFTP transfer

The TFTP application must be in octet or binary mode for software upgrade transfers.

Procedures for performing a Flash Load to upgrade the operating software of the router:

- 1) Execute the Network (TFTP) command from the Load FLASH Set-Up menu.
- 2) Enter none to connect locally or enter the remote site ID number or alias to connect to a remote site. Login when connected.
- 3) Start the TFTP application to be used for transfers to the router.
(The IP address of the router may be found in the Internet Set-Up menu.)
- 4) Put the file ###.all to the router from the Operational Code diskette.
(Any router not in Network Load BOOT mode will respond with an access violation error.)
- 5) The router will verify the file ###.all in memory, program and verify the FLASH, clear the configuration to default values (except: IP Address, IP Routing state, IP Forwarding state, WAN Environment, Link 1 & 2 State, the Switch Type, Directory Numbers, SPIDs, Password and connection data for the remote site, if applicable), and then reset. After the reset, the router will operate normally using the newly upgraded software. In some upgrade situations the Directory Numbers and SPIDs may be corrupted after the upgrade and will need to be re-entered.

- The router may take up to two (2) minutes to program and verify the FLASH. The console will not respond during this time.

To check on the router's current state during this process, get the file status.txt from the router. This file will report the router's state: both the mode and version if no errors have occurred, or an error message.

On the rare occasion that during the programming of the FLASH something happens to the bridge/router (power hit or hardware reset), causing the FLASH to become corrupted, the bridge/router will restart in ZMODEM receive mode only. If the bridge/router does not start in ZMODEM receive mode: power down the bridge/router, remove the case cover, remove the jumper on pins 3-4 of strap J2, power up the bridge/router, power down the bridge/router, re-install jumper on J2 pins 3-4, replace the case cover and power up the bridge/router. The bridge/router should now restart and be in ZMODEM receive mode. Please refer to the Servicing Information section of the Installation & Applications Guide for information on removing the case and changing the strap settings.

Menus Reference Manual: Load FLASH Menu

The TFTP Load Flash operation may be aborted by re-connecting to the console of the router and choosing the Abort Load option from the Load FLASH Set-Up menu. This will cause the router to reset and return to normal operations operating from the existing software.

Considerations:

When the router is placed in Network (TFTP) load mode, the router will restart and then remain idle.


In the following diagram of a cluster of routers, when upgrading the three IOLINK SOHO routers in the diagram, the upgrade order should be Router C, then Router B, and finally Router A.

A TFTP software load to router Router C would be performed as follows:

- Using TFTP, get config.txt from each router and save.
- Telnet to Router C. Enter the ID or alias of Router B in the Network (TFTP) option to put Router C in Network Load mode. When Router C restarts in Network Load mode, the connection to Router B will be re-established only if autocall is enabled on router B.
- The TFTP transfer of the upgrade code may now be performed from the PC to Router C. Once Router C has completed programming the flash and has restarted in operational mode, the connection to Router B will be re-established only if autocall is enabled on router B.

Once router C is operating with the new software, the PC may be used to reload the config.txt file back to Router C.

Repeat for Router B, then again for Router A. Perform the Router B upgrade using the ID or alias of Router A. Router A upgrades would not require a remote site ID as the PC used for TFTP transfers is located on the same LAN as Router A.



Console Menu

CONSOLE MENU	
Option	Description
1. Dump	- Back-up configuration from console
2. Restore	- Load configuration from console

Enter option number, "=" - main menu, <TAB> - previous menu

>

1 - Dump

Lists the configuration changes from the default settings to the console so it may be stored on a PC running a terminal-emulation package. This is an important step after configuration of the bridge/router, since the configuration changes would be lost in the event of battery failure or replacement.

The Dump option should not be used during a connection to another bridge/router.

Note that only changes from the default settings are saved, not the entire configuration.

Two kinds of settings are not considered to be part of the configuration, and therefore are not included in the dump: trace settings and the password.

Procedures for performing a Configuration Dump:

- 1) Prepare the emulation package so that it is ready to accept the transfer of the configuration file.
- 2) Send the file (dump) to the PC disk using the Dump command.
- 3) Use a text editor to check the configuration file saved to the PC disk to confirm that information is still in order. If minor errors occurred, they may be corrected with the text editor. If errors were major, check the emulation package settings and dump the configuration again.

2 - Restore

Restores a configuration to the bridge/router that was previously saved to a disk file with the Dump command.

Note that the Restore will only restore those configuration settings that were changed from the default settings at the time the Dump was performed; Restore does not overwrite the entire configuration. Any changes made since the Dump was performed will not be overwritten and will thus remain in effect after the restore. It is strongly recommended that you do a full reset (under the Diagnostics menu) before performing a Restore to be certain that the system is restored to the state it was in at the time of the Dump. After a full reset, the IP address of the router must be re-entered.

Considerations:

The terminal-emulation package selected should have the capability to pace the loading of commands into the bridge/router. This may be done through the setting of a delay timer (character or line pacing) or a wait for the echo of the character before transmitting the next character.

The pacing function is commonly available, although pacing procedures will vary with each emulation package.

The Load option should not be used during a connection to another bridge/router.

Procedures for performing a Configuration Load:

- 1) Prepare the PC to transfer the configuration file.
- 2) Execute the Load command.
Confirmation is required. Enter `yes` to proceed.
- 3) Send the file from the PC to the router.
- 4) When the transfer is complete, the configuration will have been restored to the bridge/router.

Internet Set-Up Menu

INTERNET SET-UP MENU		
Option	Value	Description
1. ARP set-up	menu	- Configure ARP operation
2. DNS set-up	menu	- Define DNS address(es)
3. Secondary IP set-up	menu	- Configure Secondary IP
4. Nonstandard subnets	[enabled]	- Allow subnet zero
5. IP address	[none]	- Define IP address
6. Default gateway	[none]	- Define default gateway
7. Time to live	[32]	- Router hops allowed
8. Ping		- Generate ICMP echo requests

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **INTERNET SET-UP MENU** contains options used to enable the router to be recognized as a device on the network. This is important to be able to route IP data and connect to other routers across the LAN, and for SNMP Network Management Stations to be able to access the router's SNMP agent.

1 - ARP Set-Up

The ARP Set-up option directs you to the ARP Set-Up Menu, where the ARP timers may be set and the ARP table may be viewed.

2 - DNS Set-Up

The DNS Set-up option directs you to the DNS Set-Up Menu, where the Primary and Secondary DNS (Domain Name Server) addresses may be set.

3 - Secondary IP Set-Up

The Secondary IP Set-up option takes you to the Secondary IP Set-up Menu, where this router may be configured to use secondary IP addresses on the local network for local routing.

4 - Nonstandard Subnets

The Nonstandard Subnets option allows the use of subnet addresses containing all zeroes or all ones.

Allows the definition of a subnet size starting at 1 instead of 2. When this option is enabled, the subnet size may be defined as values from 1 to 24 by setting the subnet mask between 32 and 8. The use of a subnet size of 1 (subnet mask = 32) allows a single IP network address to be split into two equal sized sub-networks each containing half of the number of allowable hosts of the original IP network address. A subnet size of 1 is accomplished by using all zeroes or all ones in the subnet portion of the address, this is not allowable with standard subnet masks.

Default: [enabled]

5 - IP Address

The IP Address option allows the definition of an Internet Protocol (IP) address and corresponding subnet size for the router. The router requires an IP address.

The IOLINK SOHO Ethernet router supports SNMP that uses UDP for message transmission, and UDP runs on top of IP. An IP address is also required to connect to other routers across the LAN by using Telnet (for example, from a remote router to a local bridge).

The IP address consists of 4 octets and is represented by 4 fields separated by periods (.), where each field is specified by a decimal number (e.g. 92.3.1.10). Each decimal number must be less than or equal to 255, that is the maximum value of each 8-bit field.

The Subnet Size variable partitions the host field of an IP address into two parts: a *subnet number* and a *host number*. This is used when a site uses multiple logical networks within a single IP network address. The subnet size must be the same as the subnet mask used on the subnet this router is connected to. The subnet mask is defined as a series of contiguous bit locations from the start of the IP address.

Note: after changing the IP address of this device, a soft reset must be performed to bring the change into effect.

Default: [none]

```
Enter :
      none, internet address (up to 15 characters)
>
Enter :
      size of subnet mask (from 8 to 32)
>
```

6 - Default Gateway

The Default Gateway option allows the identification of a default gateway (i.e. *router*). Messages destined for hosts not on this (sub-)network are forwarded to the default gateway. The default gateway may be located on the local LAN or may be one of the remote site peer IP routers.

If PPP is used and the IP address of the remote site peer IP router is not known, the default gateway may be defined as the remote site ID. This will cause the default gateway to become whatever device is currently connected at that remote site.

When an SNMP message is to be sent to an NMS, first the routing table is checked for a known route. If a route to the NMS is unknown, the SNMP message will then be sent to the default gateway. If the default gateway cannot provide the best route, it will send the message to the gateway that can provide the best route. After the default gateway sends the message to the other gateway for delivery, the default gateway will send an ICMP Redirect message back to the router that points to the best route gateway. In this manner, the router is informed of the best route for future SNMP message delivery.

A configured Default Gateway will override a default route learned from RIP. If there are more than one default gateways defined within the routing table, the default gateway with the lowest cost will be used and displayed in this option.

Menus Reference Manual: Internet Set-Up Menu

Default: [none]

```
Enter :  
    none, gateway IP address, remote site ID or alias (up to 18 characters)  
>
```

7 - Time To Live

The Time To Live option sets the maximum number of router hops that an IP packet generated by the router is allowed before being discarded.

IP packets that are being routed through the IOLINK SOHO Ethernet router will have their time-to-live value decremented by two.

Default: [32]

Range: 1 - 255

8 - Ping

The Ping option generates ICMP Ping messages to the specified destination IP address. The size and number of packets transmitted is entered within the command options. If you enter a broadcast address, you will be additionally prompted for LAN or Remote Site ID information. The ping broadcast will then be sent out the LAN port or to the remote site router.

```
Enter :  
    Destination (up to 15 characters)  
> 25.25.25.25  
  
Enter :  
    Length of data in bytes (1472 or lower)  
> 15  
  
Enter :  
    Number of packets to send (from 1 to 32767)  
> 1
```

The results of the Ping messages received will be displayed on the screen. The example below shows the results of an unsuccessful Ping command.

```
Ping to 25.25.25.25, 15 bytes, count 1  
Enter <Tab> or <Esc> to stop  
No Reply from 25.25.25.25 sequence 0 for 2.0 seconds  
Ping results for 25.25.25.25, packets transmitted 1, received 0  
  
Press any key to return to menu.
```

ARP Set-Up Menu

ARP SET-UP MENU		
Option	Value	Description
1. ARP aging timer	[2 min]	- Interval to remove entries
2. ARP retry timer	[2 sec]	- Interval to retry ARP
3. Add ARP entry		- Add static ARP entry
4. Remove ARP entry		- Delete static ARP entry
5. Show ARP table		- View ARP table

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **ARP SET-UP MENU** contains options used to view and maintain the ARP table for this device.

1 - ARP Aging Timer

The ARP Aging Timer option sets the ARP (Address Resolution Protocol) aging timer. Upon the expiration of the ARP aging timer, unused entries are removed from the ARP cache.

Default: [2 min]

Range: 1 to 1440 minutes (1 day)

2 - ARP Retry Timer

The ARP Retry Timer option sets the time-out value after which an ARP message will be resent.

Default: [2 sec]

Range: 1 - 20 seconds

3 Add ARP Entry

The Add ARP Entry option allows the manual entry of static addresses into the ARP table. When this option is selected, you are requested to enter the IP address, then to enter the MAC address of the node to be added.

4 Remove ARP Entry

The Remove ARP Entry option allows removal of node addresses from the ARP table. Entries may be removed individually by entering the IP address of the node to be removed. Groups of addresses may also be removed: all static addresses may be taken out by entering `static`, all dynamically assigned addresses by entering `dynamic` or the entire table may be cleared by entering `all`.

5 - Show ARP Table

The Show ARP Table option displays all of the devices that have responded to ARP requests from this router and the devices that this router has responded to with an ARP reply. IP address information learned (possibly via RIP) will also be added to the table to eliminate the need for generating an ARP request when data needs to be sent to that address in the future.

Arp Table			
Interface	IP Address	MAC Address	Type
LAN	164.44.25.142	00-00-d0-00-23-24	dynamic
LAN	164.44.25.98	00-00-d0-00-24-24	dynamic
LAN	164.44.25.37	00-00-d0-00-25-24	dynamic
LAN	164.44.25.13	00-00-d0-00-26-24	dynamic
LAN	164.44.25.33	00-00-d0-00-27-24	dynamic
Link 1	164.44.26.53	00-00-d0-00-28-24	dynamic
Link 2	164.44.27.76	00-00-d0-00-23-25	dynamic

Type: [s]tart, [n]ext, [=] main menu, any other key to end.

Interface: Interface on which the ARP mapping applies.

IP Address: IP address of the device in the ARP table.

MAC Address: MAC address of the device in the ARP table.

Type: Type of entry in the table, either dynamic (learned via ARP requests) or static (configured via SNMP).

DNS Set-up Menu

DNS SET-UP MENU		
Option	Value	Description
1. Primary DNS	[none]	- Address of Primary DNS
2. Secondary DNS	[none]	- Address of Secondary DNS
3. Domain name	[none]	- Network name

Enter option number, "=" - main menu, <TAB> - previous menu
>

The **DNS SET-UP MENU** contains options used to configure and maintain the DNS parameters for this device. The DHCP server will supply the IP address of the primary and secondary Domain Name Servers when this router is configured as a DHCP server. The DHCP server will not return an IP address if the DNS entries in this menu are set to none.

1 - Primary DNS

The Primary DNS option defines the IP address of the primary network Domain Name Server (DNS).

Default: [none]

2 - Secondary DNS

The Secondary DNS option defines the IP address of the secondary network Domain Name Server (DNS)

Default: [none]

3 - Domain Name

The Domain Name option allows the specification of a domain name of up to 254 characters.

Default: [none]

Considerations:

When setting up a router using IP addressing that will have a DNS server on the local network as well as a connection to an external DNS server (such as in Internet Service Provider), the local DNS server should be set as the Primary DNS and the external DNS server as the Secondary DNS.

Secondary IP Set-up Menu

```

                                SECONDARY SET-UP MENU

Option                          Value                          Description
1. Edit secondary entry        menu                          - Modify/add Secondary IP entry
2. Show secondary entries      -                             - Display secondary IP entries
3. Remove secondary entry      -                             - Delete secondary IP entry

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

The Secondary IP Set-Up Menu contains options to configure secondary networks or subnetworks on this network. This provides the ability to set up a number of independently addressed virtual networks or subnetworks on the same physical local area network (also known as Secondary IP Addressing). Up to 16 secondary IP networks may be defined on this router.

1 - Edit Secondary Entry

The Edit Secondary Entry option takes you to the Edit Secondary Entry Menu, where the parameters for the secondary IP networks are defined.

2 - Show Secondary Entries

The Show Secondary Entries option displays a listing of the entries in the Secondary local network table.

ID	Alias	Secondary IP Address	Subnet Size / Mask		Secondary IP Subnet/Network
1	LAN.1	199.65.43.21	24	255.255.255.0	199.65.43.0
2	LAN.2	198.123.45.67	28	255.255.225.240	198.123.45.64
12	LAN.12	199.76.54.32	14	255.252.0.0	199.76.0.0

ID: the identification numbers between 1 and 16 entered for the secondary local networks

Alias: the alias names assigned (automatically) to the secondary local networks; set as LAN.id#

Secondary IP Address: the IP addresses of this router on each of the secondary local networks

Subnet Mask Size: the number of bits set in the subnet mask for each of the secondary IP networks

Subnet mask: the four decimal number representation of the bits set for the subnet mask.

Secondary IP Subnet / Network: the network or subnet IP address of the secondary subnet or network as defined by the Secondary IP Address and subnet mask.

3 - Remove Secondary Entry

The Remove Secondary Entry option allows you to delete a selected entry from the secondary local network table, or to clear all entries.

Edit Secondary Entry Menu

EDIT SECONDARY ENTRY MENU		
Option	Value	Description
1. Secondary IP	*[]	- Secondary IP address
2. Mask size	*[]	- Secondary subnet mask size
3. Subnet mask	*[]	- Secondary subnet mask
4. Routing protocol	[]	- Define routing protocol
5. RIP mode	[]	- Define RIP send/receive mode
6. Private route	[]	- Do not advertise this route
7. Route cost	[]	- Cost added to learned routes

Enter :
Set the entry ID (from 1 to 16)

>

The Edit Secondary Entry Menu provides options for entering parameters for routing to secondary networks or subnetworks through this router.

When an ID number for a secondary network is entered for the first time, you will be prompted to enter the defining IP address and mask size for the network. Once the secondary network is defined, the IP address and mask cannot be edited with this menu; the entry must be removed and re-entered to change these parameters.

1 - Secondary IP

The Secondary IP Address for this router on the secondary network or subnet with the new ID number is entered here the first time the ID number for this secondary network is entered.

The secondary IP address is used to access the secondary subnet or network through this router.

The IP address consists of 4 eight-bit fields separated by periods (.), where each field is specified by a decimal number (e.g. 92.3.1.10). Each decimal number must be less than or equal to 255 (the maximum value of an 8-bit binary number).

* Display only. This address is set when the entry is defined for the first time and may not be changed here; to make a change, the entry must be removed from the secondary address table and re-entered.

2 - Mask Size

The Mask Size defines the number of contiguous bit locations from the start of the IP address to be used for the subnet mask for this secondary network. The Subnet Mask when applied to the secondary IP address defines this Secondary IP subnet or network.

* Display only. This number is set when the entry is defined for the first time and may not be changed here; to make a change, the entry must be removed from the secondary address table and re-entered.

3 - Subnet Mask

The Subnet Mask option displays the subnet mask defined by the subnet mask size in option 2.

* Display only. This mask is set when the mask size entry is defined for the first time and may not be changed here; to make a change, the entry must be removed from the secondary address table and re-entered.

4 - Routing Protocol

The Routing Protocol option defines the type of IP routing protocol to be used on this secondary network.

When the routing protocol is defined as none, the IOLINK SOHO will NOT participate in the exchange of RIP messages for this secondary network with the other networks. Routing on this secondary network is accomplished by using static routes. All routes within this secondary network must be manually entered as the static routes. Host devices and other routers on this network must be statically configured (they will not receive RIP messages). Routes with next hops on this network must be statically configured on this router. In addition to the static routes entered, this router will use routing information learned from other interfaces and networks

When the routing protocol is defined as rip1, the IOLINK SOHO will use RIP1 IP protocol for this secondary network. All routing information will be sent and received via broadcast RIP packets.

When the routing protocol is defined as rip1_compatible, the IOLINK SOHO will use RIP2 IP protocol in broadcast mode for this secondary network. All routing information will be sent via broadcast RIP2 packets. Routing information may be received as broadcast RIP1, broadcast RIP2, or multicast RIP2.

When the routing protocol is defined as rip2, the IOLINK SOHO will use RIP2 IP protocol for this secondary network. All routing information will be sent via multicast RIP2 packets. Routing information may be received as broadcast RIP2 or multicast RIP2.

Networks on this router do not need to use the same IP routing protocols. For example, one secondary network may be set as RIP_compatible to learn and advertise changes to the network, while another may be set to none and must use static routes.

Default: [rip1_compatible]

Choices: none, rip1, rip1_compatible, rip2

5 - RIP Mode

The RIP Mode option defines how this IOLINK SOHO will participate in RIP IP routing message exchange for this subnet.

When the RIP mode is set to both, the IOLINK SOHO will send and receive RIP routing messages.

When the RIP mode is set to send_only, the IOLINK SOHO will only send RIP routing messages.

When the RIP mode is set to receive_only, the IOLINK SOHO will only receive RIP routing messages.

Default: [both]

Choices: both, send_only, receive_only

6 - Private Route

Setting this secondary network IP address to be a private route causes the IP address and network to not be advertised in the RIP information.

Default: [disabled]

7 - Route Cost

The Route Cost option defines the amount of extra routing cost (in hops) to add to routes that are learned from this Secondary network. This can be used in the case of multiple routes to artificially increase the cost of a less preferred route so that it will be used only if the preferred route is not available. The cost will not be added (and thus not appear in the route statistics) until a connection is made.

Default: [0]

Applications Set-Up Menu

APPLICATIONS SET-UP MENU		
Option	Value	Description
1. SNMP set-up	menu	- Define SNMP communications
2. DHCP set-up	menu	- Define DHCP configuration
3. Firewall set-up	menu	- Define firewall parameters
4. NAT exports	menu	- Define exported services for NAT
5. Syslog set-up	menu	- Define Syslog configuration

Enter option number, "=" - main menu, <TAB> - previous menu
>

The **APPLICATIONS SET-UP MENU** provides paths to menus for Internet communication management applications.

1 - SNMP Set-Up

The SNMP Set-up option takes you to the SNMP Set-Up Menu, where you to define the parameters necessary to allow the router's SNMP agent and corresponding MIB information to be accessed by an SNMP Network Management Station. Traps (Alarms) will also be sent by the router to the NMS to inform it of a significant event (cold start, warm start, link up, link down, and authentication failure).

2 - DHCP Set-Up

The DHCP Set-up option directs you to the DHCP Set-Up Menu, where the DHCP (Dynamic Host Configuration Protocol) parameters may be set and the IP address pool may be viewed.

3 - Firewall Set-Up

The Firewall Set-up option directs you to the Firewall Set-Up Menu, where the IP Firewall parameters may be set. This menu is only available when Firewall Support is enabled for this device.

4 - NAT Exports

The NAT Exports option directs you to the NAT Exports Menu, where Internet services available for export on this network may be set up, checked, or removed.

5. Syslog Set-Up

The Syslog Set-up option directs you to the Syslog Set-up Menu, where a system message logging service to forward event messages to servers using the Syslog utility may be set up.

SNMP Set-Up Menu

SNMP SET-UP MENU		
Option	Value	Description
1. Edit community	menu	- Modify SNMP community
2. Message size	[1472 bytes]	- Define maximum message size
3. Show communities		- View SNMP communities
4. Remove community		- Delete SNMP community

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **SNMP SET-UP MENU** allows the display and configuration of the Simple Network Management Protocol (SNMP) parameters for the router. For information on the IOLINK SOHOs compliance with the SNMP Management Information Bases (MIBs) and details of the proprietary MIB, please refer to the MIB diskette included with the unit.

The SNMP Set Up Menu contains two default communities:

- "public" which is a read-only community accessible by all Network Management Station (NMS) addresses
- "GUI_Config" which is a read-write community accessible by all NMS addresses

1 - Edit Community

The Edit Community option takes you to the Define Community Menu, where the router's agent and NMS are brought under a management community.

2 - Message Size

The Message Size option allows the setting of the maximum message size sent by the router's SNMP agent.

Default: [1472 bytes]

Range: 484 to 1472 bytes

Considerations:

The message size sent by the router is determined by what the NMS can accept. The default size of 1472 bytes, combined with the overhead, totals the maximum Ethernet frame size.

3 - Show Communities

The Show Communities option displays the defined SNMP communities.

```
SNMP Communities
Number of defined communities : 3
Community Name  Write Access  Addresses      Trap Format
GIU_Config      enabled      all            -
Public          disabled     all            -
NMS_1           enabled      92.0.0.1      SNMPv1
                111.1.1.1    SNMPv2
Type: [s] to redraw, [=] main menu, any other key to end.
```

4 - Remove Community

The Remove Community option deletes the specified SNMP community from the list of available communities. Enter either the community name for a single deletion or `all` if the entire SNMP community list is to be deleted. Note that removing all communities will prevent access from any NMS until replacements are added.

Edit Community Menu

EDIT COMMUNITY MENU		
Option	Value	Description
1. Write access	[]	- Allow write access
2. Show addresses		- View address lists
3. Add address		- Add address and trap format
4. Remove address		- Delete address from list

Enter:
community name string (up to 32 characters)
>

Note: only alphanumeric characters and the underscore (_) character may be used in the community name. In addition, the characters are **case-sensitive**. Once the community name is defined, it is added to the Menu title (as shown below), and the options become available.

EDIT COMMUNITY Marketing MENU		
Option	Value	Description
1. Write access	[disabled]	- Allow write access
2. Show addresses		- View address lists
3. Add address		- Add address and trap format
4. Remove address		- Delete address from list

Enter:
>

1 - Write Access

The Write Access option defaults to [disabled] when a SNMP Community name string is entered. This allows an NMS to have read-only access to this SNMP Community. Write access [enabled] allows a NMS to have read/write access to the SNMP community.

Considerations:

If several NMSs are available at one site, a community might be named `Public` with read-only access. This allows all NMS managers to view SNMP information for the router, although only the community(ies) with read/write access [enabled] will be able to modify parameters. (Note that the community name `all` should not be used, since, if it were ever removed, other defined communities would be removed along with it).

2 - Show Addresses

The Show Addresses option provides a display of existing NMS and trap addresses for this Community name (e.g. Marketing).

```
Address Lists for Community Marketing
Total NMS addresses      :   3

Addresses                Trap Format
192.24.56.1             SNMPv1
111.1.1.1               SNMPv2
all                      -
```

3 - Add Address

Up to 10 addresses may be added to the address list. If the address list is empty, the router's SNMP agent will not accept requests from a NMS, even if it correctly provides this community name. If the list contains the single entry `all`, the router's SNMP agent will accept requests from any NMS providing this community name. Addresses must be entered in standard IP format (four fields separated by a periods, with each field specifying a decimal number).

When a trap is generated by the router's SNMP agent, it will be sent (along with the Community name) to each of the destination addresses specified.

Considerations:

If `all` is initially chosen for the address list, and (one or more) specific addresses are desired as a replacement, remove `all` with *Option 4, Remove address*, to allow the addition of the new address(es).

4 - Remove Address

The Remove Address option deletes the specified address associated with the SNMP Community. Other addresses remain unaffected. (If `all` is specified, all addresses are deleted.)

DHCP Set-Up Menu

DHCP SET-UP MENU		
Option	Value	Description
1. Server IP address pool	menu	- Range of allowable Addresses
2. NetBIOS setup	menu	- NetBIOS parameters
3. DHCP services	[none]	- Set DHCP operational mode
4. Relay destination	[none]	- BOOTP/DHCP server IP address
5. ICMP echo verification	[enabled]	- Ping allocated IP address
6. Lease period	[60]	- Length of lease (minutes)

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **DHCP SET-UP MENU** contains options used to dynamically configure and maintain the DHCP parameters for remote devices on a network via a central DHCP server. Dynamic Host Configuration Protocol (DHCP) allows configuration of devices (DHCP clients) to be handled from a central DHCP server. This allows devices to be added and removed from a network with all of the network information (i.e. IP address, DNS, subnet mask, etc.) being configured automatically. It is designed to allocate network addresses to a number of hosts on the IOLINK SOHO s LAN and supply minimal configuration needed to allow hosts to operate in an IP network.

Note: DHCP is not available for addresses on secondary IP networks or subnetworks (local routing).

1 - Server IP Address Pool

The Server IP address pool option directs you to the Server IP address pool Menu, where the range of allowable IP addresses may be set.

2 - NetBIOS Set-Up

The NetBIOS set-up option directs you to the NetBIOS set-up Menu, where the NetBIOS parameters may be set.

3 - DHCP Services

The DHCP services option sets the DHCP operational mode as none, server or relay. Selecting `none` disables the option. Selecting `server` enables this IOLINK SOHO to act as a simple DHCP server for its LAN. Selecting `relay` enables the IOLINK SOHO to relay DHCP service data to a remote DHCP server.

Default: none

Choices: none, server, relay

4 - Relay Destination

The Relay destination option allows you to enter the IP address of the remote DHCP server to which DHCP client data will be routed.

Note: BootP Relay should only be used with leased line connections, it is not recommended when using any form of connection management (spoofing, IP address connect) on a dial-up line.

Default: none

5 - ICMP Echo Verification

The ICMP echo verification option enables or disables the ping allocated IP address. If enabled, ICMP Ping messages may be sent to the specified IP address when a Ping command is issued.

Default: enabled

6 - Lease Period

The Lease period option sets the length of time (in minutes) that an assigned IP address will be allocated to a DHCP client.

Default: 60

Range: 10 to 65535 minutes

Server IP Address Pool Menu

```
SERVER IP ADDRESS POOL MENU

Option          Value          Description
1. IP address pool [none]      - Specify IP address pool
2. Show address pool      - Display allocated addresses
3. Add static Address     - Specify clients IP/MAC address
4. Remove static address  - Remove static IP address

Enter option number, "=" - main menu, <TAB> - previous menu
>
```

The **SERVER IP ADDRESS POOL MENU** contains options used to view and maintain the Server IP address pool for the DHCP server of this device.

1 - IP Address Pool

The IP address pool option sets the IP address pool. A block of IP addresses may be configured from which the server will hand out IP addresses. The first address in the range must be specified followed by the number of addresses desired.

Default: none

Range: 1 to 253 addresses

Considerations:

IP address assigned to the pool must be on the same IP network or the LAN of which this IOLINK SOHO is a part.

2 - Show Address Pool

```
DHCP Server IP Address Pool
Pool Address      Type      Hardware Address      Lease Remaining
-----
129.0.0.25       Dynamic   00-00-D0-00-12-34      45
129.0.0.26       Dynamic   00-00-D0-00-12-35      Reserved
129.0.0.27       Static    00-00-D0-00-12-36      55
129.0.0.28       Static    00-00-D0-00-12-3      Reserved
129.0.0.29       Dynamic   Available

Type: [s] to redraw, [=] main menu, any other key to end.
```


3 - Add Static Address

The Add static address option assigns a specific IP address to a specific device, such as a network server, from the central DHCP server. When this option is selected, first enter the IP address to be assigned to the device, then the MAC of the device.

4 - Remove Static Address

The Remove static address option removes the static address assignment from a device. Devices may be removed individually by entering the MAC of the device to be taken off, or the entire list of static address assignments may be cleared by entering `all` .

NetBIOS Set-Up Menu

NETBIOS SETUP MENU		
Option	Value	Description
1. Send NetBIOS node type	[enabled]	- Send node type to client
2. Send NetBIOS scope	[enabled]	- Send scope identifier
3. Send NetBIOS name srv	[enabled]	- Send name server address
4. <i>NetBIOS node type</i>	<i>[B]</i>	- <i>Type of name resolution</i>
5. <i>NetBIOS scope Id</i>	<i>"DEV050607_scope"</i>	- <i>Scope identifier</i>
6. <i>NetBIOS name server</i>	<i>[none]</i>	- <i>IP address of name server</i>

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **NETBIOS SET-UP MENU** contains options used to configure and maintain the NetBIOS parameters for this device. NetBIOS is used by Windows NT or Windows 95 clients to advertise themselves and to locate resources. When a netBIOS client initializes, it must advertise its machine name; the Windows NT server then finds the IP address associated with that name.

1 - Send NetBIOS Node Type

The Send NetBIOS node type option sends the node type to the client when enabled. If disabled, broadcasts will be used to advertise and locate resources.

Default: disabled

2 - Send NetBIOS Scope

The Send NetBIOS scope option sends the scope identifier to the client when enabled. The scope identifier is a name for the group of computers to which the NetBIOS name of this router is known

Default: disabled

3 - Send NetBIOS Name Srv

The Send NetBIOS name srv option sends the name server address to the client when enabled.

Default: disabled

4 - NetBIOS Node Type

The NetBIOS node type option allows you to set the type name resolution. The Send NetBIOS node type option must be enabled before this option will be displayed.

Default: disabled

Choices: B - broadcasts node names and queries

P - point-to-point communication with the NetBIOS name server to resolve and register NetBIOS names.

M - mixed; a combination of B and P communication. Traffic is first broadcast on the local segment and attached segments configured to propagate NetBIOS broadcasts. Once a NetBIOS name server is located, point-to-point communication across routers is allowed.

H - hybrid; a mixture of B and P communications. P is used if a NetBIOS name server is available, otherwise B is used.

5 - NetBIOS Scope Id

The NetBIOS scope Id option allows you to set the scope identifier. The default scope identifier will be the device name followed by `_scope` (i.e. `DEVXXX_scope`). The Send NetBIOS scope option must be enabled before this option will be displayed.

Default: DEVXXX_scope

6 - NetBIOS Name Server

The NetBIOS name server option allows you to set the IP address of the NetBIOS name server. The Send NetBIOS name srv option must be enabled before this option will be displayed.

Default: none

Firewall Set-Up Menu

FIREWALL SET-UP MENU		
Option	Value	Description
1. Designated servers	menu	- Edit entry for a specific server
2. Edit firewall entry	menu	- Edit/Add firewall entries
3. Firewall support	[disabled]	- Enable/disable firewall support
4. Block src IP spoofing	[disabled]	- Discard WAN pkts with local src IP
5. Firewall statistics		- View firewall statistics
6. Show firewall entries		- Display firewall entries
7. Remove entry		- Remove a firewall entry
8. Clear statistics		- Clear firewall statistics

Enter option number, "=" - main menu, <TAB> - previous menu
>

The **FIREWALL SET-UP MENU** contains options used to view and maintain the IP firewall settings for this device.

Remember that when the firewall function is enabled, **all incoming IP traffic EXCEPT normal TCP traffic** from the Wide Area Network (WAN) will be **filtered**. This means that only regular TCP connection traffic will be allowed through the firewall. Other IP traffic like UDP (ping), and TCP connection initiation data received from remote sites will be filtered and not allowed through the firewall.

To allow specific IP traffic to be passed from the connected remote site to this local LAN, either a firewall entry must be specified or a designated server must be specified or a combination of the two.

TCP connections initiated from the local LAN will be allowed to remote site resources. Once the TCP connections have been established, normal TCP connection traffic will be allowed between the local and remote device.

1 - Designated Servers

The Designated Servers option directs you to the Designated Servers Menu, where the IP addresses may be defined for the designated servers on the local LAN. A designated server is a device that is legally accessible from the remote site locations. Such designated servers may be the HTTP server and the FTP server on the local LAN that may be accessed by devices located on remote site LANs.

2 - Edit Firewall Entry

This option directs you to the Edit Firewall Entry Menu, where a table of entries that are to be allowed through the firewall is defined. A firewall entry allows all IP traffic from a specific remote site IP network to access the local LAN. The Firewall table may have up to 64 entries.

3 - Firewall support

The Firewall Support option enables or disables the IP Firewall functions of this IOLINK SOHO. **All incoming IP traffic EXCEPT normal TCP traffic** from the Wide Area Network (WAN) will be **filtered**. This means that only regular TCP connection traffic will be allowed through the firewall. Other IP traffic like UDP, ICMP (ping), and TCP connection initiation data received from remote sites will be filtered and not allowed through the firewall.

Incoming TCP connections that are allowed must be defined within the Firewall Set-up menu. To allow specific IP traffic to be passed from the connected remote site to this local LAN, either a firewall entry must be specified or a designated server must be specified or a combination of the two.

TCP connections initiated from the local LAN will be allowed to external remote site resources. Once the TCP connections have been established, normal TCP connection traffic will be allowed between the local and remote device.

Once the Firewall function is enabled, the IP traffic that is allowed to be received from the remote sites must be defined within the Firewall Set-Up Menu.

Default: [disabled]

4 - Block Source IP Spoofing

When the Block Source IP Spoofing option is enabled, all of the WAN traffic that uses a source IP address the same as the local network IP address will be filtered. This prevents devices located on a remote site network from attempting to gain access to the local network by using a local IP address as their source address. The IOLINK SOHO will discard any IP traffic that is received from the WAN with a source IP address the same as an IP address located on the locally connected LAN.

Default: [disabled]

5 - Firewall Statistics

The Firewall Statistics option displays a summary of the number of frames discarded by the firewall function.

The firewall statistics may be cleared with the Clear All Statistics option in the Statistics Set-up menu.

Firewall Statistics	
Frames discarded	Totals
Source IP spoofed	0
Source IP address	0
Destination IP address	0
Protocol number	0
Port number	0
Total frames discarded	0

Source IP Spoofed:	Incoming WAN frames discarded due to source IP address being the same as an IP address already on the local network.
Source IP Address:	Incoming WAN frames discarded because the source IP address on the remote site network is not allowed to access this local network.
Destination IP Address:	Incoming WAN frames discarded because the destination IP address on the local network is not allowed to be accessed from any remote site network.
Protocol Number:	Incoming WAN frames discarded because the protocol type is not allowed.
Port Number:	Incoming WAN frames discarded because the port number is not allowed..
Total Number:	Total number of incoming WAN frames discarded due to firewall filtering.

Menus Reference Manual: Firewall Set-Up Menu

6 - Show Firewall Entries

The Show Firewall Entries option displays all of the entries in the Firewall table. Entries marked with a ** indicate an entry from the Designated Servers menu.

Firewall Entries						
#	Source / Dest address	Source / Destination mask	Type	Port 1	Port n	Alias
**	All addresses 199.167.3.145	None None	TCP	20	21	FTP server
**	All addresses 199.167.3.139	None None	TCP	80	80	WWW server
1	199.167.4.0 199.167.3.0	255.255.255.0 255.255.255.0	TCP	1	65535	Manual entry

#:	Entry number in the Firewall table.
Source/Destination Address:	IP addresses to be checked for in the incoming IP traffic from the WAN.
Source/Destination Mask:	IP address masks to be used for checking the source and destination addresses.
Type:	Type of IP packet. TCP, UDP, or another user defined value.
Port 1:	Starting port of the range of ports to allow through the firewall.
Port n:	Ending port of the range of ports to allow through the firewall.
Alias:	Name used to indicate the type of entry in the port, either a manual entry or a name from the Designated Servers menu.

7 - Remove Entry

The Remove Entry option deletes individual entries or all of the entries from the Firewall table.

```
Enter :  
  all, index number (from 1 to 64)  
>
```

8 - Clear Statistics

The Clear Statistics option clears all of the firewall statistics.

Designated Servers Menu

DESIGNATED SERVERS MENU		
Option	Value	Description
1. E-mail (SMTP) server	[none]	- Specify E-Mail server IP address
2. POP 2/3 server	[none]	- Specify E-Mail POP server address
3. FTP server	[none]	- Specify FTP server IP address
4. WWW (HTTP) server	[none]	- Specify WWW server IP address
5. Telnet server	[none]	- Specify Telnet IP address
6. Local DNS	[none]	- Specify local DNS IP address
7. Remote DNS	[none]	- Specify remote DNS IP address
8. Gopher server	[none]	- Specify Gopher server IP address

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **DESIGNATED SERVERS MENU** contains options used to define the IP address of specific local network services that may be accessed by remote site network devices. Defining a Designated Server allows for simpler set up when configuring what traffic is to be allowed through the firewall.

1 - E-mail (SMTP) Server

The E-mail Server option defines the IP address of the local network E-mail (SMTP) Server that may be accessed by remote site network devices.

Default: [none]

2 - POP 2/3 Server

The POP Server option defines the IP address of the local network POP 2/3 Server that may be accessed by remote site network devices.

Default: [none]

3 - FTP Server

The FTP Server option defines the IP address of the local network FTP Server that may be accessed by remote site network devices.

Note: depending on the FTP software used, a client may not be able to reach an FTP server through a router using NAPT with firewall security enabled unless a port is opened for user authentication communications. This port may be set up in the Edit Firewall Entry Menu.

Default: [none]

4 - WWW (HTTP) Server

The WWW Server option defines the IP address of the local network WWW (HTTP) Server that may be accessed by remote site network devices.

Default: [none]

5 - Telnet Server

The Telnet Server option defines the IP address of the local network Telnet Server that may be accessed by remote site network devices.

Default: [none]

6 - Local DNS

The Local DNS option defines the IP address of the local network Domain Name Server (DNS) that may be accessed by remote site network devices. This entry allows access to the designated IP address only on port 53.

Default: [none]

7 - Remote DNS

The Remote DNS option defines the IP address of the remote network Domain Name Server (DNS) that may be accessed by local network devices. This setting would be used when connecting to an ISP for example and the DNS is located external to your network within the ISP. This entry allows access to the designated IP address on port 53 as well as on ports 1024 to 65535.

Default: [none]

8 - Gopher Server

The Gopher Server option defines the IP address of the local network Gopher Server that may be accessed by remote site network devices.

Default: [none]

Edit Firewall Entry Menu

```

                                EDIT FIREWALL ENTRY MENU

Option                          Value          Description
1. Dest IP address              [          ] - Incoming IP destination address
2. Destination mask             [          ] - Destination subnet mask
3. Source IP address           [          ] - Incoming IP source address
4. Source mask                  [          ] - Source subnet mask
5. Protocol type                [          ] - Allow specific protocol types
6. Initial port                 [          ] - First port to allow traffic in
7. Last port                    [          ] - Last port in range
8. Description                  [          ] - describe the entry

Enter :
      Firewall filter id (from 1 to 64)

> 1

```

The above display is the first level of the **EDIT FIREWALL ENTRY MENU**. Once the firewall entry index number is entered, the number specified is added to the menu title bar and the Options are as shown below:

```

                                EDIT FIREWALL ENTRY 1 MENU

Option                          Value          Description
1. Dest IP address              [none]         - Incoming IP destination address
2. Destination mask             [none]         - Destination subnet mask
3. Source IP address           [all]          - Incoming IP source address
4. Source mask                  [none]         - Source subnet mask
5. Protocol type                [TCP]          - Allow specific protocol types
6. Initial port                 [1]            - First port to allow traffic in
7. Last port                    [65535]        - Last port in range
8. Description                  [          ]   - describe the entry

Enter option number, "=" - main menu, <TAB> - previous menu

>

```

A Firewall entry allows the creation of a specific IP connection type of communication path to be allowed through the firewall. The Source IP address of a known remote site network may be defined to be allowed to access either a specific local device or the entire local network.

1 - Destination IP Address

The Destination IP Address option defines the IP address of a local device that may be accessed through the firewall for this entry. On all incoming frames from the WAN, this address will be the destination IP address.

The IP address consists of 4 eight-bit fields, each field is specified by a decimal number and the fields are separated by a decimal point (e.g. 92.3.1.10). Each decimal number must be less than or equal to 255(the maximum decimal value of an 8-bit binary number).

Default: [none]

2 - Destination Mask

The Destination Mask option defines the address mask to be used on the Destination IP Address defined in option 1 for this entry. To have the firewall entry apply to an individual IP address a mask of none should be used.

The address mask consists of 4 octets and is represented by 4 fields separated by periods (.), where each field is specified by a decimal number (e.g. 255.255.255.0). Each decimal number must be less than or equal to 255, that is the maximum value of each 8-bit field.

Default: [none]

3 - Source IP Address

The Source IP Address option defines the IP address of a remote site device or network that may be allowed access through the firewall for this entry. On all incoming frames from the WAN, this address will be the source IP address. By default, this option allows all remote site source IP addresses to access the local device specified. Specifying a specific remote site IP address for an individual device or a network allows for greater restrictions on incoming frames.

The IP address consists of 4 eight-bit fields, each field is specified by a decimal number and the fields are separated by a decimal point (e.g. 92.3.1.10). Each decimal number must be less than or equal to 255(the maximum decimal value of an 8-bit binary number).

Default: [all]

4 - Source Mask

The Source Mask option defines the address mask to be used on the Source IP Address defined in option 3 for this entry. To have the firewall entry apply to an individual IP address a mask of none should be used.

The address mask consists of 4 octets and is represented by 4 fields separated by periods (.), where each field is specified by a decimal number (e.g. 255.255.255.0). Each decimal number must be less than or equal to 255, that is the maximum value of each 8-bit field.

Default: [none]

5 - Protocol Type

The Protocol Type option defines the protocol type to allow through the firewall for this entry. The protocol type may be defined as TCP, UDP, or any other protocol type. Other protocols are defined as a valid IP protocol type in hex.

Default: [TCP]

Choices: TCP, UDP, (any protocol type number in hex)

6 - Initial Port

The Initial Port option defines the starting port number to be allowed through the firewall for this entry.

Default: [1]

Range: 1 to 65535

7 - Last Port

The Last Port option defines the last port number to be allowed through the firewall for this entry. Specifying a port number greater than the Initial Port number allows all of the port numbers within the range to be allowed.

Default: [1]

Range: 1 to 65535

8 - Description

This option allows a text description of up to 19 characters of this entry in the firewall table

NAT Exports Menu

NAT EXPORTS MENU		
Option	Value	Description
1. Edit Services	menu	- Add/remove exported services
2. Router port	menu	- Change router server ports for export
3. Show services		- Display exported services
4. Clear services		- Clear all exported services

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **NAT Exports Menu** has options for setting, clearing and reviewing exported Internet services available on this network. Using Network Address Translation (NAT). NAT maps arbitrary internal network IP addresses to valid global IP addresses used on the Internet. Network Address Port Translation (NAPT) allows a number of internal hosts to map to the same global IP address via port assignment to that address. NAT exported services are only available through port translation.

NOTE: Exported services from a remote site are only available if NAPT is enabled for that site (under the Configuration/WAN Set-up/Remote Site Set-up/Edit Remote Site/Protocol Set-up/IP Parameters menu).

1 - EDIT Services

The Edit Services option takes you to the Edit Services Menu, where the host devices for the various Internet services that will be offered on this network may be added to or removed from the export services table.

2 - Router Port

The Router Port option takes you to the Router Port Menu where the port number for services provided by this router may be assigned.

3 - Show Services

Displays a list if the Internet services available for export on this network.

4 - Clear Services

Clears the NAPT table of IP addresses of services available for export on this network.

Edit Services Menu

EDIT SERVICES MENU		
Option	Value	Description
1. Other Services	menu	- Add/remove other exported services
2. E-mail	[none]	- E-mail server's IP address
3. POP2/POP3	[none]	- POP2/POP3 server's IP address
4. FTP	[none]	- FTP server's IP address
5. WWW (HTTP)	[none]	- WWW (HTTP) server's IP address
6. Telnet	[none]	- Telnet server's IP address
7. DNS	[none]	- DNS server's IP address
8. Gopher	[none]	- Gopher server's IP address

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **EDIT SERVICES MENU** allows you to set the internal IP address of the device where each Internet service that will be available for export on this network can be accessed. The NAT port used for Network Address Port Translation for the services in options 2 through 8 will be the well known port number for that service.

When a service is added using this menu, it will also be automatically added to the firewall designated servers list, even if firewall is not enabled.

1 - Other Services

The Other Services option takes you to a menu where the internal IP address of an Internet service not offered in the list below may be set up.

2 - E-mail

The IP address of the E-mail server on this network may be set. (port 25)

3 - POP2/POP3

The IP address of the POP2/POP3 server on this network may be set. (POP2 - port 109, POP3 port 110)

4 - FTP

The IP address of the FTP server on this network may be set. (port 21, FTP data port 20)

Note: depending on the FTP software used, a client may not be able to reach an FTP server through a router using NAPT with firewall security enabled unless a port is opened for user authentication communications. See Main/Configuration/Applications/Firewall/ Edit Firewall Entry Menu..

5 - WWW (HTTP)

The IP address of the WWW (HTTP) server on this network may be set. (port 80)

6 - Telnet

The IP address of the Telnet server on this network may be set. (port 23)

7 - DNS

The IP address of the DNS server on this network may be set. (port 53)

8 - Gopher

The IP address of the Gopher server on this network may be set. (port 70)

Other Services Menu

OTHER SERVICES MENU		
Option	Value	Description
1. NAT port	*[]	- Port number exported by NAT
2. Status	*[]	- Is service in export's table?
3. Host IP address	[]	- Enter location of service
4. Host port	[]	- Enter port number of service on host
5. Description	[]	- Describe the service
6. Remove		- Remove the service

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **OTHER SERVICES MENU** allows the set up of an Internet service not listed in the Edit Services menu.

1 - NAT Port

This option displays the port number that NAT will use to export this service

Range: 1 to 65535

2 - Status

This option displays whether or not this port has an IP address present in the export table and is being used by another service. If the port is already present in the table, the host address and port will be displayed and may be changed.; the NAT Port and Status for this entry may not be changed if already present you must return to the previous menu, re-enter this one and use another port number.

Default: [not present]

3 - Host IP Address

Enter the internal IP address of the host for this service.

Default: [0.0.0.0]

4 - Host Port

Enter the internal port number of the host for this service.

Default: [port number entered for NAT Port]

Range: 1 to 65535

5 - Description

Enter a description of the service.

Range: up to 20 characters

6 - Remove

Remove this service from the export table. The service must be present in the export table before this option will be displayed.

Router Port Menu

ROUTER PORT MENU		
Option	Value	Description
1. Telnet	[default]	- Change telnet server ports for export
2. TFTP	[default]	- Change TFTP server ports for export
3. SNMP	[default]	- Change SNMP server ports for export

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **EDIT ROUTER SERVICES MENU** contains options to set alternate port numbers to export the Telnet, TFTP and SNMP services of this router. If one of these services is offered on another server through NAT, then that server will use the well known port number for that service; this router must use a different port number for its service.

1 - Telnet

The Telnet option defines a port number to use for Telnet services on this router.

2 - TFTP

The TFTP option defines a port number to use for TFTP services on this router.

3 - SNMP

The SNMP option defines a port number to use for SNMP services on this router.

SYSLOG Set-Up Menu

SYSLOG SET-UP MENU		
Option	Value	Description
1. Syslog	[enabled]	- Enable/disable syslog logging
2. Syslog IP address	[none]	- Define host IP address
3. Events facility	[none]	- Define network events facility
4. Security facility	[none]	- Define security facility
5. Activation facility	[local2]	- Define activation facility

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **SYSLOG Set-Up Menu** configures this IOLINK SOHO to send messages to a standard Syslog service running on a specified host. Syslog is a utility, typically on a UNIX type system but also available for other systems, that forwards system messages to a user selected destination, known as a facility. A facility may be a file, another device, such as a printer, or another utility, such as an e-mail service. A listing of available facilities is given at the end of this section. It is recommended that you choose the `localn` facilities for logging messages from this router unless you are certain that a specified facility is not used by any other part of the system.

For a listing of system messages and their descriptions, please see Appendix A of the IOLINK SOHO Reference Manual file on the accompanying disk. For information on Syslog, please see your UNIX (or equivalent) operating system reference manual.

This router will generate one of three classes of message: events, security, or activation. Each type may be sent to a separate facility. All messages are sent at severity level 6 (information level).

Note: if Syslog is set up to send messages to a host across a WAN link and spoofing or traffic initiated connection is enabled, the link will be brought up every time a system event occurs, i.e. very frequently. Depending on how link service charges are accrued, this may not be desirable. It is recommended that the Syslog host be on the same LAN as this router.

Note: Time of day should be synchronized between this IOLINK SOHO and the Syslog daemon host; if this is not done, interpreting a sequence of logged events becomes more difficult.

1 Syslog

The Syslog option toggles the Syslog operation between enabled and disabled.

Default: [disabled]

2 Syslog IP address

Enter the IP address of the Syslog host to which the system messages are to be forwarded for logging.

3 Events Facility

A network event message generated by this router will be forwarded to the selected facility for logging on the Syslog host.

Default: [none]

Choices: (see below for details)

none, local0, local1, local2, local3, local4, local5, local6, local7,
auth, cron, daemon, kern, lpr, mail, news, syslog, user, uucp

4 Security Facility

A security message generated by this router will be forwarded to the selected facility for logging on the Syslog host.

Default: [none]

Choices: (see below for details)

none, local0, local1, local2, local3, local4, local5, local6, local7,
auth, cron, daemon, kern, lpr, mail, news, syslog, user, uucp

5 Activation Facility

An activation message generated by this router will be forwarded to the selected facility for logging on the Syslog host.

Default: [none]

Choices:

none, local0, local1, local2, local3, local4, local5, local6, local7,
auth, cron, daemon, kern, lpr, mail, news, syslog, user, uucp

Facilities available on Syslog:

none	Message will not be sent
local0-7	Reserved for user defined service recommended choice.
user	Messages generated by user processes.
kern	Messages generated by the kernel.
mail	The mail system.
daemon	System daemons, such as ftpd(1M), routed(1M), etc.
auth	The authorization system: login(1), su(1M), getty(1M), etc.
syslog	Syslog daemon

Menus Reference Manual: SYSLOG Set-Up Menu

lpr	The line printer spooling system: lpr(1), lpc(1M), lpd(1M), etc.
news	Reserved for the USENET network news system.
uucp	Reserved for the UUCP system.
cron	The cron/at facility; crontab(1), at(1), cron(1M), etc.

WAN Set-Up Menu

WAN SET-UP MENU		
Option	Value	Description
1. Switch type	[NI-1]	- Set switch type
2. Group set-up	menu	- Configure group operation
3. Link set-up	menu	- Configure link parameters
4. Remote site set-up	menu	- Configure remote site access
5. Security set-up	menu	- Configure security
6. PPP set-up	menu	- Configure PPP parameters
7. IP address connect	menu	- Configure IP address connect
8. Force disconnect		- Disconnect a link
9. Link summary		- Summary statistics of all links

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **WAN SET-UP MENU** allows the definition of link operation for the router.

1 - Switch Type

Choosing the Switch Type option defines the ISDN switch (signaling) type that this router is connected to.

When the Switch Type is changed, a **Soft Reset** must be performed for this to take effect. This allows the router to initiate operation with the new switch type.

Default: if S/T module installed: [NET3]
If U module installed: [NI-1]

Choices: DMS-100, NI-1, NI-2, 5ESS-PP, 5ESS-MP, NET3, TPH1962, KDD, SWEDEN, and NTT

Considerations:

The 5ESS switch types are split into two versions: 5ESS-PP (point to point) and 5ESS-MP (multipoint). In ISDN, point to point means that both B channel links in an ISDN BRI are used for a connection between two devices. Multipoint means that one link of the BRI may be used to connect to one device, the other link may be used to connect to a different device.

2 - Group set-up

The group Set-up option takes you to the Group Set-up Menu, where ISDN hunt group parameters may be configured.

Note: this menu item appears only if the switch type is not NET3.

3 - Link Set-Up

The Link Set-up option takes you to the Link Set-Up Menu, where the link interfaces are configured. Directory numbers and Service Profile Identifiers are defined for the ISDN B-channels.

4 - Remote Site Set-Up

The Remote Site Set-up option takes you to the Remote Site Set-Up Menu, where configuration parameters required to establish PPP connections to remote devices are maintained.

5 - Security Set-Up

The Security Set-up option takes you to the Security Set-Up Menu, where PPP security options are maintained.

6 - PPP Set-Up

The PPP Set-up option takes you to the PPP Set-Up Menu, where general PPP options are maintained.

7 - IP Address Connect

The IP Address Connect Menu allows you to define PPP remote sites to be called depending upon the destination IP address of IP traffic on the local LAN.

8 - Force disconnect

Disconnects the link specified.

9 - Link summary

Displays a summary of the links available on this device, their connections and a brief set of statistics.

The time period for the statistics sampling interval may be set in the Statistics Set-Up Menu. The default sampling period is 60 seconds.

Link Summary					
Link ID	Link Type/State	Remote Site Alias	Throughput Kbps (Rcv/Xmt)	% (Rcv/Xmt)	Frame Errors
1	ISDN/Up	REM1	48.4/55.0	75/86	10
2	ISDN/Down	none	0.0/0.0	0/0	0

Link ID the identification number associated with the link interface module; the same as the physical slot number in which the module is installed.

Link Type the type of interface module for the link
Types: ISDN, Digital Leased

Link State whether the link is up or down

Remote Site Alias the name assigned to the remote site associated with the link.

Throughput the transmit and receive speeds in kilobytes per second over the link.

% - the actual transmit and receive speeds as a percentage of specified link speed.

Frame Errors a count of frame errors over the link.

Group Set-Up Menu

```
GROUP SET-UP MENU

Option                Value                Description
1. Force 56k          [disabled]          - Force 56k rate adaptation
2. Hunt group #       [none]              - Set common telephone number
3. Add link           - Add a specific link to this group
4. Show groups

Enter:
  group number (1 or 2)

> 1
```

The above display is the first level of the **GROUP SET-UP MENU**. Once the group number is entered, the group number specified is added to the menu title bar and the Options are as shown below:

```
GROUP SET-UP 1 MENU

Option                Value                Description
1. Force 56k          [disabled]          - Force 56k rate adaptation
2. Hunt group #       [none]              - Set common telephone number
3. Add link           - Add a specific link to this group
4. Show groups

Enter:

>
```

The **GROUP SETUP MENU** provides for grouping sets of ISDN B-channels together. These sets may be hunt groups or callback groups.

A hunt group phone number is defined by the ISDN service provider. This method of grouping the B-channels allows one ISDN phone number to be used to establish connections from remote site devices to multiple B-channels on the central site device. A group of single link protocol remote site devices may all dial in to the same ISDN phone number at the central site and contend for a link connection. This greatly simplifies the configuration process.

By default, all B-channel links are initially configured to be in group 1. Group 1 is defined with multilink operation disabled.

Consideration: If this IOLINK SOHO is configured with remote site callback enabled, (this router will place a return call when it receives a prompting call from a remote site), then a callback group should be set up. A callback group is a grouping of one (the primary ISDN call number) or two (primary and alternate) ISDN numbers that a remote site router may dial to trigger the callback from this IOLINK SOHO.

Note: this menu will only be displayed if this router has a dual link ISDN BRI module installed and the switch type is not NET3.

Menus Reference Manual: Group Set-Up Menu

1 - Force 56K

This option forces the B-channels in this group to use V.110 rate adaptation for all incoming and outgoing calls.

If the path to a destination number passes through a 56 Kbps digital circuit or the destination itself is a 56 K switched digital service, V.110 rate adaptation must be performed to allow the data to be sent at 56 K on the 64 K ISDN lines. When an ISDN call is placed, the local ISDN service must be informed that V.110 rate adaptation is required to fully complete this connection. Adding a percent symbol % before the ISDN number will cause the IOLINK SOHO to send a message to the local ISDN service requesting V.110 rate adaptation.

Note: The link must be disconnected for this operation to take effect.

Default: [disabled]

2 - Hunt Group

Enter the Hunt Group ISDN phone number assigned to this group of B-channels by the ISDN circuit provider. This Hunt Group number is used by this IOLINK SOHO to inform the remote site partner devices which ISDN number to call when performing a suspend or resume of a connection managed circuit. This means that the remote site device will call the Hunt Group number when attempting to re-establish the ISDN call.

Note: Hunt Groups are a service from ISDN service providers and must be requested from them. If you have not subscribed for Hunt Group service, select none as the entry for this option. If a Hunt Group number is not defined, the ISDN number of the B-channel used to establish the call will be used for connection management negotiations.

When adding entries to the Stored Number table on remote partner ISDN IOLINK SOHO bridge/routers, this Hunt Group Number should be entered in the ISDN Number section in the table on the remote IOLINK SOHO.

Default: [none]

```
Enter :  
    none, Directory number (up to 35 characters)  
>
```

3 - Add Link

Use this option to add a B-channel link to this group. Each link must always belong to only one group, so adding a link to a group will remove it from the previous group.

```
Enter :  
    link number (1 or 2)  
> 1
```

Menus Reference Manual: Group Set-Up Menu

4 - Show Groups

Choosing this option displays an overview of the group configurations.

Groups Configuration				
Group #	Force 56K	Directory number	Links	
1		9876543	1	*
2	Y	12345678	*	

Link Set-Up Menu

```
                                LINK SET-UP MENU

Option                          Value          Description
1. Physical link type  * [          ]

Enter:
  link number (1 or 2)

> 1
```

The above display is the first level of the **LINK SET-UP MENU**. Once the WAN link number is entered, the link number specified is added to the menu title bar and one of the menus shown on the following pages will appear. The menu shown will vary depending on whether the logical ISDN type selected is ISDN or Digital Leased.

Link Set-Up Menu

If the Logical ISDN type is **ISDN**, the menu will be:

LINK SET-UP 1 MENU		
Option	Value	Description
1. Physical link type	* "BRI"	
2. Link operation	[enabled]	- Enable/disable link
3. Logical ISDN type	[ISDN]	
4. ISDN set-up menu	menu	- Configure ISDN operation
5. Group	[1]	

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **LINK SET-UP MENU** allows the configuration the link connections on this IOLINK SOHO. The options displayed for this menu will vary depending on what interface modules are installed on this router.

1 - Physical link type

The Physical Link Type option displays the type of interface module installed for this link. This is a display-only item and may not be changed.

Values: BRI

2 - Link Operation

The Link Operation option toggles between [enabled] and [disabled] to allow this link to be used for connections.

Default: [enabled]

3 - Logical ISDN Type

The Logical ISDN Type option allows you to select between a switched (dial up) ISDN circuit or a digital leased circuit to configure the router to match the type of service connected to this interface module.

The ISDN option is used when a switched (dial up) ISDN service is connected to the BRI module.

The Digital_Leased option is used when a permanent leased ISDN circuit is available from your ISDN service provider and is connected to the BRI module; please see the Link Set-up menu on following pages for a description of this option.

When this link is set to use digital leased circuits instead of switching circuits, the ISDN call establishing functions are not displayed on the menu.

Default: [ISDN]

Values: ISDN, Digital_Leased

Considerations:

The state of the Logical ISDN type option is saved when performing a software upgrade. This means that when the IOLINK SOHO restarts, it will return to the operation state that was enabled before the upgrade was performed.

4 - ISDN Set-Up

The ISDN Set-Up option takes you to the ISDN Set-up menu where ISDN switch types and other ISDN parameters may be set.

Note: this option appears only if the router has an ISDN BRI module installed on this link and Logical ISDN Type is set to ISDN.

5 - Group

The identifying number (from 1 or 2) of the Group to which this link is to belong is set here.

Default: [1]

Choices: 1 or 2

Note: Groups may also be set under the Group Set-up Menu. Links set in that menu need not be set here.

Note: this option appears only if the Logical ISDN Type is set to ISDN.

Link Set-Up Menu

If the Logical ISDN type is **Digital_Leased**, the menu will be:

LINK SET-UP 1 MENU		
Option	Value	Description
1. Physical link type	*"BRI"	
2. Link operation	[enabled]	- Enable/disable link
3. Logical ISDN type	[Digital_Leased]	
4. Phantom power detect	[disabled]	- Detect phantom power
5. Link B channel	[B1]	- Assign B channel

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **LINK SET-UP MENU** allows the configuration the link connections on this IOLINK SOHO. The options displayed for this menu will vary depending on what interface modules are installed on this router.

1 - Physical link type

The Physical Link Type option displays the type of interface module installed for this link. This is a display-only item and may not be changed.

Values: BRI

2 - Link Operation

The Link Operation option toggles between [enabled] and [disabled] to allow this link to be used for connections.

Default: [enabled]

3 - Logical ISDN Type (if BRI module installed on this link)

The Logical ISDN Type option allows you to select between a switched (dial up) ISDN circuit or a digital leased circuit to configure the router to match the type of service connected to this interface module.

The ISDN option is used when a switched (dial up) ISDN service is connected to the BRI module; please see previous Link Set-up Menu for a description of this option.

The Digital_Leased option is used when a permanent leased ISDN circuit is available from your ISDN service provider and is connected to the BRI module. A digital leased circuit is permanently established by your service provider and does not require ISDN phone numbers or dialing functionality. When a digital leased circuit is established, the IOLINK SOHO will treat it as if it were a normal 64 Kbps leased line connection for each assigned B-channel.

When this link is set to use digital leased circuits instead of switching circuits, the ISDN call establishing functions are not displayed on the menu.

Default: [ISDN]

Values: ISDN, Digital_Leased

Considerations:

The state of the Logical ISDN type option is saved when performing a software upgrade. This means that when the IOLINK SOHO restarts, it will return to the operation state that was enabled before the upgrade was performed.

4 - Phantom Power Detect

Most NT-1s provide a signal to the connected ISDN device to indicate that the NT-1 is powered up and functioning correctly. This signal is generally called phantom power. Some NT-1s do not support phantom power. This option should be disabled if the NT-1 connected to the ISDN link module does not support phantom power.

If the IOLINK SOHO is having difficulty obtaining a connection to the NT-1, this option should be disabled.

Default: [disabled]

Considerations:

This option is not available when the link module in an ISDN type U interface.

5 - Link B Channel

When the digital leased circuit option is enabled for the ISDN interface on this IOLINK SOHO, the ISDN B-channels must be assigned to link numbers for normal operation. When a B-channel is assigned to a link number, the IOLINK SOHO then treats the ISDN B-channel as a 64 Kbps leased line connection.

Link 1 may be assigned B-channel 1, B-channel 2 or both.

If link 1 is assigned B-channel 1, the other channel is available to service link 2 on the ISDN module; if link 1 is assigned B-channel 2, the other channel is not available.

This option is available only when the Digital Leased Circuit option is enabled.

```
Enter :  
    B1, B2, B1-B2  
>
```

If B-channel 2 has not previously been assigned to link 1 on this ISDN module, link 2 may be assigned B-channel 2 or none.

If link 2 is assigned none, it is not available for user data connection.

This option is available only when the Digital Leased Circuit option is enabled.

```
Enter :  
    B2, none  
>
```

Considerations:

If B-channel 2 is already claimed by link 1 and you wish to reassign it to link 2, you must first reassign B1 to link 1 (select B1); otherwise, the following error display will appear:

Menus Reference Manual: Link Set-Up Menu

Error: B2 is currently allocated to first link, Enter :
none, B2

ISDN Set-Up Menu

ISDN SET-UP MENU		
Option	Value	Description
1. Dial prefix	[none]	- Set dial prefix
2. Phantom power detect	[disabled]	- Detect phantom power
3. Force 56k	[disabled]	- Force 56k rate adaptation
4. Directory number	[none]	- Set directory number
5. SPID	[none]	- Link service profile identifier

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **ISDN SET-UP MENU** provides for stored ISDN number set-up.

Note: this menu appears only if this router has an ISDN module installed.

1 - Dial Prefix

The Dial Prefix option is used when the ISDN IOLINK SOHO is attached to an ISDN PBX. If a dialing prefix is required before an outside line is obtained, the dialing prefix must be entered here.

Default: [none]

Considerations:

This option is not available when the Digital Leased Circuit option is set to enabled.

2 - Phantom Power Detect

Most NT-1s provide a signal to the connected ISDN device to indicate that the NT-1 is powered up and functioning correctly. This signal is generally called phantom power. Some NT-1s do not support phantom power. This option should be disabled if the NT-1 connected to the ISDN link module does not support phantom power.

If the IOLINK SOHO is having difficulty obtaining a connection to the NT-1, this option should be disabled.

Default: [disabled]

Considerations:

This option is not available when the link module in an ISDN type U interface.

3 - Force 56K

This option forces both B-channels on this IOLINK SOHO router to use V.110 rate adaption for incoming and outgoing calls.

If the path to a destination number passes through a 56 Kbps digital circuit or the destination itself is a 56 K switched digital service, V.110 rate adaption must be performed to allow the data to be sent at 56 K on the 64 K ISDN lines. When an ISDN call is placed, the local ISDN service must be informed that V.110 rate adaption is required to fully complete this connection. Adding a percent symbol % in the ISDN number will cause the IOLINK SOHO to send a message to the local ISDN service requesting V.110 rate adaption.

Default: [disabled]

4 - Directory Number

Enter the ISDN number of the B-channel (up to 15 characters). The ISDN number is available from the ISDN circuit provider. For a type NI-1 switch, enter only the local portion of the directory number, unless the area code is required for local calls.

When the Directory Number is changed, a **Soft Reset** must be performed for this to take effect. The router will be reset and begin operation with the new directory number.

Default: [none]

Note: this option appears only if the router has an ISDN module installed and the Digital Leased Circuit option is set to disabled.

The following option appears when an ISDN type U interface is installed and the Digital Leased Circuit option is set to **disabled**:

5 - SPID

Enter the ISDN Service Profile Identifier (SPID) number assigned to this B-channel. The SPID number is available from the ISDN circuit provider.

When the SPID is changed, a **Soft Reset** must be performed for this to take effect. The router will be reset and begin operation with the new SPID.

Remote Site Set-Up Menu

REMOTE SITE SET-UP MENU		
Option	Value	Description
1. Edit remote site	menu	- Modify/add a remote site entry
2. Remote site summary		- Summary of remote sites
3. Call summary		- Call summary of remote sites
4. Remove remote site		- Delete remote site entry
5. Manual call		- Make a manual call to a remote site
6. Force disconnect		- Disconnect a call to a remote site

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **REMOTE SITE SET-UP MENU** allows the display, configuration, and creation of remote site profiles. Remote site profiles are used to establish PPP connections to other PPP routers. The appearance of this menu will vary depending on the interface modules installed and their configuration.

Important: When configuring this IOLINK SOHO to be the originator of PPP ISDN calls or leased line connections, always define a remote site for each of the possible remote partner routers that this IOLINK SOHO may connect to. Each of the remote sites created stores all of the configuration information required to properly maintain the PPP connection to that remote PPP router. The remote site alias is used to match against the incoming user name during authentication. If an authenticated user name is the same as one of the configured remote site profiles, that connection will use the configuration defined within the remote site profile.

The configuration parameters for a remote site profile may be set by using another profile as a template. Two remote site table entries have been reserved for ISDN and leased line site profile templates; these are:

<u>ID number</u>	<u>remote site name</u>
41	ISDN_TEMPLATE
42	LEASED_TEMPLATE

Parameters for these profiles may be set under the `Edit Remote Site` menu option. If a number of remote sites will have a similar profiles, copying the remote site profile from a template can save considerable time in setting them up.

If this router has an ISDN BRI interface and it is set for Digital Leased Circuit, the ISDN B-channel will be treated as a leased line connection.

When the IOLINK SOHO receives an incoming ISDN call, the Multilink state is taken from the `ISDN_TEMPLATE` remote site profile. After the authentication process is finished, if the remote site is a valid remote site that has already been configured, the remaining call parameters are taken from the configured remote site profile. If the remote site does not match one of the configured remote site profiles, then the remaining call parameters will be taken from the `ISDN_TEMPLATE` remote site profile and a remote site profile for that link will be dynamically created at the next available remote site ID number. The newly created remote site profile will be named `INCOMING n` where `n` is the next unassigned Initial Profile number.

When CallerID security is enabled, an incoming call will not be accepted if the remote site does not match one of the configured remote site profiles.

When displaying status or statistic information on the connections to a remote site PPP router, most of the information is displayed according to a particular remote site. Within the Statistics section, a remote site is chosen and then the information for that connection may be displayed. The name of the remote site that the connection has been attached to may be viewed in the Event log file available within the Network Events menu.

Menus Reference Manual: Remote Site Set-Up Menu

There are 40 configurable remote sites available. Each of these remote sites will have a remote site alias associated with them. When a connection is made to a particular remote site, the call will be attached to that remote site profile after the connection has been established. Statistics for a connection are stored under the remote site profile alias or ID number.

Two remote site profiles, numbered 41 and 42, are reserved as templates that may be used for faster remote site configuration.

<u>Remote Site ID</u>	<u>Remote Site Alias</u>	<u>Description</u>
------------------------------	---------------------------------	---------------------------

1 - 40	(user configurable)	Remote site used for outgoing connections to these specific remote sites. Configuration parameters for the outgoing connection are taken completely from the parameters defined in the remote site profile.
--------	---------------------	---

Remote site profile used for incoming connections that have been authenticated and the incoming user name matches the name of one of the configured remote sites.

41	ISDN_TEMPLATE	Remote site profile used to set up a template that may be used to configure remote sites with ISDN connections. Multilink state is taken from this profile. If the incoming user name matches the name of one of the configured remote sites, the remaining call parameters will be negotiated from the values defined for that remote site.
----	---------------	--

If the incoming user name does not match any of the remote sites defined, the connection is attached to the INCOMING profile for that link (44 or 45). The remaining negotiating parameters, such as BCP, IPCP, IPXCP, and CCP, will be taken from the ISDN_TEMPLATE settings.

42	LEASED_TEMPLATE	Remote site profile used to set up a template that may be used to configure remote sites with Leased Line connections.
----	-----------------	--

For incoming connections, a remote site profile is auto-created at the first available location in the remote site table.

Menus Reference Manual: Remote Site Set-Up Menu

1 - Edit Remote Site

The Edit Remote Site option directs you to the Edit Remote Site Menu where the remote site profiles are maintained.

40 remote sites may be defined.

2 - Remote site summary

The Display Summary option displays an overview of the remote site profiles configured on this IOLINK SOHO. Each of the options is shown as "E" for enabled, "D" for disabled or "NA" for not available.

		Total Remote Site Entries: 7										
		* - Up @ - Suspended										
		E - Enabled D - Disabled NA - Not Available										
Id	Alias	FR	AC	MP	Pri/Sec	DLCI	BRG	IP	IPX	CCP	CMCP	BACP
1	LEASED1	NA	D	E	Link02/none	NA	E	E	E	E	NA	NA
2	Toronto	NA	D	E	ISDN/none	NA	E	E	E	E	D	NA
3	LEASED2	NA	D	E	Link02/ISDN	NA	E	E	E	E	NA	D
4	Dallas	NA	D	E	ISDN/ISDN	NA	E	E	E	E	D	E
41	ISDN_TEMPLATE	NA	D	E	ISDN/ISDN	NA	E	E	E	E	D	D
42	LEASED_TEMPLATE	NA	D	E	none/none	NA	E	E	E	E	NA	D

Id: Entry number in the Remote Site table. The Index number may be used to reference this entry in the IP Address Connect table or for viewing statistics.

Alias: Text name used to easily reference this entry in the table. The Alias may be used to reference this entry in the IP Address Connect table or for viewing statistics.

FR: Frame Relay This column displays not applicable (NA) in a non-frame relay environment.

AC: The state of the Auto-call option for this remote site profile.

MP: The state of the Multilink option for this remote site profile.

Pri/Sec: The type of primary and secondary links configured for this remote site profile. ISDN/none indicates that the circuit will only use ISDN calls. Link1 or Link2 entries indicates that the circuit has been defined as a digital leased circuit.

DLCI: The Frame Relay DLCI number of this remote site. Not applicable (NA) in a non-frame relay environment.

BRG: The state of the BCP (bridging) option for this remote site profile.

IP: The state of the IPCP (IP routing) option for this remote site profile.

IPX: The state of the IPXCP (IPX routing) option for this remote site profile.

CCP: The state of the CCP (compression) option for this remote site profile.

CMCP: The state of the CMCP (connection management) option for this remote site profile. Not applicable (NA) if the remote site is not an ISDN site.

BACP: The state of the BACP option for this remote site profile.

3 - Call Summary

The Display Call Summary option displays the ISDN call parameters for the Remote Site Table

* - Up		@ - Suspended		Total Call Site Entries: 0	
Id	Alias	ISDN Numbers	Wildcard	Callback Enabled	Group
1	NEW YORK	1-234-5678	543210	No	1
2	LOS ANGELES	9-876-543-2100 9-876-543-2101	none	No	2
3	test3	246-8101	none	No	1

Note: This option will only appear if an ISDN BRI interface module is installed which does not have the digital leased line option enabled.

4 - Remove Remote Site

The Remove Remote Site option deletes individual entries or all of the entries from the Remote Site table.

```
Enter:
  all, id or alias to delete
>
```

5 - Manual Call

The Manual Call option is used to establish a manual PPP call to a configured remote site.

```
Enter :
  remote site id or alias to dial (1 to 16 characters)
>
```

Note: This option will only appear if an ISDN BRI interface module is installed which does not have the digital leased line option enabled.

6 - Force Disconnect

The Force Disconnect option will cause the chosen remote site ISDN connection to be disconnected.

```
Enter :
  remote site id or alias to disconnect
>
```

Edit Remote Site Menu

EDIT REMOTE SITE MENU		
Option	Value	Description
1. Connection set-up	menu	- Configure connections
2. Protocol set-up	menu	- Configure protocols
3. Remote site alias	*[]	- Alias of remote site entry
4. Connection	*[]	- Select connection configuration
5. Primary connection	*[]	- Select connection type
6. Remote site type	*[]	- Interoperable or spoofing

Enter:
Remote site id or alias (1 to 16 characters)
>

The above display is the first level of the **EDIT REMOTE SITE MENU**. Enter the ID number or alias of the site you wish to edit.

Note: the options on this menu are not active until the Remote Site ID is entered.

When creating a new remote site profile, an alias must be entered for the new site. The first available identifier number will be assigned to this alias. The alias may be up to 16 characters long; blank spaces and the character **!** may not be used and the alias must start with a letter of the alphabet. You will then be prompted to enter a Template id number or profile; if this remote site will have a profile similar to an existing site, entering the alias or id number of that site will copy that remote site profile to this one. If you wish to start from the default settings, enter **none** (case sensitive).

After the remote site id or alias is supplied, the next level menu specific to that site appears

EDIT REMOTE SITE MENU		
Option	Value	Description
1. Connection set-up	menu	- Configure connections
2. Activation set-up	menu	- Configure remote site activation
3. Protocol set-up	menu	- Configure protocols
4. Security parameters	menu	- Configure security parameters
5. Remote site alias	"LEASED1"	- Alias of remote site entry
6. Connection	[dual_link]	- Select connection configuration
7. Primary connection	[Leased]	- Select connection type
8. <i>Secondary connection</i>	[Leased]	- <i>Select connection type</i>
9. Remote site type	*[interoperable]	- Interoperable or spoofing

Enter option number, "=" - main menu, <TAB> - previous menu

>

1 - Connection Set-Up

The Connection Set-up option takes you to the Connection Set-Up Menu for the chosen remote site. Here you define the connection parameters that will be used to establish the connection to the remote site device.

2 - Activation Set-Up

The Activation Set-up option takes you to the Activation Set-up menu for the chosen remote site, where activation conditions are defined for the main connection to this remote site. The activation conditions for the primary connection consist of the activation schedule, which determines when the connection may be operational, the usage limits and the load thresholds at which the link will be brought up or down.

The Activation conditions are not applicable when placing a manual call to this remote site.

3 - Protocol Set-Up

The Protocol Set-up option takes you to the Protocol Set-up menu for the chosen remote site, where the BCP, IPCP, IPXCP, CCP, CMCP and BACP protocol parameters are configured.

4 - Security Parameters

The Security Parameters option allows you to set the password that this remote site will use for incoming security authorization and to set a user name and password for outgoing security authorization.

Note: Routers configured to have a leased line link operating in conjunction with an ISDN B-Channel (either as backup or bundled link) must have security enabled and with the proper usernames and passwords entered on both partner routers.

5- Remote Site Alias

The Remote Site Alias option defines the name used to represent this remote site. The remote site alias is used to match against the incoming user name during authentication. If an authenticated user name is the same as one of the configured remote site profiles, that ISDN call will use the configuration defined within the corresponding remote site profile.

The remote site alias is case sensitive and may consist of 1 to 16 alphanumeric characters. Use the underscore character instead of a space character.

6 Connection

The Connections option defines the type of connection and its usage.

Options: `single_link`, `dual_link`, `threshold`, `recovery`, `threshold_with_recovery`.

Single link operation: only one link (the primary link) will be used for connection to this remote site.

Dual link operation: Two links will be available for connection to this remote site; both will be brought up any time a connection to this site is established.

Threshold: traffic levels on the primary link will be used to determine whether or not to bring up the secondary link. The conditions controlling the secondary link are set under the Activation menu.

Recovery: The secondary link will be used as a backup connection in case of failure of the primary link. The conditions controlling the secondary link are set under the Activation menu.

Threshold with recovery: the secondary link will be brought up if traffic on the primary link exceeds a threshold level or if the primary link fails. The conditions controlling the secondary link are set under the Activation menu.

Considerations: The `threshold with recovery` option is not compatible with partner routers that are configured to have only `threshold` or only `recovery` available on the link. If a connection of this type is attempted, the link will bob when the connection criteria are met for one router but not for the other. For example, if one is set for `threshold_with_recovery` and the other is set only for `recovery`, when the threshold is exceeded the router with `threshold_with_recovery` will attempt to bring up the connection, but because the partner router is not set for threshold activation, the partner router will bring the connection down.

7 Primary connection

The Primary connection option defines what type of service will be used on the primary connection. If the currently selected primary link is not configured for the chosen connection type, a warning is displayed: the connection will not be established if the link is not configured for the chosen connection type.

Options: `Leased`, `ISDN_call`

8 Secondary Connection

The Secondary connection option defines what type of service will be used on the secondary connection. If the currently selected secondary link is not configured correctly for the chosen connection type, a warning is displayed. The primary connection will still be established even if the secondary connection is not correctly configured.

Options: Leased, ISDN_call

Note: this option is user configurable only if the connection is not single link. If the connection is single link, the option becomes display only with * [none] displayed.

9 - Remote Site Type

The Remote Site Type option defines whether spoofing is enabled or not with this remote site connection.

Options: interoperable, spoofing

Considerations: If you are running spoofing with Triggered RIP, both routers must be set to Triggered RIP link_up_only . The IOLINK SOHO will automatically configure to this setting but the remote partner router should be checked to make certain that it is correctly configured.

Menus Reference Manual: Edit Remote Site - Connection Set-Up Menu

Connection Set-Up Menu

The appearance of the Remote Site Connection Set-Up Menu will vary depending on the options selected for the WAN connection to this remote site.

A Link logical type set to ISDN, single or multiple links.

EDIT REMOTE SITE n CONNECTION SET-UP MENU		
Option	Value	Description
1. ISDN call set-up	menu	- Configure ISDN calls
2. Auto-call	[disabled]	- Activate auto-call

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **REMOTE SITE CIRCUIT SET-UP MENU** allows the setting of parameters used for connection establishment to the remote site PPP router.

1 - ISDN Call Set-Up

The ISDN Call Set-up option takes you to the ISDN Call Set-Up Menu for the chosen remote site. Here you set parameters such as the ISDN numbers of the remote partner ISDN routers and redial timers that pertain to ISDN circuit activation. This option is not available when the ISDN interface on this IOLINK SOHO has been set as a Digital Leased Circuit.

2 - Auto-Call

The Auto-Call option is used to define this remote site as one that the IOLINK SOHO will attempt to establish a connection to at all times. Each time the IOLINK SOHO is powered up a connection will be attempted to this remote site.

Default: [disabled]

B - Link logical type set to Digital Leased, single link connection.

EDIT REMOTE SITE n CONNECTION SET-UP MENU		
Option	Value	Description
1. Primary link	[none]	- Configure primary link number
2. Auto-call	[disabled]	- Activate auto-call

Enter :
none, link_number (from 1 or 2)
>

1 Primary link

The Primary link option defines the link number that will be used to connect to this remote site.

Options: 1, 2, none

Default: [none]

2 - Auto-Call

The Auto-Call option is used to define this remote site as one that the IOLINK SOHO will attempt to establish a connection to at all times. Each time the IOLINK SOHO is powered up a connection will be attempted to this remote site.

Default: [disabled]

C - Link logical type set to Digital Leased, multiple link connection.

EDIT REMOTE SITE n CONNECTION SET-UP MENU		
Option	Value	Description
1. Primary link	[1]	- Configure primary link number
2. Secondary link	[2]	- Configure secondary link number
3. Auto-call	[disabled]	- Activate auto-call

Enter :
 none, link_number (1 or 2)
>

1 Primary link

The Primary link option defines the primary link number that will be used to connect to this remote site.

Options: 1, 2, none

Default: [none]

2 Secondary link

The Secondary link option defines the secondary link number that will be used to connect to this remote site.

Options: 1, 2, none

Default: [none]

3 - Auto-Call

The Auto-Call option is used to define this remote site as one that the IOLINK SOHO will attempt to establish a connection to at all times. Each time the IOLINK SOHO is powered up a connection will be attempted to this remote site.

Default: [disabled]

D Multiple link connection, primary link set to Leased, secondary link to ISDN.

EDIT REMOTE SITE n CONNECTION SET-UP MENU		
Option	Value	Description
1. ISDN call set-up	menu	- Configure ISDN calls
2. Primary link	[none]	- Configure primary link number
3. Auto-call	[disabled]	- Activate auto-call

Enter option number, "=" - main menu, <TAB> - previous menu

>

1 - ISDN Call Set-Up

The ISDN Call Set-up option takes you to the ISDN Call Set-Up Menu for the chosen remote site. Here you set parameters such as the ISDN numbers of the remote partner ISDN routers and redial timers that pertain to ISDN circuit activation. This option is not available when the ISDN interface on this IOLINK SOHO has been set as a Digital Leased Circuit.

2 Primary link

The Primary link option defines the primary link number that will be used to connect to this remote site.

Options: 1, 2, none

Default: [none]

Considerations:

The primary link must be a leased line module in this configuration. An ISDN BRI module with one link set to logical leased (monopole) and the other as ISDN (dial up) is not supported.

3 - Auto-Call

The Auto-Call option is used to define this remote site as one that the IOLINK SOHO will attempt to establish a connection to at all times. Each time the IOLINK SOHO is powered up a connection will be attempted to this remote site.

Default: [disabled]

Menus Reference Manual: Edit Remote Site - Connection Set-Up – ISDN Call Set-Up Menu

ISDN Call Set-Up Menu

```
EDIT REMOTE SITE 1 CONNECTION SET-UP ISDN CALL SET-UP MEN

Option                Value                Description
1. Advanced settings  menu                - Advanced ISDN call settings
2. ISDN number        [none]              - Set ISDN number
3. Alternate ISDN number [none]              - Set alternate ISDN number
4. Group              [1]                 - Specify dial group
5. Wildcard           [none]              - Set wildcard ISDN number
6. Call you           [none]              - Set call you prefix
7. Call me            [none]              - Set call me prefix
8. Callback           [enabled]           - Enable/disable callback

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

The **REMOTE SITE ISDN CALL SET-UP MENU** allows the setting of parameters used for ISDN call establishment to the remote site PPP router. This menu is not displayed when the Digital Leased Circuit option is enabled for the ISDN interface.

1 – Advanced Settings

This option takes you to the Advanced Settings menu where callback delay and redial parameters may be set.

2 - ISDN Number

The ISDN Number option defines the ISDN number to be called to establish a connection to the remote partner PPP router.

Default: [none]

3 - Alternate ISDN Number

The alternate ISDN number is used for two different situations when Multilink operation is set to enabled for this remote site.

1. ISDN number called when Bandwidth on Demand settings require a second ISDN call to be made after an initial Auto-Call or IP Address Connect call has been placed to the remote site. When the secondary connection is enabled by selecting the ISDN_call option, the first ISDN Number will be used to place the first ISDN call according to the IP Address Connect table, and the Alternate ISDN Number will be used to place the second ISDN call according to the Bandwidth on Demand options defined within the Secondary Activation menu.
2. ISDN number called when both the primary and secondary connections are set to ISDN_call and an Auto-Call or IP Address Connect call is placed. This will cause this alternate ISDN call to be placed to the remote site PPP router once the main ISDN call has been established and Multilink operation has been successfully negotiated.

Default: [none]

4 - Group

The Group option specifies which group number will be used to make calls to this remote site connection.

Default: [1]

Options: 1 or 2

5 - Wildcard

The Wildcard option defines the ISDN number used when checking for a match on an incoming callerID identified call. The incoming call is checked for a match against the configured values for the ISDN number, the alternate ISDN number, and then the wildcard number.

This wildcard number may contain don't care values to allow for a broader matching possibility. Don't care values are defined with an "X" in the wildcard number. When the IOLINK SOHO checks the incoming call's callerID against this wildcard value, the IOLINK SOHO starts at the rightmost digit and checks each digit from there. The number of digits compared is determined by the ISDN number with the least amount of digits. This means that the checking will only be done to the maximum number of digits of either the incoming callerID or the wildcard value, whichever is less.

For example: The wildcard value is set to 931-1XXX. Refer to the following list for accept and reject examples.

Incoming callerID	Result
328	accepted
931-1328	accepted
2328	rejected
555-1212	rejected

Default: [none]

6 - Call You

Dialing prefix used to make the ISDN call to the remote site PPP router. The Call You dialing prefix is used to define the area codes, country codes, long distance dialing prefixes, or any other information required to establish an ISDN call to the remote site PPP router.

Default: [none]

7 - Call Me

Dialing prefix used by the remote partner router to make an ISDN call to this IOLINK SOHO. When Connection Management is enabled, this ISDN IOLINK SOHO will pass its directory numbers as well as the Call Me dialing prefix to the remote partner ISDN IOLINK SOHO. This allows the remote partner ISDN IOLINK SOHO to correctly dial this IOLINK SOHO when the ISDN circuit needs to be resumed.

The Call Me dialing prefix is used to define the area codes, country codes, long distance dialing prefixes, or any other information required for the remote partner ISDN IOLINK SOHO to establish an ISDN call to this ISDN IOLINK SOHO.

Default: [none]

8 - Callback

The Callback option when set to enabled causes this IOLINK SOHO to refuse an incoming ISDN call for this remote site profile and then initiate an outgoing ISDN call to this remote site. Once a match of an incoming ISDN call is made to an existing remote site profile, the matching remote site profile is checked to determine whether the incoming call is answered or refused and a callback ISDN call initiated.

The Callback option may be used to provide a single point of ISDN billing. By allowing only one of the IOLINK SOHOs to establish ISDN calls, the ISDN charges may be centralized in one location.

The CallerID option when enabled will take precedence on determining whether an incoming call is ignored or answered. When calling back this remote site, both the ISDN number and the alternate ISDN number will be tried.

Default: [disabled].

Considerations:

For this feature to operate, the ISDN service provider must supply the caller's number. Check with your ISDN service provider to see whether this service is available. For callback from an IOLINK SOHO to a remote site router with only a single BRI to operate properly, the IOLINK SOHO must either have a hunt group number that the remote site router can call or the ISDN links must be set up in groups of two. If this is not done, the remote site router can call in to the IOLINK SOHO on one of up to 14 ISDN numbers; the callback will be made from the first available ISDN link. This may not be the number that the remote router uses as the primary or alternate ISDN, which means that the call will be rejected.

Advanced Settings Menu

EDIT REMOTE SITE 1 CONNECTION SET-UP ISDN CALL SET-UP ADVANCED SETTINGS MENU		
Option	Value	Description
1. Callback delay	[2 s]	- Time to wait until callback
2. Redial timer	[10 s]	- Time to wait until redial
3. Redial count	[5]	- Number of redials to try

1 – Callback Delay

The Callback Delay option specifies the number of seconds that this router will wait before making a call in response to a callback request call from the remote site router. This allows sufficient time for the originating call to complete its disconnect before the response call arrives.

Default: [2 sec]

Range: 1 to 20 seconds

2 - Redial Timer

The Redial Timer option specifies the time the router will wait before attempting to redial an incomplete ISDN call.

Default: [10 sec]

Range: 4 to 255 seconds

Considerations:

When the ISDN switch type is set to KDD or NTT, the default, and minimum redial timer value is 90 seconds.

3 - Redial Count

The Redial Count option specifies the number of times the router will attempt to redial an incomplete ISDN call.

Default: [5] redials

Range: 0 to 255 redials

Auto-Call Considerations:

When two ISDN numbers are defined in the ISDN Call Set-Up menu of the remote site entry, the IOLINK SOHO will alternate between the two numbers when re-dialing.

When the IOLINK SOHO attempts to establish an Auto-Call ISDN call and the PPP router at the remote site does not respond, the IOLINK SOHO will try up to the number of times defined in the Redial Count to establish the ISDN call. The interval between the successive attempts is defined by the Redial Timer. If after the defined number of redials the IOLINK SOHO cannot establish a call to the remote partner, the IOLINK SOHO will wait for one minute and then try to establish the ISDN call again using the Redial Count and the Redial Timer values. If the call is not established after these attempts, the IOLINK SOHO will wait for 2 minutes and then try again. The IOLINK SOHO will keep trying to establish the call (according to Redial Count & Redial Time) in blocks with the time intervals: 4 minutes, 8 minutes, 15 minutes, 15 minutes, etc.) until the remote partner answers the call.

When the ISDN switch type is set to KDD or NTT, the minimum time between re-dialing blocks is 3 minutes.

When the Redial Count is set to zero (0), the IOLINK SOHO will redial the remote partner indefinitely at one minute intervals using the defined ISDN numbers for the remote site according to the redial blocks explained earlier. The IOLINK SOHO will alternate between the two defined ISDN numbers for the partner in blocks of #1, #2 with a time between the two ISDN numbers of 4 seconds.

Address Connect Considerations:

When the IOLINK SOHO attempts to establish an Address Connect ISDN call and the remote partner does not respond, the IOLINK SOHO will not attempt to redial the remote partner until the next Address Connect connection is required.

If two ISDN numbers are defined in the ISDN Call Set-Up menu of the remote site entry, the IOLINK SOHO will dial the alternate ISDN number after waiting 4 seconds if the first ISDN number does not respond.

Activation Set-Up Menu

EDIT REMOTE SITE 1 ACTIVATION SET-UP MENU		
Option	Value	Description
1. Schedule	menu	- Schedule remote site activation
2. Usage set-up	menu	- Set up line usage parameters
3. Threshold set-up	menu	- Set up traffic level thresholds
4. Inactivity timer	[60 sec]	- Set traffic inactivity timer
5. Recovery timer	[60 s]	- Define recovery steady state time

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **ACTIVATION MENU** allows the setting of the activation schedule and usage limits for the primary link used to connect to the remote site router. Traffic activation levels may also be set allowing the secondary link to be used when the throughput of the primary link exceeds the defined levels.

Note: the activation schedules of **both** partner routers on the link must be set up identically. If one is set to be active while the other is not, the active router will continuously try to bring up the link to the partner router, which will reject the connection because its activation table is set to have the connection to that remote site inactive. If the routers are in different time zones, you must decide on a standard time to be used by both.

1 - Schedule

The Schedule option takes you to the Schedule Menu where the times that the primary link will be activated or deactivated are set.

2 - Usage Set-Up

The Usage Set-up option takes you to the Usage Set-up Menu, where the circuit usage limits may be set.

3 - Threshold Set-Up

The Traffic Set-up option takes you to the menu where the traffic load conditions and stability timers for activating and deactivating the secondary link may be set.

4 - Inactivity Timer

The Inactivity Timer option defines the **Connection Management Idle Timer** that is used to determine when an ISDN call will be suspended or terminated. This timer monitors traffic on the link. If the link traffic is idle, this IOLINK SOHO is set to use Connection Management, and there are LAN sessions using the link, the ISDN call will be suspended.

When the Inactivity Timer is set to off, this IOLINK SOHO will not suspend or terminate the ISDN call. This may be used to allow only one of the IOLINK SOHOs to monitor the link traffic to determine when to suspend or terminate the ISDN call.

The Inactivity Timer is also used for **IP Address Connect** configurations. If connection management is not used, the inactivity timer will monitor link traffic. If the traffic on the link is idle for a time longer than the inactivity timer, the link will be terminated and then be made available for the next IP address connect request.

Default: [60 sec]

Range: off, 20 to 3600 seconds

Note: This option will only be displayed if the primary link to this site is configured to be ISDN.

5 - Recovery Timer

The recovery timer sets the delay before the secondary link is activated or deactivated when the primary link goes down or is reestablished. This acts as a stability timer to give the primary link a period to recover before the backup is activated and to ensure that when the primary link is reestablished that it stays up for a significant time before the backup link is dropped.

Default: [15 sec]

Range: 15 to 300 seconds

Note: This option will only be displayed if the Connection option in the Edit Remote Site menu is set to `recovery` or `recovery_with_threshold`.

Schedule Menu

```
EDIT REMOTE SITE 1 ACTIVATION SET-UP SCHEDULE MENU

Option                                Description
1. Activation intervals                - Set activation intervals
2. Display schedule                    - View activation timetable
3. Display time                        - View current date and time

Enter option number, "=" - main menu, <TAB> - previous menu
>
```

The **PRIMARY ACTIVATION MENU** allows the setting of the activation schedule for the primary link to be used to connect to the remote site PPP router. It controls outgoing calls from this router to the remote site router incoming calls are not controlled by these options.

The Primary Activation conditions are not applicable when placing a manual call to this remote site.

1 - Activation Intervals

The Activation Intervals option defines the times that the primary link will be activated or deactivated.

Choose an action:

```
Enter:
  activate, deactivate, remove, clear
> activate
```

The Remove option will let you remove a specified activation time

The Clear option will clear the entire table of all activation times.

The following example show the set-up for a connection to be active from 7:00 AM to 11:00 PM on weekdays and 10:00 AM to 5:00 PM on Saturdays:

Specify the day(s):

```
Enter:
  Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday,
  Weekends, Weekdays
> Weekdays
```

Specify the time:

```
Enter:
  Time (hour or hour: 00 or hour: 30)
> 07
```

The above Time can be specified in any one of three ways: 7, 07, or 7: 00. Valid hour values are 0 to 23 (24 hour clock). Settings on the half-hour are also permissible, e.g. 7: 30.

Menus Reference Manual: Edit Remote Site - Activation Set-Up – Schedule Menu

Set link disconnect time:

```
> deactivate
> Weekdays
> 23
```

For a deactivation time of midnight on a given day, you must specify hour 0 of the next day. Note that hour 0 starts a given day and hour 23: 30 is the last time specifiable for a given day.

Add Saturday:

```
> activate
> Saturday
> 10
```

```
> deactivate
> Saturday
> 17
```

2 - Display Schedule

```
Call 1 Activation Schedule

  0  1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23
Sun -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
Mon -- -- -- -- -- -- -- AA AA AA AA AA AA AA AA AA AA AA AA AA AA AA --
Tue -- -- -- -- -- -- -- AA AA AA AA AA AA AA AA AA AA AA AA AA AA AA --
Wed -- -- -- -- -- -- -- AA AA AA AA AA AA AA AA AA AA AA AA AA AA AA --
Thu -- -- -- -- -- -- -- AA AA AA AA AA AA AA AA AA AA AA AA AA AA AA --
Fri -- -- -- -- -- -- -- AA AA AA AA AA AA AA AA AA AA AA AA AA AA AA --
Sat -- -- -- -- -- -- -- -- -- AA AA AA AA AA AA AA -- -- -- -- -- -- --

Activation Schedule Entries
Weekdays - 7: 00 Act      Weekdays - 23: 00 Deact    Saturday - 10: 00 Act
Saturday - 17: 00 Deact

Type: [s] to redraw, [=] main menu, any other key to end.
```

The display schedule shows the current schedule of when the primary connection to this remote site will be activated.

- A indicates that the connection will be active at this time
- indicates that the connection is inactive at this time

3 - Display Time

The Display Time option displays the current router time and date in the format::

Day of the week yyyy-mm-dd hh:mm:ss

Usage Set-Up Menu

```
EDIT REMOTE SITE 1 ACTIVATION SET-UP USAGE SET-UP MENU

Option      Value      Description
1. Usage limit [unlimited] - Set line use limit per day
2. Call limit  [unlimited] - Set outgoing call limit per day
3. Restart time "07:00"    - Set time-of-day to restart limits

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

1 - Usage Limit

The Usage Limit option defines the maximum ISDN connection time for this remote site. The time limit is defined in minutes of connection time and is the maximum connection time per day. The Restart Time option determines when the IOLINK SOHO will restart the usage limit timer.

Default: [unlimited]

Range: 1 to 2880 minutes or unlimited

2 - Call Limit

The Call Limit option defines the maximum number of ISDN connections allowed to this remote site per day.

Default: [unlimited]

Range: 1 to 86400 calls or unlimited

3 - Restart Time

The Restart Time option defines the time of day that the call limit and usage limit timers will start recounting. Time is specified as a 24 hour clock and may be set in 30 minute increments. Time can be specified in any one of three ways: 7, 07, or 7:00. Valid hour values are 0 to 23. Valid minute settings are :00 or :30, e.g. 7:30.

Default: [07:00]

Range: 0 to 23:3

Note: Changing the Restart Time will reset all statistics counters; all current statistics will be erased.

Threshold Set-Up Menu

EDIT REMOTE SITE 1 ACTIVATION SET-UP THRESHOLD SET-UP MENU

Option	Value	Description
1. Up threshold	[50 %]	- Set activation traffic level
2. Up stability timer	[5 min]	- Define up level steady state time
3. Down threshold	[40 %]	- Set deactivation traffic level
4. Down stability timer	[10 min]	- Define down level steady state time

Enter option number, "=" - main menu, <TAB> - previous menu

The **THRESHOLD SET-UP MENU** allows the traffic load conditions and stability timers for activating and deactivating the secondary link to be set.

1- Up Threshold

The Up Threshold value determines the percentage of primary link s capacity that will cause the secondary link to be activated. The primary link must sustain a throughput (either receive or transmit) of greater than the up threshold for a period greater than the up stability timer in order for the secondary link to be activated.

```
Enter:
  Percent of main link capacity (from 50 to 100)
> 80
```

Default: 80%

2 - Up Stability Timer

To prevent the unnecessary activation of the secondary link if the Up Threshold is only reached for a brief period, the Up Stability Timer is used. It defines how long the primary link s throughput must be at or above the Up Threshold before the secondary call is activated.

For example, using the default values, if a traffic level above the Up Threshold of 80% is maintained on the primary link for a period of 2-min. (length of time the secondary link is held inactive), then the secondary link will be activated.

```
Enter:
  time in minutes when link is down (from 1 to 60)
> 2
```

Default: 2 minutes

3 - Down Threshold

The Down Threshold determines when the secondary link is shut down again. It must be set lower than the Up Threshold.

After the secondary link comes on-line, it will begin to share the load that would have gone across the primary link. For example, if the primary link brings the secondary link on-line at a threshold of 80%, then both links will be carrying the load.

The Down Threshold looks at the total throughput (both links together) to determine if the second link will be brought down. The total throughput is compared to the throughput of a single link. When the total throughput drops below the Down Threshold, the second link will be dropped.

```
Enter:
  Percent of main link capacity (40 to 95)
> 60
```

Default: 60%

4 - Down Stability Timer

The Down Stability Timer is similar in operation to the Up Stability Timer. When the total link throughput drops below the value set by the Down Threshold for a period of time defined by the Down Stability Timer, the secondary link will be disconnected and placed back in the stand-by mode.

For example, if the total throughput (both links together) drops below 60% of the bandwidth of a single link (64 Kbps) for a period of 10 minutes, the secondary link will be disconnected.

```
Enter:
  time in minutes when link is up (from 1 to 60)
>10
```

Default: 2 minutes

Protocol Set-Up Menu

EDIT REMOTE SITE 2 PROTOCOL SET-UP MENU		
Option	Value	Description
1. Bridge parameters	menu	- Configure bridge parameters
2. IP parameters	menu	- Configure IP parameters
3. IPX parameters	menu	- Configure IPX parameters
4. CCP parameters	menu	- Configure CCP parameters
5. CMCP parameters	menu	- Configure connection management
6. BACP set-up	menu	- Configure BACP parameters
7. Multilink protocol	[enabled]	- Allows multilink operation

Enter option number, "=" - main menu, <TAB> - previous menu

>

1 - Bridge Parameters

The Bridge Parameters option takes you to the Bridge Parameters menu for the chosen remote site, where the bridge parameters are configured.

2 - IP Parameters

The IP Parameters option takes you to the IP Parameters menu for the chosen remote site, where the IP parameters are configured. The type of link is specified as numbered or unnumbered. The type of IP routing is set within this menu: either none, RIP1, RIP2 or RIP1_compatible. Both local and peer IP addresses are defined here, NAT and NATP may be enabled and configured and some connection management parameters are set.

3 - IPX Parameters

The IPX Parameters option takes you to the IPX Parameters menu for the chosen remote site, where the IPX parameters are configured. The type of link is specified as numbered or unnumbered. Both local and peer IPX addresses are defined here and some connection management parameters are set.

4 - CCP Parameters

The CCP Parameters option takes you to the CCP Parameters menu for the chosen remote site, where the CCP (Compression) parameters are configured.

5 - CMCP Parameters

The CMCP Parameters option takes you to the CMCP Parameters menu for the chosen remote site, where the CMCP (Connection Management) parameters are configured. The Connection Management parameters determine when the ISDN calls will be suspended and spoofed or when they will be terminated.

Note: this option will only be displayed if this remote site connection is configured as ISDN

5/6 - BACP Set-Up

The BACP Parameters menu allows you to activate the BACP (Bandwidth Allocation Control Protocol) and set the call conditions used. BACP reduces network charges by adding or dropping the second link based on traffic demands. BACP mediates control of the link between the routers to prevent link bobbing .

Note: this option will only be displayed if this remote site connection is not configured for single-link operation.

6/7/8 - Multilink Operation

This option determines whether the connection to this remote site will operate using single link protocol or PPP multilink protocol. Multilink protocol allows multiple links to be connected between two routers. The physical links may be of different types (e.g. Leased and ISDN)

Default: [disabled]

ISDN Considerations:

When multilink operation is changed for a group, all active ISDN calls will be disconnected.

When the IOLINK SOHO receives an incoming call, the Multilink state is taken from the INITIAL_PROFILE remote site profile. Note that if Multilink is disabled in the INITIAL_PROFILE and an incoming call requests Multilink, the IOLINK SOHO will negotiate to have Multilink enabled.

When a PPP IOLINK SOHO with Multilink disabled attempts to establish an ISDN connection to an Ascend router with Multilink enabled, the Ascend router will shut down the ISDN call. Simply set the Multilink values on each of the routers to be the same value and then establish the ISDN connection.

Bridge Parameters Menu

EDIT REMOTE SITE 1 BRIDGE PARAMETERS MENU		
Option	Value	Description
1. STP parameters	menu	- Define port specific options
2. Bridge enabled	[enabled]	- Enable BCP negotiations
3. Tinygram	[disabled]	- Enable tinygram compression
4. FCS preservation	[enabled]	- Preserve FCS across WAN

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **BRIDGE PARAMETERS MENU** allows the setting of the type of Bridge link connection to the remote site PPP router. The parameters defined here are used by the BCP (Bridge Control Protocol) functions of the router for negotiating bridging during call establishment.

1 - STP Parameters

The STP Parameters option directs you to the STP Parameters Menu where STP Port parameters for this remote site are set.

2 - BCP Enabled

The BCP Enabled option enables or disables the Bridge Control Protocol negotiations for this remote site. When a connection to this remote site does not require bridging, this option may be disabled causing BCP not to be negotiated.

Default: [enabled]

3 - Tinygram

The Tinygram option enables or disables the compression of bridge frames that are smaller than the minimum frame size of 64 bytes. Tinygram compression simply suppresses the trailing zeroes of a small frame.

Default: [disabled]

4 - FCS Preservation

The FCS Preservation option enables or disables the transmission of the Frame Check Sequence (FCS) for bridge frames that are passed to the remote site PPP device.

When set to disabled, this IOLINK SOHO will not send the FCS on bridge frames sent to the remote site PPP partner.

This option may need to be disabled when connecting to some Cisco routers.

Default: [enabled]

STP Parameters Menu

EDIT REMOTE SITE 1 BRIDGE PARAMETERS STP PARAMETERS MENU		
Option	Value	Description
1. State	[enabled]	- Enable/disable port
2. Path cost	[100]	- Define network cost for port
3. Priority	[128]	- Set port priority

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **STP PARAMETERS MENU** allows the setting of the STP port parameters used by the BCP (Bridge Control Protocol) functions of the router for negotiating bridging during call establishment. All of the settings in this menu will be ignored when STP is disabled within the Bridging Set-up menu.

1 - State

The State option toggles between enabling and disabling this WAN port when running Spanning Tree Protocol on the WAN connection to this remote site device.

2 - Path Cost

The Path Cost option allows the setting of the contributing path cost to the Root for this port.

Contribution of Path Cost to Root Path Cost:

The path cost to the Root Bridge is added to path costs of other bridges along the same stream to the Root Bridge. The result is the Root Path Cost.

Once the Root Bridge is selected, a determination of which bridge(s) will become blocked where necessary is made. This determination is made by comparing the sum of the path costs (i.e. the Root Path Cost) to the Root Bridge. Where redundant paths exist, the bridge with the lowest Root Path Cost to the Root Bridge will become the *Designated Bridge* for the LAN. If all contending bridges ports have the same Root Path Costs, then first their Bridge IDs (Priority/MAC address) and second their Port IDs (Port Priority) will be used as tiebreakers.

Default: [100]

Range: 1 to 65535

Considerations:

Increasing this value increases the total cost of the path to the Root Bridge. This may (depending on the topology) cause a bridge along the path to the Root bridge to be taken out of service and a blocked bridge to come into service.

Decreasing the value may have the opposite effect.

3 - Priority

The Priority option allows the setting of the port priority. This value is entered in decimal format and appears in hex format in the Port ID/Designated Port identifier (as applicable) of the Port Status display.

Default: [128] (decimal)

Range: 0 - 255

Considerations:

Increasing this value lowers the probability of this port becoming the Root port to the Root Bridge.
Decreasing this value increases the probability.

IP Parameters Menu

EDIT REMOTE SITE 1 PROTOCOL SET-UP IP PARAMETERS MENU		
Option	Value	Description
1. IP routing	menu	- Configure IP routing
2. NAT advanced setup	menu	- Configure NAT address pool
3. IP enabled	[enabled]	- Enable IP protocol
4. NAT enabled	[disabled]	- Enable address translation
5. Link IP type	[unnumbered]	- Define numbered link
6. Peer IP address	[none]	- Define peer IP address
7. Negotiate address	[enabled]	- IPCP address negotiation
8. VJ compression	[disabled]	- Enable VJ header compression
1. IP routing	menu	- Configure IP routing
2. NAT advanced setup	menu	- Configure NAT address pool
3. IP enabled	[enabled]	- Enable IP protocol
4. NAT enabled	[disabled]	- Enable address translation
5. Link IP type	[numbered]	- Define numbered link
6. Local IP address	[none]	- Define local IP address
7. Peer IP address	[none]	- Define peer IP address
8. Private route	[disabled]	- Do not advertise this route
9. VJ compression	[disabled]	- Enable VJ header compression

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IP PARAMETERS MENU** allows the setting of the type of IP link connection to the remote site PPP router. The parameters defined here are used by the IPCP (Internet Protocol Control Protocol) functions of the router for negotiating IP routing during call establishment. The menu options are shown in the above screen with the defaults for both the numbered and unnumbered link IP type settings.

Each side of the connection must have an IP address assigned to the router in order to properly route IP packets between the two routers.

The IP routing parameters defined here are for this connection to the remote site peer IP router only. The IP routing performed on the local LAN is defined within the IP Routing menu under the Configuration menu. This allows the IP routing to be set independently for each interface on this IOLINK SOHO router.

1 - IP Routing

The IP Routing option directs you to the IP Routing Parameters Menu where the IP routing parameters for this remote site are set. The parameters include the type of IP routing, the use of triggered RIP, and others.

2 NAT Advanced Setup

The NAT Advanced Setup option takes you to NAT Advanced Setup menu where parameters for the Network Address Translation pool for this remote site may be assigned.

3 - IP Enabled

The IP Enabled option enables or disables the Internet Protocol negotiations for this remote site. When a connection to this remote site does not require IP routing, this option may be disabled causing IP not to be negotiated.

Default: [enabled]

4 - NAT Enabled

Network Address Translation (NAT) is a technique which translates private IP addresses on a private network to valid global IP addresses for access to the Internet. Network Address Port Translation (NAPT) translates both the IP address and the port. The advantage of port translation is that more than one private IP address can be translated to the same single global IP address. NAPT allows data exchanges initiated from hosts with private IP addresses to be sent to the Internet via the IOLINK SOHO using a single global IP address. Port translation can also be used from one private network to another private network if the two networks have conflicting IP addresses.

A global IP address must be assigned to the WAN link upon which NAT is enabled for NAT to work. The global IP address may be configured locally or negotiated if numbered links are enabled. If unnumbered links are enabled, the router must accept an IP address for the WAN link from the remote site.

When NAT is enabled this router will not send RIP messages out. The router will be able to receive RIP requests. IP pattern filters and Firewall use the non-translated IP address. (i.e. the private IP address that is used on the private network).

Remember: if NAT is enabled with IP addressing and Firewall is enabled, then the IP address for this remote site must be in the firewall table.

Default: [disabled]

5 - Link IP Type

The Link IP Type option defines the type of link connection that will be established with the remote site PPP router. The link may be numbered, in which both sides of the WAN connection have IP addresses assigned; or unnumbered, in which the peer (remote partner PPP router) and the calling router use their device IP address.

When operating in unnumbered mode, each of the two IP routers operates as half of a complete router. The WAN connection is considered a common internal data path with the IP routing actually taking place between the two remote LANs.

When the link IP type is set to unnumbered, the Local IP Address option is not available. For an unnumbered link, the local IP address is taken from the IP address assigned to this router in the Internet Set-Up menu.

Default: [unnumbered]

Choices: numbered, unnumbered

6 - Local IP Address

The Local IP Address option allows the definition of an Internet Protocol (IP) address and corresponding subnet size for the link of this router.

When the link IP type is set to unnumbered, the Local IP Address option is not available. For an unnumbered link, the local IP address is taken from the IP address assigned to this router in the Internet Set-Up menu.

The IP address consists of 4 octets and is represented by 4 fields separated by periods (.), where each field is specified by a decimal number (e.g. 92.3.1.10). Each decimal number must be less than or equal to 255, that is the maximum value of each 8-bit field.

The Subnet Mask Size variable partitions the host field of an IP address into two parts: a *subnet number* and a *host number*. The subnet mask is defined as a series of contiguous bit locations from the start of the IP address.

Default: [none]

```
Enter :
      IP address (up to 15 characters)
>
Enter :
      subnet mask size(from 8 to 32)
>
```

Caution: when using numbered links, both the local IP address AND the subnet mask size MUST be entered. If only the IP address is entered and no subnet mask size, the router has no way of determining the subnet location the link will not operate.

6/7 - Peer IP Address

The Peer IP Address option allows the definition of an Internet Protocol (IP) address and corresponding subnet size for the link side of the PPP IP router at the remote site. If the link IP type is set to numbered, the peer IP address must be on the same network as the local IP address.

The IP address consists of 4 octets and is represented by 4 fields separated by periods (.), where each field is specified by a decimal number (e.g. 92.3.1.10). Each decimal number must be less than or equal to 255, that is the maximum value of each 8-bit field.

The subnet mask size is not specified when the link IP type is set to numbered. The subnet mask is defined as a series of contiguous bit locations from the start of the IP address.

Default: [none]

```
Enter :
      IP address (up to 15 characters)
>
Enter :
      subnet mask size(from 8 to 32)
>
```

7 - Negotiate Address

The Negotiate Address option is only available when the **Link IP Type is set to unnumbered**. Address negotiation causes this IOLINK SOHO to negotiate with the peer IP router to determine the IP addresses of each device. This allows this IOLINK SOHO to supply an IP address to the peer IP router if the Peer IP Address option is defined.

When address negotiation is enabled, this IOLINK SOHO will accept an IPCP PPP connection from a peer IP router even if the global IP address of this IOLINK SOHO is not configured. This IOLINK SOHO will use the negotiated address that the peer has provided.

When address negotiation is disabled, this IOLINK SOHO will not initiate address negotiations but will respond to address negotiations if requested by the peer IP router.

Default: [enabled]

8 - Private Route

The Private Route option is only available when the **Link IP Type is set to numbered**. Setting this numbered link connection to be a private link causes the IP connection to the peer IP router to not be advertised in the RIP information.

Default: [disabled]

8/9 - VJ Compression

The VJ Compression option enables or disables Van Jacobson header compression on packets send to this remote site.

Default: [disabled]

IP Parameters - IP Routing Menu

EDIT REMOTE SITE 1 PROTOCOL SET-UP IP PARAMETERS IP ROUTING MENU		
Option	Value	Description
1. Routing protocol	[rip1_compatible]	- Define link routing protocol
2. RIP mode	[both]	- Define RIP send/receive mode
3. Triggered RIP	[disabled]	- Define triggered RIP
4. Auto Default Route	[disabled]	- Add default route on connect
5. Link cost	[0]	- Define cost added to routes

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IP PARAMETERS - IP ROUTING MENU** allows the setting of the IP routing parameters to use for this IPCP connection to the peer IP router. The parameters defined here are used by the IPCP (Internet Protocol Control Protocol) functions of the router for negotiating IP routing during call establishment.

1 - Routing Protocol

The Routing Protocol option defines the type of IP routing protocol to be used on this link interface. The IOLINK SOHO may be set up to use different types of IP routing protocols on each of its interfaces: LAN and links.

When the routing protocol is defined as none, the IOLINK SOHO will operate as an IP router but will NOT participate in the exchange of RIP messages between the other IP routers in the network. All IP routing is accomplished by using the static routes table. All routes within the network must be manually entered in the static routing table.

When the routing protocol is defined as rip1, the IOLINK SOHO will operate as a RIP1 IP router. All routing information will be sent and received via broadcast RIP packets.

When the routing protocol is defined as rip1_compatible, the IOLINK SOHO will operate as a RIP2 IP router in broadcast mode. All routing information will be sent via broadcast RIP2 packets. Routing information may be received as broadcast RIP1, broadcast RIP2, or multicast RIP2.

When the routing protocol is defined as rip2, the IOLINK SOHO will operate as a RIP2 IP router. All routing information will be sent via multicast RIP2 packets. Routing information may be received as broadcast RIP2 or multicast RIP2.

Partner routers connected on the WAN do not need to have their IP routing protocols set to the same values. An IP router at a central site may have its routing protocol set to RIP so that it may continue to listen to RIP messages and adapt to the changes of the local network, while the remote locations, with their default routes back to the main router, cannot propagate any incorrect routing information that might be present on the remote segments. Each of the routers at the remote sites would have their routing protocol set to none.

Default: [rip1_compatible]

Choices: none, rip1, rip1_compatible, rip2

2 - RIP Mode

The RIP Mode option defines how this IOLINK SOHO will participate in RIP IP routing messages over the link to this remote site.

When the RIP mode is set to both, the IOLINK SOHO will send and receive RIP routing messages over the link to this remote site.

When the RIP mode is set to send_only, the IOLINK SOHO will only send RIP routing messages over the link to this remote site.

When the RIP mode is set to receive_only, the IOLINK SOHO will only receive RIP routing messages over the link to this remote site.

Default: [both]

Choices: both, send_only, receive_only

3 - Triggered RIP

The Triggered RIP option disables or defines the type of triggered RIP to use on the link to this remote site.

Disabling this option will cause the RIP routing tables to be transmitted every 60 seconds.

Entering `standard` enables triggered RIP; the IOLINK SOHO will only send RIP messages over the link to this remote site when the routing information has actually changed.

Entering `link_up_only` enables triggered RIP; the IOLINK SOHO will only send RIP messages over the link to this remote site when the routing information has actually changed **and** the link is currently up. If the link is down due to suspension, the routing information will be queued and then sent the next time the link is brought up for user data.

When triggered RIP is enabled, if the remote site router refuses to negotiate triggered RIP on the initial connection, this router will attempt to negotiate triggered RIP for 5 minutes. During the 5 minutes, this router will use normal RIP and SAP. If triggered RIP has not been negotiated after the 5 minutes, this router will fall back to using normal RIP and SAP.

Default: [disabled]

Choices: disabled, standard, link_up_only

Considerations: If you are running spoofing with Triggered RIP, both routers must be set to Triggered RIP `link_up_only`. The IOLINK SOHO will automatically configure to this setting but the remote partner router should be checked to make certain that it is correctly configured.

4 - Auto Default Route

The Auto Default Route option allows a default IP route to be added to the routing tables when a connection is established to this remote site. When the link to this remote site goes down, the auto default route will be removed from the routing table.

Default: [disabled]

5 - Link Cost

The Link Cost option defines the amount of extra routing cost to add to routes that are learned from this link connection. This added link cost may be useful in forcing learned routes to have a higher cost when they are across a slower link connection.

Default: [0]

IP Parameters – NAT Advanced Set-Up Menu

```

EDIT REMOTE SITE 1 PROTOCOL SET-UP IP PARAMETERS NAT ADVANCED SETUP MENU

Option                Value                Description
1. Translation type   [port]              - Define translation method
2. Show address pool                    - Display IP mappings
3. Dynamic IP pool    [none]              - Dynamically assigned mappings
4. Add static entry                    - Specify IP-IP mappings
5. Remove static entry                  - Remove static IP mapping

Enter option number, "=" - main menu, <TAB> - previous menu
>
    
```

The NAT Advanced Set-Up Menu allows you to set parameters for the NAT address pool for this remote site router.

1 - Translation Type

This option sets the address translation method to be used for NAT. The address may be translated as either a port or an internal IP address. With IP address translation, each internal IP address is mapped to one global IP address; with port translation, several internal IP addresses may be mapped to a single global IP address.

Default: [port]

2 - Show Address Pool

This option displays the IP address pool for this remote site.

NAT ADDRESS POOL			
Pool Address	Type	Actual Address	Status
-----	-----	-----	-----
12.34.5.6	Static	196.23.45.6	In use
12.34.5.12	Static	196.23.45.24	Reserved
23.45.6.10	Dynamic	123.45.67.8	In use
23.45.6.11	Dynamic	None assigned	Available
23.45.6.12	Dynamic	None assigned	Available
23.45.6.13	Dynamic	None assigned	Available

The Pool Address is the internal address to be used on this network, the Actual Address is the global IP address to which the internal address is assigned.

When the last dynamically assigned address in the address pool is reached, the router will automatically use port translation with that address in order to allow as many connections as possible. If there are zero or one address specified for the pool, then NAPT will be used for all connections. If zero, the address assigned by the remote router IPCP or the address specified in the Peer IP address option will be used. If one address is specified, that address will be used.

3 - Dynamic IP Pool

The Dynamic IP Address Pool option defines the block of global IP addresses that may be used to map to internal addresses. The router will assign a global IP address from this pool to the internal address of a device on the network.

The first address in the range must be specified followed by the number of addresses in the pool.

4 - Add Static Entry

The Add Static Address option assigns a specific internal IP address of a device to a specific global IP address. When this option is selected, first enter the internal IP address to be assigned, then the global IP address.

5 - Remove Static Address

The Remove static address option removes the static address assignment from the address pool. Addresses may be removed individually by entering the global IP address to be taken off, or the entire list of static address assignments may be cleared by entering `all` .

IPX Parameters Menu

EDIT REMOTE SITE 1 IPX PARAMETERS MENU		
Option	Value	Description
1. IPX enabled	[enabled]	- Enable IPX protocol
2. Link IPX type	[unnumbered]	- Define numbered link
3. Static routes only	[disabled]	- Only use static IPX routes
4. IPX DMR enabled	[disabled]	- Enable Demand RIP
5. Force RIP update	[disabled]	- Enable forced regular RIP updates
1. <i>IPX enabled</i>	<i>[enabled]</i>	<i>- Enable IPX protocol</i>
2. <i>Link IPX type</i>	<i>[numbered]</i>	<i>- Define numbered link</i>
3. <i>IPX net</i>	<i>[none]</i>	<i>- Define IPX network number</i>
4. <i>Local IPX node</i>	<i>[none]</i>	<i>- Define local IPX node number</i>
5. <i>Peer IPX node</i>	<i>[none]</i>	<i>- Define peer IPX node number</i>
6. <i>Static routes only</i>	<i>[disabled]</i>	<i>- Only use static IPX routes</i>
7. <i>IPX DMR enabled</i>	<i>[disabled]</i>	<i>- Enable Demand RIP</i>
8. <i>Force RIP update</i>	<i>[disabled]</i>	<i>- Enable forced regular RIP updates</i>
Enter option number, "=" - main menu, <TAB> - previous menu		
>		

The **IPX PARAMETERS MENU** allows the setting of the type of IPX link connection to the remote site PPP router. The parameters defined here are used by the IPX (Internet Packet Exchange) functions of the router for negotiating IPX routing during call establishment. The menu options are shown in the above screen with the defaults for both the numbered and unnumbered link IPX type settings.

1 - IPX Enabled

The IPX Enabled option enables or disables the Internet Packet Exchange negotiations for this remote site. When a connection to this remote site does not require IPX routing, this option may be disabled.

Default: [enabled]

2 - Link IPX Type

The Link IPX Type option defines the type of link connection that will be established with the remote site PPP router. The link may be:

1. Numbered - This is where both sides of the WAN connection have IPX node addresses assigned and the WAN connection has its own IPX network number.
2. Unnumbered - This is where the local and peer (remote partner PPP router) routers use their internal LAN side IPX node numbers.

When operating in unnumbered mode, each of the two IPX routers operates as half of a complete router. The WAN connection is considered a common internal data path with the IPX routing actually taking place between the two remote LANs.

When the link IPX type is set to unnumbered, the IPX Net, Local IPX Node, and Peer IPX Node options are not available.

When the link IPX type is set to numbered, the IPX network and local and peer IPX node numbers should be defined to ensure proper IPXCP negotiations between the local and peer IPX PPP routers.

Default: [unnumbered]

Choices: numbered, unnumbered

3 - IPX Net

The IPX Net option allows the definition of the IPX network number to use for the WAN connection when operating in numbered mode for this IPXCP link to the remote site PPP router.

Default: [none]

```
Enter :  
  none, Network number (up to 8 characters)  
>
```

4 - Local IPX Node

The Local IPX Node option allows the definition of an Internet Packet Exchange (IPX) node address for the link of this router.

When the link IPX type is set to unnumbered, the Local IPX Node option is not available.

The IPX Node address consists of 12 hexadecimal bytes. The address may be entered with or without the hyphens. An example of an IPX node address may be 00-00-d0-00-12-13, and would be entered as such or simply as 0000d0001213.

Default: [none]

```
Enter :  
  none, IPX node number (up to 17 characters)  
>
```

5 - Peer IPX Node

The Peer IPX Node option allows the definition of an Internet Packet Exchange (IPX) node address for the link side of the PPP IPX router at the remote site.

When the link IPX type is set to unnumbered, the Peer IPX Node option is not available.

Default: [none]

```
Enter :
  none, IPX node number (up to 17 characters)
>
```

3 / 6 - Static Routes Only

The Static Routes Only option determines the type of IPX routing to perform on the connection with the peer IPX router. By enabling this option, only the static IPX routes and services defined in the IPX Routing Set-up menu will be used to perform IPX routing with the peer IPX router.

Default: [disabled]

4 / 7 - IPX DMR Enabled

The IPX DMR Enabled option defines or disables demand RIP for IPX routing with the peer IPX router. Demand RIP allows the IPX routing tables to be updated only when there has been a change in the routing table.

Disabling this option will cause the IPX RIP routing tables to be transmitted every 60 seconds.

Entering `standard` enables demand RIP; the IOLINK SOHO will only send RIP messages over the link to this remote site when the routing information has actually changed.

Entering `link_up_only` enables demand RIP; the IOLINK SOHO will only send RIP messages over the link to this remote site when the routing information has actually changed **and** the link is currently up. If the link is down due to suspension, the routing information will be queued and then sent the next time the link is brought up for user data.

When demand RIP is enabled, if the remote site router refuses to negotiate demand RIP on the initial connection, this router will attempt to negotiate demand RIP for 5 minutes. During the 5 minutes, this router will use normal RIP and SAP. If demand RIP has not been negotiated after the 5 minutes, this router will fall back to using normal RIP and SAP.

Default: [disabled]

Choices: disabled, standard, link_up_only

5 / 8 - Force RIP Update

The Force RIP Update option determines if the IOLINK SOHO will send a RIP update request to the WAN peer IPX router when a local LAN RIP update is sent. When operating under normal RIP update times, this forces the WAN partners to provide their RIP tables when requested to maintain proper routing information.

Default: [disabled]

Compression Parameters Menu

EDIT REMOTE SITE 1 CCP PARAMETERS MENU		
Option	Value	Description
1. Compression	[enabled]	- Allows compression operation
2. Extended sequence	[disabled]	- Two byte sequence field

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **COMPRESSION (CCP) PARAMETERS MENU** allows the setting of data compression on the link connection to the remote site PPP router. The parameters defined here are used by the CCP functions of the router for negotiating data compression during call establishment.

1 - Compression

The Compression option enables or disables the negotiation of data compression for data packets sent from the remote site PPP router and received by this router. The IOLINK SOHO performs data compression at the bundle level and not at the link level. Link based compression will be rejected. The IOLINK SOHO supports CCP option 17 - PPP Stac LZS Compression Protocol.

When the Compression option is enabled, this router will allow data compression to be negotiated from the remote site PPP router for data that is sent from this router to the remote site router.

When compression is disabled, this router will not allow data compression to be negotiated for the connection.

Default: [enabled]

2 - Extended Sequence

The Extended Sequence option enables or disables the use of a two-byte sequence number for inter-router communications. When disabled, the sequence number is one byte.

This option should be enabled when connecting to a PPP router that uses a two-byte sequence number instead of a one-byte sequence number. Some Cisco routers with software versions IOS 11.0 and IOS 11.1 use a two-byte sequence number.

Default: [disabled]

Considerations:

If compression has been negotiated for the connection but many data errors are received and very little data, the Extended Sequence number may need to be enabled to allow for the two byte sequence numbering.

CMCP (Connection Management) Parameters Menu

EDIT REMOTE SITE 1 PROTOCOL SET-UP CMCP PARAMETERS MENU		
Option	Value	Description
1. IP spoofing	menu	- Configure IP spoofing
2. IPX spoofing	menu	- Configure IPX spoofing
3. CMCP enabled	[disabled]	- Enable CMCP negotiations
4. Bridge traffic	[enabled]	- Spoof bridge traffic
5. Disc after last	[disabled]	- Disconnect after last session
6. Suspension timeout	[off]	- Set maximum suspension interval

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **CONNECTION MANAGEMENT (CMCP) PARAMETERS MENU** allows the configuration of the Connection Management options for this remote site.

Note: this menu will only appear if this router has a connection to this remote site configured as ISDN.

1 - IP Spoofing

The IP Spoofing option directs you to the IP Spoofing Parameters Menu where the IP spoofing parameters for this remote site are set. The parameters define how to interact and keep track of the TCP sessions while connection management is enabled on the link to this remote site.

2 - IPX Spoofing

The IPX Spoofing option directs you to the IPX Spoofing Parameters Menu where the IPX spoofing parameters for this remote site are set. The parameters define how to interact and keep track of the IPX sessions while connection management is enabled on the link to this remote site.

3 - CMCP Enabled

The CMCP Enabled option enables or disables the Connection Management Control Protocol negotiations for this remote site. When a connection to this remote site does not require connection management, this option may be disabled causing CMCP not to be negotiated.

Connection Management is used to minimize the amount of connection time used when connected to partner IOLINK SOHOs.

When Connection Management is enabled, the active ISDN calls are monitored for "Interesting Traffic", suspended, and resumed when required to transfer user data between IOLINK SOHOs.

Default: [disabled]

Considerations: if this remote site is set as spoofing, CMCP will be set to enabled.

4 - Bridge Traffic

The Bridge Traffic option enables or disables spoofing of bridge frame traffic while Connection Management is enabled.

When the IOLINK SOHO is spoofing bridge traffic (this option enabled), the bridge traffic received from the LAN will not be used to resume a suspended ISDN call or to keep an existing ISDN call up. While the ISDN call is up for other reasons, the bridge traffic received from the local LAN will be passed.

When this option is disabled, the IOLINK SOHO will pass all bridge traffic received from the local LAN. This will cause ISDN calls to be resumed if suspended.

Default: [enabled]

5 - Disconnect After Last

The Disconnect After Last option sets the time delay for disconnecting the link connection to this remote site after all of the connection management monitored sessions have been terminated. If set to off, the link connection will be disconnected when the Inactivity Timer to expires.

Default: [off]

```
Enter :  
    off, immediately, delay in seconds (from 5 to 300)  
>
```

6 - Suspension Timeout

The Suspension Timeout option allows the definition of a maximum time that the link connection may be in the suspended state. If the link connection has been suspended for the time period defined by the suspension timeout, the link connection will be silently dropped and the sessions logged on that connection will be removed from the table. Silently dropping the link connection means that the peer remote site router will not be notified that the connection has been dropped.

Default: [off]

```
Enter :  
    Time in minutes (from 1 to 10080), off  
>
```

IP Spoofing Menu

```
EDIT REMOTE SITE 1 PROTOCOL SET-UP CMCP PARAMETERS IP SPOOFING MENU

Option          Value          Description
1. TCP idle     [3600 sec]    - Set interval till first TCP keepalive
2. TCP interval [60 sec]      - Set interval between TCP keepalives
3. TCP retries  [5]           - Set maximum TCP keepalive retries
4. TCP aging    [7200 sec]    - Set TCP connection aging interval

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

The **IP SPOOFING PARAMETERS MENU** allows the setting of connection management parameters that control the IP spoofing portion of the link connection. The timers and values defined within this menu will be used for each of the TCP sessions monitored by this IOLINK SOHO.

1 - TCP Idle

The TCP Idle option defines the idle time in seconds that the IOLINK SOHO will wait before sending the first fake (spoofed) keepalive to the TCP session endpoint. Idle time is the time when the IOLINK SOHO does not receive TCP keepalive messages for that TCP session.

When the TCP Idle option is set to off, the IOLINK SOHO will never send out fake keepalive messages.

The TCP keepalive messages are used to determine if the station at the end of the TCP session is still alive.

Default: [3600 sec]

```
Enter :
time in seconds (from 60 to 7200), off
>
```

2 - TCP Interval

The TCP Interval option defines the internal interval time in seconds that the IOLINK SOHO will wait before sending the next TCP keepalive. These additional keepalive messages will be sent when there has not been a response to the initial keepalive messages sent from the IOLINK SOHO.

The TCP keepalive messages are used to determine if the station at the end of the TCP session is still alive.

Default: [60 sec]

```
Enter :
time in seconds (from 5 to 120)
>
```

3 - TCP Retries

The TCP Retries option defines the number of unacknowledged fake TCP keepalive messages that this IOLINK SOHO will send before the TCP session is considered dead.

The TCP keepalive messages are used to determine if the station at the end of the TCP session is still alive.

Default: [5]

```
Enter :  
      Number of retries (from 1 to 20)  
>
```

4 - TCP Aging

The TCP Aging option defines the amount of idle time in seconds that the IOLINK SOHO will wait before the TCP session is aged out and considered dead. The aging timer starts counting when there is no session traffic.

The TCP aging timer can be used in conjunction with the IP address connect feature. When the TCP session traffic is idle for a time longer than the inactivity timer, the link will be suspended. If the TCP session continues to be idle, the aging timer will age out the session. Once all of the sessions are aged out, the link will be quietly taken from suspended to down. This process allows the link to be available for use with another IP address connect request.

When a TCP session has been aged out and the IOLINK SOHO then receives a TCP keepalive for that session, the link will be re-established to send the keepalive. The link is re-established because the TCP keepalive messages are not easily discernable from normal TCP session traffic. The TCP aging timer should be set to a value larger than the frequency of TCP keepalive messages on the network. TCP keepalive messages can have intervals as long as 60 minutes.

The TCP keepalive messages are used to determine if the station at the end of the TCP session is still alive.

Default: [7200 sec]

```
Enter :  
      time in seconds (from 60 to 604800), off  
>
```


IPX Spoofing Menu

EDIT REMOTE SITE 1 PROTOCOL SET-UP CMCP PARAMETERS IPX SPOOFING MENU		
Option	Value	Description
1. IPX type20	[enabled]	- Spoof IPX type20 frames
2. IPX broadcast	[enabled]	- Spoof IPX broadcast frames
3. IPX idle	[300 s]	- Set interval till first IPX watchdog
4. IPX interval	[60 s]	- Set interval between IPX watchdogs
5. IPX retries	[10]	- Set maximum IPX watchdog retries
6. IPX aging	[86400 s]	- Set IPX connection aging interval

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IPX SPOOFING PARAMETERS MENU** allows the setting of connection management parameters that control the IPX spoofing portion of the link connection. The timers and values defined within this menu will be used for each of the IPX sessions monitored by this IOLINK SOHO.

1 - IPX Type20

When the IPX Type20 option is enabled, this IPX router will ignore IPX type 20 packets and not re-transmit them to partner routers on the WAN. When the IOLINK SOHO is spoofing IPX type 20 packets, the type 20 packets received from the LAN will not be used to resume a suspended ISDN call or to keep an existing ISDN call up.

Default: [enabled]

2 - IPX Broadcast

When the IPX Broadcast option is enabled, this IPX router will ignore IPX broadcast packets and not re-transmit them to partner routers on the WAN. When the IOLINK SOHO is spoofing IPX broadcast packets, the broadcast packets received from the LAN will not be used to resume a suspended ISDN call or to keep an existing ISDN call up.

Default: [enabled]

3 - IPX Idle

The IPX Idle option defines the idle time in seconds that the IOLINK SOHO will wait before sending the first fake (spoofed) watchdog to the client for the IPX session. Idle time is the time when the IOLINK SOHO does not receive IPX watchdog messages for that IPX session.

When the IPX Idle option is set to off, the IOLINK SOHO will never send out fake watchdog messages.

The IPX watchdog messages are used by servers to determine if the client at the end of the IPX session is still alive.

Default: [300 sec]

```
Enter :  
    time in seconds (from 60 to 1260), off  
>
```

4 - IPX Interval

The IPX Interval option defines the internal interval time in seconds that the IOLINK SOHO will wait before sending the next IPX watchdog. These additional watchdog messages will be sent when there has not been a response to the initial watchdog messages sent from the IOLINK SOHO.

The IPX watchdog messages are used by servers to determine if the client at the end of the IPX session is still alive.

Default: [60 sec]

```
Enter :  
    time in seconds (from 10 to 600)  
>
```

5 - IPX Retries

The IPX Retries option defines the number of unacknowledged fake IPX watchdog messages that this IOLINK SOHO will send before the IPX session is considered dead.

The IPX watchdog messages are used by servers to determine if the client at the end of the IPX session is still alive.

Default: [10]

```
Enter :  
    Number of retries (from 5 to 100)  
>
```

6 - IPX Aging

The IPX Aging option defines the amount of idle time in seconds that the IOLINK SOHO will wait before the IPX session is aged out and considered dead. The aging timer starts counting when there is no session traffic.

When an IPX session has been aged out and the IOLINK SOHO then receives a watchdog for that session, the IOLINK SOHO will simply ignore the watchdog.

The IPX watchdog messages are used by servers to determine if the client at the end of the IPX session is still alive.

Default: [86400 sec]

```
Enter :  
      time in seconds (from 60 to 604800), off  
>
```

BACP Set-Up Menu

EDIT REMOTE SITE PROTOCOL SET-UP BACP SET-UP MENU		
Option	Value	Description
1. BACP	[enable]	- Enable/disable BACP operation
2. Call mode	[local]	- Device to initiate second call
3. Request number	[disabled]	- Partner provides second call number

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **BACP PARAMETERS MENU** allows you to activate the BACP (Bandwidth Allocation Control Protocol) and set the call conditions used.

1 - BACP

The BACP option enables or disables the BACP for the secondary link. The parameters to add or drop the secondary link are set at the Main/Configuration/WAN Set-up/Remote Site Set-up/Edit Remote Site/Secondary Link Activation Menu.

Default: [enabled]

2 - Call Mode

The Call Mode option toggles between local and partner modes. Call mode allows you to set where the call to bring up the secondary link will originate from, so that all connections may be made from one router for centralized billing.

In local mode, this IOLINK SOHO will initiate an outgoing call back to the remote site to re-establish the link.

In partner mode, this IOLINK SOHO will send a request to the other router (via the primary link) to bring up the link from that end.

Default: [local]

3 - Request Number

The Request Number option is functional when BACP is in local mode. If enabled, the partner remote site ISDN number is requested. When disabled, the acknowledge message from this IOLINK SOHO tells the partner remote site router that its ISDN number does not need to be sent (it is in the lookup table already).

Default: [disabled]

Note: this option is only displayed if Call Mode is [local].

Security Parameters Menu

EDIT REMOTE SITE SECURITY PARAMETERS MENU		
Option	Value	Description
1. Incoming PAP password	[none]	- Set incoming PAP password
2. Incoming CHAP secret	[none]	- Set incoming CHAP secret
3. Outgoing user name	"DEV050607"	- Set outgoing user name
4. Outgoing PAP password	[none]	- Set outgoing PAP password
5. Outgoing CHAP secret	[none]	- Set outgoing CHAP secret

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **EDIT REMOTE SITE SECURITY PARAMETERS MENU** allows you to set outgoing and incoming password data and an outgoing user name for PPP security on the connection to this remote site router.

Note: routers configured to have a leased line link operating in conjunction with an ISDN B-Channel (either as backup or bundled link) must have security enabled and with the proper usernames and passwords entered on both partner routers.

1 - Incoming PAP password

The Incoming PAP Password option defines the PAP password that this Orbiter PPP router expects to receive from the remote site PPP router in response to authentication requests from this router.

Default: [none]

2 - Incoming CHAP secret

The Incoming CHAP Secret option defines the CHAP secret that this Orbiter PPP router expects to receive from the remote site PPP router in response to authentication requests from this router.

Default: [none]

3 - Outgoing user name

The Outgoing User Name option defines the user name that this IOLINK SOHO PPP router will be sending to the remote site PPP router when responding to authentication requests from the remote site PPP router. The outgoing user name defaults to the device name. If the device name is changed, all remote sites are searched and any remote site whose outgoing user name matches the old device name will be updated to use the new device name.

The outgoing user name must be defined the same as the user name defined in the PPP security settings for the remote site router.

The outgoing user name is case sensitive and may consist of 1 to 32 alphanumeric characters. Use the underscore character instead of a space character.

Default: [*] Default device name

4 - Outgoing PAP password

The Outgoing PAP Password option defines the PAP password that this Orbiter PPP will use when responding to authentication requests from the remote site PPP router.

Default: [none]

5 - Outgoing CHAP secret

The Outgoing CHAP Secret option defines the CHAP secret that this Orbiter PPP will use when responding to authentication requests from the remote site PPP router.

Default: [none]

Security Set-Up Menu

SECURITY SET-UP MENU		
Option	Value	Description
1. Default parameters	menu	- Set default outgoing security
2. Security level	[none]	- Set security protocol
3. Request security	[incoming-only]	- Set security operation
4. CHAP challenges	[once]	- CHAP Authentication
5. CallerID security	[disabled]	- Enable/disable CallerID security

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **SECURITY SET-UP MENU** allows the configuration of the PPP security options used between this router and the remote site for which a profile is currently being configured.

Note: routers configured to have a leased line link operating in conjunction with an ISDN B-Channel (either as backup or bundled link) must have security enabled (security level set to either [PAP] or [CHAP]) and with the proper usernames and passwords entered on both partner routers.

1 - Default parameters

The Default Parameters option takes you to the Default Parameters menu where the outgoing PPP security options to be used by this router when calling the remote site are configured.

2 - Security Level

The Security Level option defines the type of PPP security to use for incoming connections. When a security level is set, the IOLINK SOHO will always require authentication on incoming connections. The IOLINK SOHO will ask for authentication on outgoing calls when a security request is set to always (see below).

Default: [none]

Choices: none, PAP, CHAP

3 - Request security

This specifies when the remote site router should be requested to authenticate:

- always (when this router makes an outgoing call OR receives an incoming call)
- incoming_only (ONLY when this router receives an incoming call)

Default: If an ISDN module is installed: [incoming only]
If only leased line module(s) installed: [always]

Choices: always, incoming only

4 - CHAP Challenges

The CHAP Challenges option defines the frequency of CHAP challenges that this IOLINK SOHO PPP router will require when authenticating a remote site PPP router.

Default: [once]

Choices: once, continuous

5 - CallerID Security

The CallerID Security option enables or disables the use of incoming callerID information to do a security check for valid devices. This option may be used to refuse incoming ISDN calls from routers located at an unknown site. Incoming callerID information received is matched against the ISDN number, alternate ISDN number, and wildcard values of each remote site profile. If a match is not found after checking each of the three numbers in each of the remote site profiles, the incoming ISDN call will be ignored.

The CallerID Security option must only be enabled on an IOLINK SOHO that is connected to an ISDN service that provides callerID functions. Check with your ISDN service provider about the availability of this service. This option is only applicable to incoming data calls.

When this option is set to enabled, this IOLINK SOHO will ignore any incoming ISDN call that does not provide callerID information or the callerID information does not match one of the configured values.

This option is only available when digital leased option disabled.

Default: [disabled]

Default Parameters Menu

DEFAULT PARAMETERS MENU		
Option	Value	Description
1. Outgoing user name	"DEV050607"	- Set outgoing user name
2. Outgoing PAP password	"*"	- Set outgoing PAP password
3. Outgoing CHAP secret	[none]	- Set outgoing CHAP secret

The **DEFAULT PARAMETERS MENU** allows you to set default outgoing PPP security options for this router. The values set in this menu will be used for any calls originating from this router rather than from a remote site (calls originating from a remote site will use the security parameters set for that site).

1 - Outgoing user name

The Outgoing User Name option defines the user name that this IOLINK SOHO PPP router will be sending to the called remote site PPP router when responding to authentication requests from the remote site PPP router. The outgoing user name defaults to the device name. If the device name is changed, all remote sites are searched and any remote site whose outgoing user name matches the old device name will be updated to use the new device name.

The outgoing user name must be defined the same as the user name defined in the PPP security settings for the remote site router.

The outgoing user name is case sensitive and may consist of 1 to 32 alphanumeric characters. Use the underscore character instead of a space character.

Default: [*] Default device name

2 - Outgoing PAP password

The Outgoing PAP Password option defines the PAP password that this IOLINK SOHO PPP will use when responding to authentication requests from the remote site PPP router.

Default: [none]

3 - Outgoing CHAP secret

The Outgoing CHAP Secret option defines the CHAP secret that this IOLINK SOHO PPP will use when responding to authentication requests from the remote site PPP router.

Default: [none]

PPP Set-Up Menu

PPP SET-UP MENU		
Option	Value	Description
1. Advanced PPP set-up	menu	- Configure advanced PPP parameters
2. Restart timer	[3000 msec]	- Set restart timer
3. Configure count	[10]	- Set configure count
4. Failure count	[5]	- Set failure count
5. Terminate count	[2]	- Set terminate count

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **PPP SET-UP MENU** provides for general PPP circuit parameter set-up. The parameters configurable from this menu are used during LCP (Link Control Protocol) negotiations with a remote site PPP router. This IOLINK SOHO PPP router will request the configuration parameters defined here when initiating a PPP connection to a remote site PPP router.

When negotiating the LCP parameters for incoming PPP connections initiated by the remote site PPP router, this IOLINK SOHO will use these values as defaults but will accept a request for different values from the remote site PPP router.

If any of these LCP configuration parameters are required to be of a known value for a particular PPP connection, the parameters should be set to the same values on the routers on each end of the PPP link.

1 - Advanced PPP Set-Up

The Advanced PPP Set-up option takes you to the Advanced PPP Set-Up Menu. Here you set the advanced LCP parameters such as field compression, Quality protocol, and the type of multilink sequencing.

2 - Restart Timer

The Restart Timer option specifies the time between retransmissions of Configure Request or Terminate Request packets. When attempting to establish a PPP link connection, if the Restart Timer expires before a response is received for a Configure Request, another Configure Request will be sent.

Default: [3000 msec]

Range: 50 to 20000 msec

3 - Configure Count

The Configure Count option specifies the number of Configure Request packets that will be sent without receiving a valid Configure Ack, Configure Nak, or Configure Reject packet. If a valid response packet is not received within the count specified, it is assumed that the peer PPP router is unable to respond.

Default: [10]

Range: 1 to 100

4 - Failure Count

The Failure Count option specifies the number of Configure Nak packets that will be sent without sending a Configure Ack before assuming that the configurations requested are not converging. A Configure Nak packet is sent when one of the PPP routers wishes to negotiate the particular LCP parameter to be a different value than the one proposed by the initiating PPP router.

Default: [5]

Range: 1 to 100

5 - Terminate Count

The Terminate Count option specifies the number of Terminate Request packets that will be sent without receiving a Terminate Ack before assuming that the peer PPP router is unable to respond.

Default: [2]

Range: 1 to 10

Advanced PPP Set-Up Menu

ADVANCED PPP SET-UP MENU		
Option	Value	Description
1. ACFC	[enabled]	- Address/control field compression
2. PFC	[disabled]	- Protocol field compression
3. Echo monitoring	[enabled]	- Allow echo monitoring of link
4. Quality protocol	[disabled]	- Set quality protocol
5. Quality interval	[10 sec]	- Set quality interval
6. MP encapsulation	[enabled]	- Use MP headers for NCP negotiation
7. MP sequencing	[normal]	- Set multilink sequence numbers
8. MP discriminator	[MAC_address]	- Set multilink endpoint discriminator
9. MP minimum	[50]	- Set minimum fragmentation size

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **ADVANCED PPP SET-UP MENU** provides for more advanced PPP circuit parameter set-up. The parameters configurable from this menu are used during LCP (Link Control Protocol) negotiations with a remote site PPP router. This IOLINK SOHO PPP router will request the configuration parameters defined here when initiating a PPP connection to a remote site PPP router.

When negotiating the LCP parameters for incoming PPP connections initiated by the remote site PPP router, this IOLINK SOHO will use these values as defaults but will accept a request for different values from the remote site PPP router.

If any of these LCP configuration parameters are required to be of a known value for a particular PPP connection, the parameters should be set to the same values on the routers on each end of the PPP link.

1 - ACFC

The ACFC (Address/Control Field Compression) option determines if this IOLINK SOHO PPP router will request Address and Control Field Compression on the link that is established to the peer PPP router.

Default: [enabled]

2 - PFC

The PFC (Protocol Field Compression) option determines if this IOLINK SOHO PPP router will request Protocol Field Compression on the link that is established to the peer PPP router.

Default: [disabled]

3 - Echo Monitoring

The Echo Monitoring option determines if this IOLINK SOHO PPP router will generate Echo-Request messages on the link that is established to the peer PPP router. Echo monitoring is used to help debug a link and verify data transmission. A change to the Echo Monitoring state will take effect the next time the link starts.

Default: [enabled]

4 - Quality Protocol

The Quality Protocol option determines if this IOLINK SOHO PPP router will request Link Quality Protocol monitoring on the link that is established to the peer PPP router.

Default: [disabled]

5 - Quality Interval

The Quality Interval option specifies the time interval between Link Quality Report packets that are generated and sent to the peer PPP router.

Default: [10 sec]

Range: 1 to 60 seconds

6 - MP Encapsulation

The MP Encapsulation option when set to enabled, specifies that the NCP negotiation messages are encapsulated within the Multilink header. When set to disabled, the NCP messages are not encapsulated within the Multilink frames.

Default: [enabled]

7 - MP Sequencing

The MP Sequencing option specifies the size of the Multilink sequencing number used in the Multilink header during frame transmission. A setting of normal will use a 4 byte sequencing number and a setting of short will use a 2 byte sequencing number.

Default: [normal]

Choices: normal, short

Considerations:

When connecting to a Combinet PPP device, the MP Sequencing should always be set to short.

8 - MP Discriminator

The MP Discriminator option specifies the type of identification used to identify this IOLINK SOHO PPP router during a Multilink connection. The MP Discriminator allows the remote site PPP router to uniquely identify this Multilink link when it requests establishment.

Default: [MAC_address]

Choices: MAC_address, IP_address, directory_number

9 - MP Minimum

The MP Minimum option specifies the minimum size of PPP frame that will not be fragmented when sent to the remote site PPP router. PPP frames equal or larger than this value will be fragmented across the links in a Multilink connection. A value of zero causes all inter-router frames to be fragmented.

Default: [50]

Range: 0 to 1600

IP Address Connect Menu

IP ADDRESS CONNECT MENU		
Option	Value	Description
1. Edit IP address entry		- Modify/add IP address entry
2. IP address connect	[disabled]	- Activate IP address connect
3. Show IP address entries		- Display IP address entries
4. Remove IP address entry		- Delete IP address entry

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IP ADDRESS CONNECT MENU** allows the display and configuration of the IP Address Connect table entries. IP Address Connect is used to establish ISDN calls to specific remote sites based on specific destination IP addresses.

1 - Edit IP Address Entry

The Edit IP Address Entry option allows the definition of an entry in the IP Address Connect table. The IP Address connect table allows this IOLINK SOHO to establish a PPP ISDN call to a specific remote site PPP router when IP traffic destined for a specific IP network is received from the local LAN. The IP addresses in the table are searched sequentially according to entry id number.

An entry of the IP address 0.0.0.0 causes any IP traffic to initiate a call to the specified remote site. Adding one of these default entries to the end of the table, e.g. id number 128, causes all IP traffic for destinations not listed in the address connect table to be sent to this default entry. Having this default entry at the end of the table causes all other entries to be checked first and then the remaining IP traffic will cause a connection to this default remote site.

To change any of the values of an entry that already exists, simply re-enter the values and substitute the new values where appropriate.

```
Enter :
  Set the IP address connect entry id (from 1 to 128)
>
Enter :
  Set the IP Address (up to 15 characters)
>
Enter :
  Size of subnet mask (from 1 to 32)
>
Enter :
  Remote site alias or id (up to 16 characters), none
```

Menus Reference Manual: IP Address Connect Menu

2 - IP Address Connect

The IP Address Connect option enables or disables the IP Address connect operation of the router. When IP Address Connect is enabled, all IP traffic on the local LAN is checked against the IP routing table. If the IP address is not present in the IP routing table, the address is checked in the IP Address Connect table.

Default: [disabled]

3 - Show IP Address Entries

The Show IP Address Entries option displays all of the IP addresses and their corresponding remote site profile alias currently in the IP Address connect table. There may be up to 128 IP network addresses defined in the table.

ID	IP Address	Subnet Mask Size	Subnet Mask	Remote Site
1	12.12.12.12	1	128.0.0.0	Vancouver

Type: [s] to redraw, [=] main menu, any other key to end.

ID: Entry number in the IP Address Connect table.

IP Address: Network IP address of the remote network or device.

Subnet Mask Size: IP address mask size defined

Subnet Mask: IP address mask created from the mask size defined. The mask is used to allow all IP addresses of a destination IP network to apply to the Address connect function.

Remote Site: Remote site profile entry to be used to call a remote partner IOLINK SOHO when IP traffic destined for the IP address is seen on the local LAN.

4 - Remove IP Address Entry

The Remove IP Address Entry option allows you to remove a selected IP Address Connect entry from the database. The entries may be removed individually by using the index number or all at once.

```
Enter :  
    all, id  
>
```

Bridging Set-Up Menu

BRIDGING SET-UP MENU		
Option	Value	Description
1. Spanning tree	menu	- Configure STP communications
2. Bridge forwarding	[enabled]	- Enable/disable bridge forwarding
3. Bridge aging timer	[300 sec]	- Set MAC address aging interval
4. Show bridging table		- View MAC address table
5. Show permanent table		- View permanent addresses only
6. Clear bridging table		- Delete all non-permanent entries

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **BRIDGING SET-UP MENU** provides access to management of the bridge/router frame-routing functions. These include Spanning Tree settings, management of the address tables, and adjustment of the aging timer.

1 - Spanning Tree

The Spanning Tree option directs you to the Spanning Tree Menu, where parameters of the Spanning Tree Protocol for this bridge are set and viewed.

2 - Bridge Forwarding

The Bridge Forwarding option enables or disables the frame forwarding operation of the bridge.

Default: [enabled]

3 - Bridge Aging Timer

The Bridge Aging Timer option sets the interval after which unused, non-permanent entries are removed from the address table.

Default: [300 sec]

Range: off (disabled), 10 to 1,000,000 seconds.

Considerations:

Increasing the value of the bridge aging timer will remove unused entries less frequently. This will offer an increase in bridge performance, as the table will not be rebuilt as often when stations come on and off the LAN.

Decreasing the bridge aging timer will remove unused entries more frequently. This will cause the table to be rebuilt more often, which may, depending on the size of the network, consequently decrease bridge performance.

Balancing the bridge aging timer according to the size of the local LAN and the frequency of station usage and moves can assist in optimizing bridge performance. If a closely managed topology remains stable with high usage and few station additions or moves, it could be advantageous to initially let the bridge learn all station addresses and then increase or disable the aging timer. When a station addition/deletion or move occurs, the new location can be manually added to the table or the timer value can be temporarily reduced to learn the new change(s). In any case, learning never stops, and the new/moved station will be learned and added to the address table when encountered.

4 - Show Bridging Table

The Show Bridging Table option displays all addresses in the Bridge Filter Table, identifies the active/inactive and permanent/non-permanent addresses, identifies addresses to be filtered if they are a source and/or destination, describes their location, and gives the total number of address table entries.

ALL Known MAC Addresses						
Total entries : 20						
Address	Active	Perm	Filter If		WAN	Access Location
			Src	Dest		
Start of table						
01-80-c2-00-00-01						Internal
01-80-c2-00-00-02						Internal
01-80-c2-00-00-03						Internal
01-80-c2-00-00-04						Internal
01-80-c2-00-00-05						Internal
01-80-c2-00-00-06						Internal
01-80-c2-00-00-07						Internal
01-80-c2-00-00-08						Internal
01-80-c2-00-00-09						Internal
01-80-c2-00-00-0a						Internal
01-80-c2-00-00-0b						Internal
01-80-c2-00-00-0c						Internal
01-80-c2-00-00-0d						Internal
01-80-c2-00-00-0e						Internal
01-80-c2-00-00-0f						Internal
02-44-00-c8-9a-ff	*	*			*	LAN050607
02-44-00-c8-9a-ee	*				*	LAN050607
12-34-56-78-99-99	*	*	*	*		LAN050607(fixed)
11-11-11-11-11-11				*		unknown
ff-ff-ff-ff-ff-ff						Internal
end of table						

Address

The sixteen addresses **01-80-c2-00-00-01** to **01-80-c2-00-00-0f** are reserved for future use in the 802.1d standard.

The address (**ff-ff-ff-ff-ff-ff**) is a permanent address that, in its default state (unknown), will not filter any frames. Only one choice Filter if Destination is available for this broadcast address. If applied, this will prevent broadcast frames from being put onto the LAN the bridge is connected to.

The address (**12-34-56-78-99-99**) is an active, permanent address that resides on LAN050607 (in this example, this is the LAN the bridge is attached to). Frames to and from this address will not cross the bridge, since they are identified as both filter-if-destination and filter-if-source. The (fixed) descriptor is added when the location of the address has been identified by management action.

The address (**11-11-11-11-11-11**) is an inactive, permanent address with a currently unknown location. Frames to this address will not cross the bridge, since they are identified as filter-if-destination. Note that this address should be made permanent, because if it is not encountered within the aging-timer interval it will be removed from the table.

The address (**02-44-00-c8-9a-ff**) is an active, permanent address that resides on LAN050607 and is allowed to transmit data on the ISDN WAN connection. This address is marked permanent because the operator enabled the permanent option within the Edit MAC Address menu of the MAC Address Filters menu.

The address (**02-44-00-c8-9a-ee**) is an active address that resides on LAN050607 and is allowed to transmit data on the ISDN WAN connection. Since this address is marked as having WAN access but not marked as permanent, this indicates that this address has been learned from the local LAN and assigned to have WAN access because it was one of the first 10 addresses encountered.

Active

A * in the Active column indicates the address is active. An address is considered active if it has been encountered within the aging-timer interval. Permanent addresses are not subject to the aging timer, but will be reported as active if they are encountered.

Perm

A * in the Perm column indicates the address is permanent. An address is considered permanent if it has been identified as such by the bridge manager. Permanent addresses are not subject to the aging timer, but will be reported as active if they are encountered.

Filter if Src

This indicates that a bridge/router manager has specified that frames having this source address will be filtered.

Filter if Dest

This indicates that a bridge/router manager has specified that frames having this destination address will be filtered.

Filter if Src / Dest

This indicates that a bridge/router manager has specified that frames having this source or destination address will be filtered. (This station can neither send data across the bridge/router, nor receive data from across the bridge/router.)

WAN Access

This indicates that the LAN device with this MAC address is allowed to pass data over the ISDN WAN connection to the remote site.

Location

Internal

These are the STP Multicast and LAN port MAC addresses located (internal) to the bridge/router itself. Note that the bridge/router's MAC address is used for the default bridge/router and LAN names. Partner bridge/routers MAC addresses will also be listed as internal. Internal addresses are not subject to the aging timer, but will be reported as active if they are encountered.

LANxxxxxx (unknown)

These addresses are identified as to their location on a specific LAN, or as an (unknown) location. Their LAN location is identified either by manual entry or through the Learning Process when encountered.

5 - Show Permanent Table

The Show Permanent Table option displays all of the permanent filter-table addresses entered by the bridge/router manager for which the locations were identified (Internal addresses are not displayed.) The (fixed) Location descriptor indicates that a manager made the entry and specified the LAN location.

Operator Defined MAC Addresses						
Address	Filter if WAN				Access	Location
	Active	Perm	Src	Dest		
Start of table						
02-44-00-c8-9a-ff	*	*			*	LAN050607
12-34-56-78-99-99	*	*	*	*		LAN050607(fixed)
End of table						

6 - Clear Bridging Table

The Clear Bridging Table option removes all non-permanent filter table addresses.

Considerations:

To prevent accidental removal of all non-permanent addresses, this option must be confirmed by entering `yes` at the prompt. (Refuse by entering `no` or use the TAB key to back out).

Spanning Tree Menu

SPANNING TREE MENU		
Option	Value	Description
1. LAN port	menu	- Define port specific options
2. STP state	[enabled]	- Enable/disable Spanning Tree Protocol
3. Bridge priority	[32768]	- Define root bridge selection priority
4. Forwarding delay	[15 sec]	- Set delay before forwarding begins
5. Message age timer	[20 sec]	- Receive hello message interval
6. Hello time	[2 sec]	- Set hello message transmission interval
7. Show bridge		- View bridge STP status
8. Show ports		- View STP port status

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **SPANNING TREE MENU** allows the management and display of the 802.1D Spanning Tree Protocol (STP) parameters.

1 - LAN Port

The LAN Port option directs you to the LAN Port Menu where STP Port parameters are set.

Note: For remote bridge/routers in a WAN, the following values set on one bridge/router will be automatically set the same on all other remote bridge/routers in the WAN. (This is because all remote bridge/routers function together as one unified bridge).

STP state	Option 2
Bridge Priority	Option 3
Forwarding delay	Option 4
Message age timer	Option 5
Hello time	Option 6

If these values are set differently upon start-up, the values set on the bridge/router with the lowest MAC address will prevail.

2 - STP State

The STP State option toggles between the [enabled] / [disabled] states of the Spanning Tree Protocol for the bridge.

Considerations:

STP needs to be [enabled] only if a known or potential loop is probable in the network.

If the Spanning Tree Protocol is to be [disabled], Options 1, 3, and 5 - 8 have no relevance. Note that Option 4 (Forwarding Delay) is used as the Learning timer in a non-STP configuration.

The default state for STP is **disabled**.

3 - Bridge Priority

The Bridge Priority option specifies the bridge's priority for becoming the *Root Bridge*. The bridge with the lowest bridge priority is elected to be the Root Bridge.

Default: [32768] * (IEEE 802.1D recommendation)

Range: 0 to 65535

Considerations:

*** This value is the first part of the Bridge ID For example: 32768-0000d0111111**

If you want the bridges to decide among themselves which is to be the Root bridge, then set all bridges' bridge priorities to the IEEE 802.1D default 32768. In this instance, with all bridge priorities being the same, the bridge with the lowest MAC address will be chosen as the Root Bridge.

Lower Value

If you want this bridge to become the Root Bridge, then set this number to be lower than the other bridges in the network.

Higher Value

If you want this bridge to become blocked (become the standby bridge where a redundant path exists), then set this number higher than the other bridge(s) competing to be the *designated bridge* for a LAN.

4 - Forwarding Delay

During a change in topology, the Forwarding Delay value specifies the time the bridge will wait in each of the *Listening* and *Learning States* before forwarding of frames begins.

In the *Listening State*, the bridge listens for the other bridges' topology and configuration information. (Non-permanent addresses are aged-out and cleared from the address table before the *Learning State* is entered.)

In the *Learning State*, the bridge learns the addresses of as many stations as possible, so when entering the *Forwarding State* it avoids flooding the network with packets destined for unknown addresses.

During the Listening and Learning State intervals, forwarding is blocked although during the Learning State, learned station information is included in the address table.

Default: [15 sec] (IEEE 802.1D recommendation)

Range: 4 to 30 seconds

Considerations:

The Forwarding Delay time of the bridge is applicable only if the bridge is, or becomes, the Root bridge, since the Root values override a non-root's Forwarding delay time value. The Root value is known as the Network Forward(ing) Delay.

Lower Value

If this bridge is the Root, or becomes the Root, setting the Forwarding Delay to a lower value might cause the network to flood with packets destined for addresses not yet learned. During the *Listening State*, the Root Bridge might also miss another bridge's information about a *Topology Change* if the Forwarding Delay is set too low.

Higher Value

Setting the value higher will increase the time spent in each of the *Listening and Learning States* when a reconfiguration is under way. A higher value will increase the time the network is unavailable for use during reconfiguration.

Recommendations:

The default value of 15 seconds is recommended by the IEEE 802.1D standard as a reasonable balance of performance. If a change is deemed necessary, increasing the value in consideration with Message (Max) Age is the recommended course of action.

The following relationship to Message (Max) Age must be maintained:

2 x (fwd_delay - 1.0) _ max_age default: 28 _ 20

5 - Message Age Timer

The Message Age Timer option specifies the length of time stored protocol information is considered valid. If a non-root bridge has not received protocol confirmation from the Root within this interval, it will broadcast to the other bridges that the topology has changed, and a reconfiguration calculation will be performed.

Default: [20 sec] (IEEE 802.1D recommendation)

Range: 6 to 40 seconds

Considerations:

The Maximum Age of the bridged network is set by the Root Bridge. If a reconfiguration of the bridged network occurs and this bridge becomes the Root, the value set at this bridge becomes the Network's value.

Lower Value

A much lowered Maximum Age value may cause more frequent reconfigurations of the bridged network (even if not necessary) if configuration information is delayed. A slightly lower value may trigger a reconfiguration more quickly should a bridge fail or a management action requests a change.

Higher Value

A higher Maximum Age value will allow more time for confirmation of the network configuration. This could be beneficial if delays are introduced and the network is frequently going down for unnecessary reconfigurations.

Recommendations:

The default value of 20 seconds is recommended by the IEEE 802.1D standard as a reasonable balance of performance. If a change is deemed necessary, increasing the value in consideration with Forwarding Delay and Hello Time is the recommended course of action.

The following relationship to Forwarding Delay must be maintained:

2 x (fwd_delay - 1.0) _ max_age default: 28 _ 20

The following relationship to Hello Time must be maintained:

Max Age _ 2x (Hello Time + 1.0) default: 20 _ 6

6 - Hello Time

The Hello Time option specifies the interval between the transmission of protocol configuration information by a bridge that is, or is attempting to become, the Root. In the Spanning Tree Protocol, only one bridge can be the Root Bridge. The Root Bridge generates a Configuration message after an interval set by this timer. (The Root is saying, Hello, I m still here .) All other bridges in the network wait for this Configuration message within the Network Hello Time to confirm that the topology is stable. If any bridge does not receive the Configuration message within the expected time, it will send out Topology Change messages to the other bridges in order to calculate a new configuration.

Default: [2 sec] (IEEE 802.1D recommendation)

Range: 1 to 10 seconds

Considerations:

This value is not directly used in configuration calculations but the bridged network uses the value set at the Root Bridge. (I.e. Network Hello Time).

Lower Value

Reducing this value increases the frequency of Configuration messages on the network, potentially creating excessive network traffic.

Higher Value

A higher value results in a slower response to a change in the topology of the network (e.g. addition/deletion/failure of bridges or communications paths).

Recommendations:

The default value of 2 seconds is recommended by the IEEE 802.1D standard as a reasonable balance of performance. If a change is deemed necessary, increasing the value in small steps is the recommended action.

The following relationship to Max Age must be maintained:

Max Age _ 2 x (Hello Time + 1.0) default: 20 _ 6

7 - Show Bridge

The Show Bridge option displays the Spanning Tree Protocol status of the bridge. The display of a Root bridge is shown below:

```
Bridge Status
Spanning Tree Protocol : Enabled
Bridge ID               : 32768-0000d0010101
Topology change        : 0
Designated Root        : 32768-0000d0010101
Root path cost         : 0
Root port              : None
Network Forward delay  : 15 seconds
Network Max age        : 20 seconds
Network Hello time     : 2 seconds
Bridge Forward delay   : 15 seconds
Bridge Max age         : 20 seconds
Bridge Hello time      : 2 seconds
```

Spanning Tree Protocol : Enabled

Indicates whether the Spanning Tree Protocol is Enabled or Disabled.

Bridge ID : 32768-0000d0010101
Designated Root : 32768-0000d0010101

The first part of each string indicates the (default) decimal Bridge Priority (32768). Refer to Option 4.

The remaining part of the string is the MAC address of the bridge and of the Root Bridge respectively.

If the Bridge ID string is identical to the Designated Root (bridge) string, then this bridge is the Root Bridge.

The Designated Root is the bridge sending/receiving frames to/from the attached LAN towards the Root Bridge.

Topology change : 0

If the topology is stable, this value is 0.
If the topology is changing, this value is 1.

Root path cost : 0
Root port : None

If this bridge is the Root Bridge, the Root path cost is 0 and the Root port value is None, as shown in the above display.

If this bridge is a non-root bridge, the cost is determined by the sum of this bridge's path costs leading to the Root Bridge.

The Root port of a non-root bridge is the port closest to the Root Bridge. It sends and receives protocol messages to/from the bridge and the Root Bridge. If this bridge is not the Root Bridge, the Root Port value will be in the format 0x8001. The 0x is an indicator that the values to follow are in hex. Following the 0x is the hex value of the decimal Port priority. (The default Port priority of decimal 128 yields a hex value of 80.) Following the hex value is the port number (01). Default port priority values therefore yield a Root port value of 0x8001.

Menus Reference Manual: Spanning Tree Menu

Network Forward delay : 15 seconds **
Network Max age : 20 seconds **
Network Hello time : 2 seconds **

Bridge Forward delay : 15 seconds *
Bridge Max age : 20 seconds *
Bridge Hello time : 2 seconds *

* These parameters are defined at each bridge with Options 4, 5, and 6.

** These parameters are defined by the Root bridge.

*** If this bridge is the Root bridge, corresponding parameters will be the same. If it is not the Root Bridge, these values may differ. (It is very possible that these values can be the same if this is not the Root Bridge, since these are the values recommended by the IEEE 802.1D standard. Check and compare the Bridge ID to the Root ID for confirmation of the Root.)

8 - Show Ports

The Show Ports option displays the status of this bridge's STP ports.

Port Status Summary									
Name	State	Id	Pri	Cost	Designated Bridge Address	Pri	Designated Port Id	Pri	Cost
LAN	Forward	1	128	100	Self		Self		
SITE2	Forward	44	128	100	020304050607	32768	44	128	0

Name

The **Name** column shows either the name of the STP port. LAN for the local LAN, or the remote site profile alias name for a properly connected remote site device.

State

The **State** column indicates the current port states that may be Disabled (by management action); or either Listen(ing), Learn(ing), Forward(ing) or Block(ing) (by STP action).

ID

In the above display, there are two indicators of the LAN port identifying numbers. They are found under the **ID** columns. They may not fall in order, as the listing is based on the MAC address of each bridge.

Cost

The **Cost** columns indicate the contributing cost of each port's path to the Root Path Cost.

Designated Bridge

If `self` is listed, then the bridge is the designated bridge for the LAN it is attached to.

Address

This is the MAC address for the designated bridge attached to the specified LAN.

Priority

This is the port priority given to the designated bridge.

Designated Port

ID

This is the Port ID number.

Priority

This is the priority of the Designated Port.

Cost

If this is the Root Port, the priority is 0.

LAN Port Menu

LAN PORT MENU		
Option	Value	Description
1. State	[enabled]	- Enable/disable LAN port
2. Path cost	[100]	- Define network cost for port
3. Priority	[128]	- Set port priority

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **LAN PORT MENU** allows the management of the port's state, path cost, and priority.

1 - State

The State option toggles between Enabling and Disabling of the Spanning Tree Protocol for the LAN port.

Considerations:

When the port is [enabled] the states are reported as either Listen(ing), Learn(ing), Forward(ing) or Block(ing). If the port is disconnected, Disabled is shown in the Show Ports display (even if the state is enabled).

When the port is [disabled], it does not participate in the learning process. Also, when [disabled] the port is not included in the STP topology calculations and will not be activated by the STP should it be needed to take over from a failed bridge.

2 - Path Cost

The Path Cost option allows the setting of the contributing path cost to the Root for this port.

Contribution of Path Cost to Root Path Cost:

The path cost to the Root Bridge is added to those path costs of other bridges along the same stream to the Root Bridge. The result is the Root Path Cost.

Once the Root Bridge is selected, a determination of which bridge(s) will become blocked where necessary is made. This determination is made by comparing the sum of the path costs (i.e. the Root Path Cost) to the Root Bridge. Where redundant paths exist, the bridge with the lowest Root Path Cost to the Root Bridge will become the *Designated Bridge* for the LAN. If all contending bridges ports have the same Root Path Costs, then first their Bridge IDs (Priority/MAC address) and second their Port IDs (Port Priority) will be used as tiebreakers.

Default: [100]

Range: 1 to 65535

Considerations:

Increasing this value increases the total cost of the path to the Root Bridge. This may (depending on the topology) cause a bridge along the path to the Root bridge to be taken out of service and a blocked bridge to come into service.

Decreasing the value may have the opposite effect.

3 - Priority

The Priority option allows the setting of the port priority. This value is entered in decimal format and appears in hex format in the Port ID/Designated Port identifier (as applicable) of the Port Status display.

Default: [128] (decimal)

Range: 0 - 255

Considerations:

Increasing this value lowers the probability of this port becoming the Root port to the Root bridge. Decreasing this value increases the probability.

IP Routing Set-Up Menu

IP ROUTING SET-UP MENU		
Option	Value	Description
1. IP routes	menu	- Modify/view routes
2. IP routing	[enabled]	- Enable/disable IP router
3. IP forwarding	[enabled]	- Enable/disable IP routing
4. LAN routing protocol	[ripl_compatible]	- Define routing protocol
5. LAN RIP mode	[both]	- Define RIP send/receive mode
6. LAN route cost	[0]	- Cost added to route learned
7. ARP proxy	[disabled]	- Support proxy-ARP

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IP ROUTING SET-UP MENU** allows the display and configuration of the IP Routing parameters for the router.

1 - IP Routes

The IP Routes option directs you to the IP Routes Menu, where the routing tables are displayed and changed.

2 - IP Routing

The IP Routing option enables or disables the IP routing functions of the router.

Default: [enabled]

Considerations:

When IP Routing is disabled, all learned RIP routes will be cleared from the routing table.

3 - IP Forwarding

The IP Forwarding option enables or disables the forwarding of IP traffic when IP routing is enabled. When the IP forwarding option is disabled, IP traffic across the WAN links will be blocked

Default: [enabled]

4 - LAN Routing Protocol

The LAN Routing Protocol option defines the type of IP routing protocol to be used on the LAN interface. The IOLINK SOHO may be set up to use different types of IP routing protocols on each of its interfaces: LAN and links.

When the routing protocol is defined as none, the IOLINK SOHO will operate as an IP router but will NOT participate in the exchange of RIP messages between the other IP routers in the network. All IP routing is accomplished by using the static routes table. All routes within the network must be manually entered in the static routing table.

When the routing protocol is defined as rip1, the IOLINK SOHO will operate as a RIP1 IP router. All routing information will be sent and received via broadcast RIP packets.

When the routing protocol is defined as rip1_compatible, the IOLINK SOHO will operate as a RIP2 IP router in broadcast mode. All routing information will be sent via broadcast RIP2 packets. Routing information may be received as broadcast RIP1, broadcast RIP2, or multicast RIP2.

When the routing protocol is defined as rip2, the IOLINK SOHO will operate as a RIP2 IP router. All routing information will be sent via multiast RIP2 packets. Routing information may be received as broadcast RIP2 or multicast RIP2.

Default: [rip1_compatible]

Choices: none, rip1, rip1_compatible, rip2

5 - LAN RIP Mode

The LAN RIP Mode option defines how this IOLINK SOHO will participate in RIP IP routing messages on the LAN.

When the RIP mode is set to both, the IOLINK SOHO will send and receive RIP routing messages on the LAN.

When the RIP mode is set to send_only, the IOLINK SOHO will only send RIP routing messages on the LAN.

When the RIP mode is set to receive_only, the IOLINK SOHO will only receive RIP routing messages on the LAN.

Default: [both]

Choices: both, send_only, receive_only

6 - LAN Route Cost

The LAN Route Cost option defines the amount of extra routing cost to add to routes learned from the LAN.

Default: [0]

7 - ARP Proxy

The IOLINK SOHO Ethernet router will respond to ARP requests destined for other networks, from its local network, when this option is enabled. The IOLINK SOHO will reply to any matching route in the routing table. The IOLINK SOHO will also reply for a station that is supposed to be on the local LAN but is connected through a remote route in the routing table.

Default: [disabled]

IP Routes Menu

```

                                IP ROUTES MENU

Option                          Value      Description
1. Edit route                    menu      - Modify a route in the table
2. Show all routes                -         - Display the route table
3. Show static routes            -         - Display only static routes
4. Clear static routes            -         - Remove all permanent entries

Enter option number, "=" - main menu, <TAB> - previous menu
>
```

The **IP ROUTES MENU** allows the display and configuration of the routing tables.

1 - Edit Route

The Edit Route option directs you to the Edit Route Menu where the routing tables are modified.

2 - Show All Routes

The Show All Routes option displays all of the routes currently in use by the router. The table is sorted by destination IP address. The default gateway, either learned or defined, will be displayed as default route.

There is a maximum of 512 route entries allowed in the table.

```

                                All IP Routes
Total entries : 0 R: al 0, fr 512, tot 512  N: al 0, fr 1024, tot 1024

Destination      Mask      Next Hop      Interface      Route
IP Address       Size      IP Address    Up / Identifier Cost  Age  Type
-----
--Start of table--
5.5.5.0          24      5.5.5.1      * LAN.1        1      0  DIRECT
5.5.5.1          32      5.5.5.1      * LAN.1        1      0  DIRECT
192.168.12.0     24      192.168.12.1 * LAN          1      0  DIRECT
192.168.12.1     32      192.168.12.1 * INTERNAL     1      0  DIRECT
192.168.15.1     32      192.168.15.1 * RS2          2      0  CONNECT
192.168.84.0     24      192.168.84.1 RS4            2      0  CONNECT
192.168.84.1     32      192.168.84.1 RS4            2      0  CONNECT
198.169.1.150   32      198.169.1.150 RS5            2      0  CONNECT
--End of table--
```

Destination IP Address: Network IP address of the remote network. Routes listed with a "+" indicate that these are secondary routes to the same destination network. If the main route goes away, the secondary route will be used.

Mask Size: Subnet mask size defined for the route.

Menus Reference Manual: IP Routes Menu

Next Hop IP Address:	IP address of the next hop router to use to reach the Destination IP Address.
Interface Up	An asterisk will be displayed if this route is up.
Interface Identifier	RS followed by a number indicates the Remote site profile ID number that this route is currently using. LAN indicates that this route is on the local LAN. A decimal point and number following the LAN indicates that this is a secondary network. INTERNAL indicates that this is the IP address of a port on this device
Cost:	Number of hops to reach the Destination IP Address.
Age:	Actual cost to reach the Destination IP Address. Triggered RIP routes will be indicated as RIP routes with a constant age of 0.
Route Type:	Type of route used: RIP, LOCAL, CONNECT, DIRECT, or OTHER. LOCAL is used for static routes. CONNECT indicates the route is on a connected peer IP router on an unnumbered link. DIRECT indicates that the route is directly connected to one of the interfaces. This could also indicate the peer IP router of a numbered link.

3 - Show Static Routes

The Show Static Routes option displays all of the static routes currently in use by the router.

Static IP Routes						
Destination IP Address	Mask Size	Next Hop IP Address	Interface Up / Identifier	Cost	Age	Route Type
--Start of table--						
5.5.5.0	24	5.5.5.1	* LAN.1	1	0	DIRECT
5.5.5.1	32	5.5.5.1	* LAN.1	1	0	DIRECT
192.168.12.0	24	192.168.12.1	* LAN	1	0	DIRECT
192.168.12.1	32	192.168.12.1	* INTERNAL	1	0	DIRECT
192.168.15.1	32	192.168.15.1	* RS2	2	0	CONNECT
192.168.84.0	24	192.168.84.1	* RS4	2	0	CONNECT
192.168.84.1	32	192.168.84.1	* RS4	2	0	CONNECT
198.169.1.150	32	198.169.1.150	* RS5	2	0	CONNECT
--End of table--						

4 - Clear Static Routes

The Clear Static Routes option clears all of the static routes from the routing table.

Note: any Default Gateway static routes that were automatically created will be deleted by this operation. A warning will be displayed if there was a default gateway defined in the static routing table.

Edit Route Menu

```

                                EDIT ROUTE MENU

  Option      Value      Description
  1. Network mask * [      ] - The network mask for the route
  2. Status    * [      ] - Is the address in the table
  3. Remote site * [      ] - Remote site alias of the next hop
  4. Next hop  * [      ] - IP address of the next hop
  5. Type      * [      ] - Type of route
  6. Cost      [      ] - Cost to reach destination in hops
  7. Private   [      ] - Do not advertise route
  8. Remove

Enter:
  destination IP address (up to 15 characters)

> 192.3.44.0
```

The above display is the first level of the **EDIT ROUTE MENU**. The destination network IP address must be entered as well as the subnet mask size associated with the destination IP address. Once the destination network IP address and mask size have been entered, the next hop IP address or remote site ID/alias must be entered.

The menu title will change to indicate the destination IP network address and the subnet size that are being edited.

```

                                EDIT ROUTE 192.3.44.0 / 24 199.2.5.12 MENU

  Option      Value      Description
  1. Network mask * "255.255.255.0" - The network mask for the route
  2. Status    * "Added"   - Is the address in the table
  3. Remote site * "none"    - Remote site alias of the next hop
  4. Next hop  * "199.2.5.12" - IP address of the next hop
  5. Type      * "LOCAL"   - Type of route
  6. Cost      [1]       - Cost to reach destination in hops
  7. Private   [disabled] - Do not advertise route
  8. Remove

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

NOTE: A Static Route will **NOT** be replaced with a RIP route, even if the cost is lower.

1 - Network Mask

The subnet mask for the destination IP network is calculated from the entered destination IP network address and the subnet size value. The resulting subnet mask is displayed here.

2 - Status

The Status option tells whether the address is `Present` or `Not Present` in the Routing Table. When the address is first entered, `Added` is the Status value. The * beside the value indicates that this value is changed automatically as an address is added or deleted and cannot be manually redefined.

Default: * [Not Present]

3 - Remote Site

The Remote Site option defines the remote site profile ID or alias of the remote site router to be used to reach the destination IP address.

4 - Next Hop

The Next Hop option defines the IP address of the next-hop router to be used to reach the destination IP address.

5 - Type

The Type option displays the type of route. The route type may be either `RIP` or `LOCAL`. `RIP` is a learned route from the RIP updates on the network. `LOCAL` is a static route entered by the operator of the router.

6 - Cost

The Cost option defines the number of hops required to reach the destination IP address.

Default: [1]

Range: 1 - 15

7 - Private

The Private option when set to enabled causes the IOLINK SOHO to not advertise this route in the RIP messages.

Default: [disabled]

8 - Remove

The Remove option removes the IP address from the routing table. If the route is a `RIP` route, the route may be re-learned by the next `RIP` route update from partner routers.

IPX Routing Set-Up Menu

IPX ROUTING SET-UP MENU		
Option	Value	Description
1. Static routes	menu	- Edit/display static routes
2. Static services	menu	- Edit/display static services
3. Configure LAN networks	menu	- Configure LAN network numbers
4. IPX routing	[enabled]	- Enable/disable IPX router
5. IPX forwarding	[enabled]	- Enable/disable IPX routing
6. Local networks		- Display local network connections.
7. Show routes		- Display the route table
8. Show services		- Display the service table
9. Help		- Description of IPX routing

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IPX ROUTING SET-UP MENU** allows the display and configuration of the IPX Routing parameters for the router.

1 - Static Routes

The Static Routes option directs you to the Static Routes Menu, where user defined IPX static routes are maintained.

2 - Static Services

The Static Services option directs you to the Static Services Menu, where user defined IPX static services are maintained.

3 - Configure LAN Networks

The Configure LAN Networks option directs you to the Configure LAN Networks Menu, where network numbers may be assigned for the four frame types supported by this router.

4 - IPX Routing

The IPX Routing option enables or disables the IPX routing functions of the router.

Default: [enabled]

Considerations:

Routing information (RIP) will only be transmitted across the WAN to the partner router according to the state of the IPX DMR Enabled option within the IPX Parameters menu of the remote site profile used to establish a PPP connection. If demand RIP is enabled, RIP messages will only be transmitted when there is a change.

When IPX Routing is disabled, all learned RIP routes will be cleared from the routing table.

5 - IPX Forwarding

The IPX Forwarding option enables or disables the forwarding of IPX traffic when IPX routing is enabled. When the IPX forwarding option is disabled, IPX traffic across the WAN links will be blocked

Default: [enabled]

Considerations:

When IPX Forwarding is disabled all learned RIP routes will be cleared from the routing table.

6 - Local Networks

The Local Networks option displays all of the IPX network numbers currently in use by the router on each of its interfaces.

LOCAL IPX NETWORKS	
LAN Interface:	
Ethernet II	51524
Raw 802.3	0
IEEE 802.2	0
802.2 Snap	0
WAN Interface:	
SITE2	14526

7 - Show Routes

The Show Routes option displays all of the learned IPX routes currently in use by the router.

There is a maximum of 512 route entries allowed in the table.

IPX Routes				
Total entries : 7				
Network	Interface	Next Hop	Hops	Ticks
51524	local	local	0	1
126	lan	205204239749	2	50
14526	SITE2	992400423941	2	50

Network: IPX Network Address of the remote network.

Interface: Interface that the IPX network is located on; either local, LAN or remote site router.

Next Hop: IPX address of the next-hop router to use to reach the Destination IPX Network.

Hops: Number of hops to reach the Destination IPX Network.

Ticks: Number of ticks to reach the Destination IPX Network.

Considerations:

A 9600-bps link on this router has a tick value of 5.

Menus Reference Manual: IPX Routing Set-Up Menu

8 - Show Services

The Show Services option displays all of the Servers currently seen by the router. The Services table is created from information received by this router in SAP (Server Advertising Protocol) packets generated by Novell Servers.

There is a maximum of 512 server entries allowed in the table.

IPX Services			
Total entries : 3			
Type	Server Address	Hops	Server Name
0004	00000311:0000ff3a4001:0451	2	SQA_SERVER_311
0004	00000312:00004ac38445:0451	6	NOVELL312
0004	00000401:000e03448a32:0451	2	NOVELL_401

Type: Novell Server types. Some possible Server types are:

Unknown	0
Print Queue	3
File Server	4
Job Server	5
Print Server	7
Archive Server	9
Remote Bridge Server	24
Advertising Print Server	47

Server Address: IPX address of the Server.

Hops: Number of hops to reach the Server from this router.

Server Name: Name of the Server.

9 - Help

The Help option offers a brief description of the IPX routing options.

Static IPX Routes Menu

```
                                STATIC ROUTES MENU

Option                           Value           Description
1. Edit route                     menu           - Modify a route in the table
2. Convert route                   - Make a learned route static
3. Show static routes              - Display static routes
4. Clear static routes             - Remove groups of static routes

Enter option number, "=" - main menu, <TAB> - previous menu
>
```

The **STATIC IPX ROUTES MENU** allows the display and configuration of the static IPX routing tables.

1 - Edit Route

The Edit Route option directs you to the Edit Route Menu where the static IPX routing table entries are modified. A maximum of 50 static IPX routes may be defined.

2 - Convert Route

The Convert Route option is used to convert one of the currently learned IPX routes into an IPX static route. Enter the IPX network number of the learned route when prompted and then enter a static route id number. The learned IPX route will become a static IPX route.

```
Enter:
  network number
>

Enter:
  static route entry id
>
```

3 - Show Static Routes

The Show Static Routes option displays all of the static IPX routes currently in use by the router.

IPX Static Routes					
Total entries : 2					
ID	Network	Interface	Next Hop	Hops	Ticks
1	00000012	lan	000000012345	1	1
2	00004143	SITE2	n/a	1	1

- ID: Entry number in the static IPX routes table.
- Network: IPX Network Address of the remote network.
- Interface: Interface that the IPX network is located on, either LAN or remote site router.
- Next Hop: IPX address of the next-hop router to use to reach the Destination IPX Network.
- Hops: Number of hops to reach the Destination IPX Network.
- Ticks: Number of ticks to reach the Destination IPX Network.

4 - Clear Static Routes

The Clear Static Routes option clears the specified static IPX routes from the routing table.

```
Enter:  
  all, lan, remote site id or alias (up to 16 characters)  
>
```

Edit Static IPX Route Menu

```
                                EDIT ROUTE MENU

  Option      Value      Description
  1. Status   * [      ] - Is entry in static route table
  2. Network  [      ] - Destination network number
  3. Interface [      ] - Interface to destination network
  4. Hops     [      ] - Hops to destination network
  5. Ticks    [      ] - Ticks to destination network

Enter:
      entry id (from 1 to 50)

> 1
```

The above display is the first level of the **EDIT ROUTE MENU**. The table id number must be entered to proceed to the next level.

The menu title will change to indicate the table id number that is being edited.

```
                                EDIT ROUTE 1 MENU

  Option      Value      Description
  1. Status   * "Not Present" - Is entry in static route table
  2. Network  "1"         - Destination network number
  3. Interface " "         - Interface to destination network
  4. Hops     [1]         - Hops to destination network
  5. Ticks    [1]         - Ticks to destination network

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

NOTE: A Static Route will **NOT** be replaced with a RIP route, even if the hop and tick count is lower.

1 - Status

The Status option tells whether the static route is Present or Not Present in the Routing Table. When the route entry is first entered, Not Present is the Status value. The * beside the value indicates that this value is changed automatically as an entry is added or deleted and cannot be manually redefined.

Default: * [Not Present]

2 - Network

The Network option defines the destination IPX network address of the static route.

3 - Interface

The Interface option defines the interface, either LAN or remote site device, that the destination IPX network is located on. A value of LAN indicates that another IPX router located on the locally connected LAN is to be used to access the destination IPX network. When the interface is set to LAN, the option Next Hop will be available to define the MAC address of the router located on the locally connected LAN.

A value of a remote site profile name or id indicates that the destination IPX network is located on the remote site IPX router. The Next Hop option is not required and therefore not available when a remote site profile is defined for the interface.

4 - Next Hop

The Next Hop option defines the MAC address of the next-hop IPX router on the locally connected LAN to be used to reach the destination IPX network. The next-hop router must be on the local IPX network.

5 - Hops

The Hops option defines the number of hops to reach the destination IPX network.

Default: [1]

Range: 1 - 15

6 - Ticks

The Ticks option defines the number of ticks to reach the destination IPX network.

Default: [1]

Range: 1 - 64000

7 - Remove

The Remove option removes the IPX static route from the routing table.

Static IPX Services Menu

STATIC SERVICES MENU		
Option	Value	Description
1. Edit service	menu	- Edit a static service
2. Convert service		- Make a learned service static
3. Show static services		- Display the service table
4. Clear static services		- Remove groups of static services

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **STATIC IPX SERVICES MENU** allows the display and configuration of the static IPX services.

1 - Edit Service

The Edit Service option directs you to the Edit Service Menu where the static IPX service entries are modified. A maximum of 50 static IPX services may be defined.

2 - Convert Service

The Convert Service option is used to convert one of the currently learned IPX services into an IPX static service. Enter the server name and service type of the learned service when prompted and then enter a static service id number. The learned IPX service will become a static IPX service.

```
Enter:
  server name
>

Enter:
  hex service type
>

Enter:
  static service entry id
>
```

3 - Show Static Services

The Show Static Services option displays all of the static IPX services currently in use by the router.

IPX Static Services					
Total entries : 2					
ID	Interface	Type	Server Address	Hops	Server Name
1	lan	0017	00000002:000000015223:0000	0	Mars

- ID: Entry number in the static IPX services table.
- Interface: Interface that the IPX service is located on, either LAN or remote site router.
- Type: Hex value of the type of IPX service.
- Server Address: IPX Address of the server.
- Hops: Number of hops to reach the server.
- Server Name: Name of the server.

4 - Clear Static Services

The Clear Static Services option clears the specified static IPX services from the table.

```
Enter:
  all, lan, remote site id or alias (up to 16 characters)
>
```

Edit Static IPX Service Menu

```
                                EDIT SERVICE MENU

  Option      Value      Description
  1. Status   * [      ] - Is entry in static route table
  2. Server name [      ] - Novell server name
  3. Service type [      ] - Novell service type
  4. Interface [      ] - Interface to service
  5. Network  [      ] - Server's network number
  6. Node     [      ] - Server's node number
  7. Socket   [      ] - Service's socket number
  8. Hops     [      ] - Hops to server

Enter:
  entry id (from 1 to 50)

> 1
```

The above display is the first level of the **EDIT SERVICE MENU**. The table id number must be entered to proceed to the next level.

The menu title will change to indicate the table id number that is being edited.

```
                                EDIT SERVICE 1 MENU

  Option      Value      Description
  1. Status   * "Not Present" - Is entry in static route table
  2. Server name " " - Novell server name
  3. Service type [1] - Novell service type
  4. Interface " " - Interface to service
  5. Network  "1" - Server's network number
  6. Node     "00-00-00-00-00-01" - Server's node number
  7. Socket   [0] - Service's socket number
  8. Hops     [1] - Hops to server

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

NOTE: A Static Service will **NOT** be replaced with a SAP learned service, even if the hop count is lower.

1 - Status

The Status option tells whether the static service is Present or Not Present in the Table. When the service entry is first entered, Not Present is the Status value. The * beside the value indicates that this value is changed automatically as an entry is added or deleted and cannot be manually redefined.

Default: * [Not Present]

2 - Server Name

The Server Name option defines the IPX server name of the static service.

3 - Service Type

The Service Type option defines the type of IPX service as a hex value.

Default: [1]

Range: 1 - ffff

4 - Interface

The Interface option defines the interface, either LAN or remote site device, which the IPX service is located on. A value of LAN indicates that the service is located on the locally connected LAN.

A value of a remote site profile name or id indicates that the service is located on the remote site IPX router s network.

5 - Network

The Network option defines the IPX network address of the static service.

6 - Node

The Node option defines the IPX node address of the static service.

7 - Socket

The Socket option defines the socket number of the static service if applicable.

8 - Hops

The Hops option defines the number of hops to reach the IPX service.

Default: [1]

Range: 0 - 15

Configure LAN Networks Menu

CONFIGURE LAN NETWORKS MENU		
Option	Value	Description
1. Ethernet-II frames	"0"	- IPX network number
2. RAW 802.3 frames	"0"	- IPX network number
3. IEEE 802.2 frames	"0"	- IPX network number
4. 802.2 SNAP frames	"0"	- IPX network number
5. Auto Learn	[enabled]	- Auto learn IPX network numbers
6. Help		- Description of IPX frame types

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **CONFIGURE LAN NETWORKS MENU** allows the configuration of the IPX network numbers on this router for each IPX frame type on the local LAN.

- 1 - Ethernet-II Frames
- 2 - RAW 802.3 Frames
- 3 - IEEE 802.2 Frames
- 4 - 802.2 SNAP Frames

A value of 0 indicates that the router will learn the network number associated with this frame type upon receiving the first IPX frame of this frame type.

Default: [0]

Range: 0 to FFFFFFFF hex

Considerations:

Once an IPX network number is defined or learned, all further IPX frames of that frame type will use the network number. If a different network number is found for that frame type, the first network number defined or learned will continue to be used.

5 - Auto Learn

Enables or disables the auto learning of IPX network numbers for this IPX router. All IPX network numbers will be taken from the user defined values within options 1 through 4 in this menu.

Default: [enabled]

6 - Help

The Help option offers a brief description of the IPX frame types and network numbers.

Filter Set-Up Menu

FILTER SET-UP MENU		
Option	Value	Description
1. MAC address filters	menu	- Define MAC address filters
2. Bridge pattern filters	menu	- Define bridge pattern filters
3. IP router pattern filters	menu	- Define IP pattern filters
4. IPX router pattern filters	menu	- Define IPX pattern filters

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **FILTER SET-UP MENU** provides paths to Menus for complete filter configuration.

1 - MAC Address Filters

The MAC Address Filters option takes you to the MAC Address Filters Menu, where you can define parameters for Source MAC Filters.

2 - Bridge Pattern Filter

The Bridge Pattern Filter option takes you to the Bridge Pattern Filter Menu, where you can create bridge filters based on custom specifications.

3 - IP Router Pattern Filter

The IP Router Pattern Filter option takes you to the IP Router Pattern Filter Menu, where you can create IP filters based on custom specifications.

4 - IPX Router Pattern Filter

The IPX Router Pattern Filter takes you to the IPX Router Pattern Filter Menu, where you can create IPX filters based on custom specifications.

MAC Address Filters Menu

MAC ADDRESS FILTERS MENU		
Option	Value	Description
1. Edit MAC address filter	menu	- Configure MAC address filter
2. Filter operation	[positive]	- Set operation of filters
3. Broadcast address	[forward]	- Filter MAC broadcast frames
4. Show bridging table		- View MAC address table
5. Show permanent table		- View permanent addresses only
6. Clear bridging table		- Delete all non-permanent entries

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **MAC ADDRESS FILTERS MENU** allows the display and configuration of the MAC Address Filters for the router.

1 - Edit MAC Address Filter

The Edit MAC Address Filter option takes you to the Edit MAC Address Filter Menu, where the MAC Address Filters are modified.

2 - Filter Operation

The Filter Operation option changes the operation of the MAC address filters defined in the bridging table from positive to negative.

When Filter Operation is positive, all frames with MAC addresses as defined in the bridging table will be filtered.

When Filter Operation is negative, all frames with MAC addresses as defined in the bridging table will be forwarded.

Internal addresses will not be affected by the current state of the Filter Operation. All internal addresses will automatically be corrected for proper operation regardless of the current setting of Filter Operation.

Default: [Positive]

3 - Broadcast Address

The Broadcast Address option allows the choice of filtering or forwarding of MAC broadcast frames for bridged data.

When set to forward, all MAC broadcast frames will be forwarded.

When set to filter, all MAC broadcast frames will be filtered.

Default: [forward]

4 - Show Bridging Table

The Show Bridging Table option displays all addresses in the Bridge Filter Table, identifies the active/inactive and permanent/non-permanent addresses, identifies addresses to be filtered if they are a source and/or destination, describes their location, and gives the total number of address table entries.

ALL Known MAC Addresses						
Total entries : 20						
Address	Filter		If		Access	Location
	Active	Perm	Src	Dest		
Start of table						
01-80-c2-00-00-01						Internal
01-80-c2-00-00-02						Internal
01-80-c2-00-00-03						Internal
01-80-c2-00-00-04						Internal
01-80-c2-00-00-05						Internal
01-80-c2-00-00-06						Internal
01-80-c2-00-00-07						Internal
01-80-c2-00-00-08						Internal
01-80-c2-00-00-09						Internal
01-80-c2-00-00-0a						Internal
01-80-c2-00-00-0b						Internal
01-80-c2-00-00-0c						Internal
01-80-c2-00-00-0d						Internal
01-80-c2-00-00-0e						Internal
01-80-c2-00-00-0f						Internal
02-44-00-c8-9a-ff	*	*			*	LAN050607
02-44-00-c8-9a-ee	*				*	LAN050607
12-34-56-78-99-99	*	*	*	*		LAN050607(fixed)
11-11-11-11-11-11				*		unknown
ff-ff-ff-ff-ff-ff						Internal
end of table						

Refer to the Show Bridging Table option of the Bridging Set-up menu for more details.

5 - Show Permanent Table

The Show Permanent Table option displays all of the permanent filter table addresses entered by the router manager for which the locations were identified (Internal addresses are not displayed.) The (fixed) Location descriptor indicates that a manager made the entry and specified the LAN location.

Operator Defined MAC Addresses						
Address	Filter if				Access	Location
	Active	Perm	Src	Dest		
Start of table						
02-44-00-c8-9a-ff	*	*			*	LAN050607
12-34-56-78-99-99	*	*	*	*		LAN050607(fixed)
End of table						

6 - Clear Bridging Table

The Clear Bridging Table option removes all non-permanent filter table addresses.

Considerations:

To prevent accidental removal of all non-permanent addresses, this option must be confirmed by entering `yes` at the prompt. (Refuse by entering `no` or use the TAB key to back out).

Edit MAC Address Filter Menu

```

                                EDIT MAC ADDRESS FILTER MENU

Option          Value          Description
1. Status       *[          ] - Is the address in the table?
2. Location     *[          ] - Location of MAC address
3. Filter if source [          ] - Filter all frames from this address
4. Filter if dest [          ] - Filter all frames to this address
5. Permanent    [          ] - Address is not subject to aging
6. Remove       [          ] - Delete address

Enter:
    MAC address in hexadecimal (up to 17 characters)
> d0456789

```

The above display is the first level of the **Edit MAC Address Filter Menu**. Once the MAC address is entered (leading 0s are padded), the address specified is added to the menu title bar, the values are shown for the address, and the options become available, as shown below:

```

                                EDIT MAC ADDRESS 00-00-d0-45-67-89 FILTER MENU

Option          Value          Description
1. Status       *"Not Present" - Is the address in the table?
2. Location     *"unknown"    - Location of MAC address
3. Filter if source [disabled]    - Filter all frames from this address
4. Filter if dest [disabled]    - Filter all frames to this address
5. Permanent    [disabled]    - Address is not subject to aging
6. Remove       [disabled]    - Delete address

>

```

1 - Status

The Status option tells whether the address is Present or Not Present in the Address Table. When the address is first entered, Not Present is the Status value, and a Location value of [unknown] is shown. The * beside the value indicates that this value is changed automatically as an address is added or deleted and cannot be manually redefined.

Default: * [Not Present]

2 - Location

The Location option identifies the location of the MAC address. The locations will either be unknown or the LAN name of one of the partner connected IOLINK SOHO bridge/routers. The * beside the value indicates that this value is changed automatically as the location is learned and cannot be manually redefined.

Default: * [unknown]

3 - Filter (*Forward*) If Source

The Filter If Source option toggles between Enabling and Disabling of the Source Filtering (Forwarding) feature for the specified address.

Default: [disabled]

Considerations:

When the Filter Operation is set to positive, enabling this option will prevent frames from this address from crossing the bridge/router to the associated LAN. Once Filter if Source is chosen, the Permanent value is set to [enabled]. This may be toggled back to [disabled] if a non-permanent entry is desired.

When the Filter Operation is set to negative, enabling this option will allow frames from this address to cross the bridge/router to the associated LAN. Once Forward if Source is chosen, the Permanent value is set to [enabled]. This may be toggled back to [disabled] if a non-permanent entry is desired.

4 - Filter (*Forward*) If Destination

The Filter If Destination option toggles between Enabling and Disabling of the Destination Filtering feature for the specified address.

Default: [disabled]

Considerations:

When the Filter Operation is set to positive, enabling this option will prevent access to this address from another LAN station located across the bridge/router. Once Filter if Destination is chosen, the Permanent value is set to [enabled]. This may be toggled back to [disabled] if a non-permanent entry is desired.

When the Filter Operation is set to negative, enabling this option will allow access to this address from another LAN station located across the bridge/router. Once Forward if Destination is chosen, the Permanent value is set to [enabled]. This may be toggled back to [disabled] if a non-permanent entry is desired.

5 - Permanent

The Permanent option toggles between Enabling and Disabling of the Permanent Address Value.

Default: [disabled]

Considerations:

This Value must be [enabled] if you want to make the Address Permanent. If [enabled] the Address will not be subject to removal by the expiration of the Aging Timer or the Clear Filter Table option (found in the Bridging Set-Up Menu or the MAC Address Filters Menu).

If a station is not expected to move, making the address Permanent will offer a slight increase in bridge/router performance.

6 - Remove

Select the Remove option to remove the specified address (permanent or non-permanent). Internal and system-supplied addresses cannot be removed.

Bridge Pattern Filter Menu

```

                                BRIDGE PATTERN FILTERS MENU

Option                          Description
1. Show alias                   - View pattern filter aliases
2. Add alias                    - Create an alias for a pattern filter
3. Remove alias                 - Delete a pattern filter alias
4. Show pattern                 - View current pattern filters
5. Add pattern                  - Create a pattern filter
6. Remove pattern               - Delete a pattern filter
7. Help                         - Read pattern filter and alias description

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

The **BRIDGE PATTERN FILTER MENU** allows for the inclusion of custom-programmable filters in the filter table to provide increased security and maximum local LAN usage.

The bridge/router supports up to 64 patterns and 32 aliases (including the defaults). Each pattern may be up to 80 characters in length. The total number of characters in all defined patterns must not exceed 500.

EXAMPLES: Refer to the Programmable Filtering section of the Reference Manual file, for detailed filter construction information with examples.

1 - Show Alias

The Show Alias option displays existing default Aliases and those created with the Add Alias option.

```

                                Bridge Pattern Filter Aliases

1. IP          - 12-0800
2. TCP         - IP & 23-06
3. UDP         - IP & 23-11
4. ARP         - 12-0806
5. NETWARE    - 12-8137 | 12-8138
6. APPLE      - 12-809B
7. DECNET     - 12-6003
8. LAT        - 12-6004
9. XNS        - 12-0807

Type: [s] to redraw, [=] main menu, any other key to end.
```

2 - Add Alias

The Add Alias option allows the creation of an easily identifiable string of characters to identify a complex Filter Mask:

```
Enter:
  alias name (up to 8 characters)

> bmCast

Enter:
  filter pattern for alias (up to 80 characters)
> 0-ffffffffffff

Enter:
  alias ID number (from 1 to 32)

> 3
```

Once an alias is created, you must use Add Pattern to add the alias to the filter table and make it operational:

```
Enter:
  filter pattern (up to 80 characters)
> bmCast

Enter:
  pattern ID number (from 1 to 64)
>5
```

Check the alias filter assignment with the Show Pattern option:

```
Bridge Filter Patterns

ID      Pattern
---      -
1       12-600x
2       0-010203040506&12-809B
...
5       bmCast
```

Menus Reference Manual: Bridge Pattern Filter Menu

3 - Remove Alias

The Remove Alias option deletes an Alias from the Alias Table. (Confirm with Show Alias.)

```
Enter:
  alias ID number, alias name
> bmCast
```

```
"bmCast" is used on LAN 1      (Prevents blanket removal when an alias is in use: carefully
                               check usage of the alias with Show Pattern and then, if removal
                               of the alias is still desired, use the Remove Pattern option first to
                               remove all occurrences of the alias in the Filter Pattern table, then
                               use the Remove Alias option).
```

4 - Show Pattern

The Show Pattern option displays the filter masks that have been defined with the Add Pattern option:

```
Enter:
  all, global, lan, Remote site id or alias
>
```

global

```
Global Bridge Filter Patterns
Id      Pattern
-----
1       12-600x
3       LAT
```

MARKETING - (Remote Site Alias)

```
Bridge Filter Patterns to MARKETING
Id      Pattern
-----
2       0-010203040506&12-809B
```

all

```
Summary of all Bridge filter patterns
Type    Id      Pattern
-----
Global  1       12-600x
        3       LAT
MARKETING 2       0-010203040506&12-809B
```

5 - Add Pattern

The Add Pattern option allows the definition of a filter mask and adds it to the filter table. *Filter masks are checked against the frame in the order of their index numbers, so those that are most likely to be encountered should have the lowest index numbers.*

```
Enter:
  global, lan, Remote site id or alias
>

Enter:
  filter pattern (up to 80 characters)
> 12-600x

Enter:
  pattern ID number (from 1 to 64)
> 1
```

A **global** filter pattern will be applied to all bridge data.

A **lan** filter pattern will be applied to all bridge data being sent to the local LAN.

A **Remote Site Id or Alias** filter pattern will be applied to all bridge data being sent to the specified remote site only. The Remote Site Alias specified must be defined on this device.

6 - Remove Pattern

The Remove Pattern option deletes a previously created filter mask (in this case, a filter mask with the pattern ID of 2). (Confirm the removal with Show Pattern).

```
Enter:
  all, pattern ID number
>2
```

7 - Help

The Help option provides Help screens describing the creation of Filter Masks.

To move between the Help screens, type: [s]tart, [n]ext, or [p]rev. (You must use lower-case letters)

IP Router Pattern Filter Menu

IP ROUTER PATTERN FILTER MENU	
Option	Description
1. Show alias	- View pattern filter aliases
2. Add alias	- Create an alias for a pattern filter
3. Remove alias	- Delete a pattern filter alias
4. Show pattern	- View current pattern filters
5. Add pattern	- Create a pattern filter
6. Remove pattern	- Delete a pattern filter
7. Help	- Read pattern filter and alias description

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IP ROUTER PATTERN FILTER MENU** allows for the inclusion of custom programmable filters in the filter table to provide increased security and maximum local LAN usage.

The router supports up to 64 patterns and 32 aliases (including the defaults). Each pattern may be up to 80 characters in length. The total number of characters in all defined patterns must not exceed 500.

EXAMPLES: Refer to the Programmable Filtering section of the Reference Manual file, for detailed filter construction information with examples.

1 - Show Alias

The Show Alias option displays existing default Aliases and those created with the Add Alias option.

IP Router Pattern Filter Aliases	
1. TCP	- 09-06
2. UDP	- 09-11
3. MSBROWSE	- 20-0089003

Type: [s] to redraw, [=] main menu, any other key to end.

2 - Add Alias

The Add Alias option allows the creation of an easily identifiable string of characters to identify a complex Filter Mask:

```
Enter:
  alias name (up to 8 characters)
> bmCast

Enter:
  filter pattern for alias (up to 80 characters)
> 0-ffffffffffff

Enter:
  alias ID number (from 1 to 32)
> 3
```

3 - Remove Alias

The Remove Alias option deletes an Alias from the Alias Table. (Confirm with Show Alias.)

```
Enter:
  alias ID number, alias name
> bmCast
```

"bmCast" is used on LAN 1

(Prevents blanket removal when an alias is in use: carefully check usage of the alias with Show Pattern and then, if removal of the alias is still desired, use the Remove Pattern option first to remove all occurrences of the alias in the Filter Pattern table, then use the Remove Alias option).

4 - Show Pattern

The Show Pattern option displays the filter masks that have been defined with the Add Pattern option:

```
Enter:
  all, global, lan, remote site id or alias
>
```

global

```
Global IP Pattern Filters

Id      Pattern
--      -
1       12-600x
3       LAT
```

Menus Reference Manual: IP Router Pattern Filter Menu

Vancouver (Remote Site alias)

IP Pattern Filters to Vancouver	
Id	Pattern
2	0-010203040506&12-809B

all

Summary of all IP Pattern Filters		
Type	Id	Pattern
Global	1	12-600x
	3	LAT
Vancouver	2	0-010203040506&12-809B

5 - Add Pattern

The Add Pattern option allows the definition of a filter mask and adds it to the filter table. *Filter masks are checked against the frame in the order of their index numbers, so those that are most likely to be encountered should have the lowest index numbers.*

```
Enter:
  global, lan, Remote site id or alias
> Vancouver

Enter:
  filter pattern (up to 80 characters)
> 12-600x

Enter:
  pattern ID number (from 1 to 64)
> 2
```

A **global** filter pattern will be applied to all IP routed data.

A **lan** filter pattern will be applied to all IP routed data being sent to the local LAN.

A **Remote Site Id or Alias** filter pattern will be applied to all IP routed data being sent to the specified remote site only. The Remote Site Alias specified must be defined on this device.

6 - Remove Pattern

The Remove Pattern option deletes a previously created filter mask (in this case, a filter mask with the pattern ID of 2). (Confirm the removal with Show Pattern.)

```
Enter:
  all, pattern ID number
> 2
```

7 - Help

The Help option provides Help screens describing the creation of Filter Masks.

To move between the Help screens, type: [s]tart, [n]ext, or [p]rev. (You must use lower-case letters)

IPX Router Pattern Filter Menu

IPX ROUTER PATTERN FILTER MENU	
Option	Description
1. Show alias	- View pattern filter aliases
2. Add alias	- Create an alias for a pattern filter
3. Remove alias	- Delete a pattern filter alias
4. Show pattern	- View current pattern filters
5. Add pattern	- Create a pattern filter
6. Remove pattern	- Delete a pattern filter
7. Help	- Read pattern filter and alias description

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **IPX ROUTER PATTERN FILTER MENU** allows for the inclusion of custom programmable filters in the filter table to provide increased security and maximum local LAN usage.

The bridge/router supports up to 64 patterns and 32 aliases (including the defaults). Each pattern may be up to 80 characters in length. The total number of characters in all defined patterns must not exceed 500.

EXAMPLES: Refer to the Programmable Filtering section of the Reference Manual file, for detailed filter construction information with examples.

1 - Show Alias

The Show Alias option displays existing default Aliases and those created with the Add Alias option.

IPX Router Filter Pattern Aliases	
1. NETBIOS	- 5-14

2 - Add Alias

The Add Alias option allows the creation of an easily identifiable string of characters to identify a complex Filter Mask:

```
Enter:
  alias name (up to 8 characters)
> bmCast

Enter:
  filter pattern for alias (up to 80 characters)
> 0-ffffffffffff

Enter:
  alias ID number (from 1 to 32)
> 3
```

3 - Remove Alias

The Remove Alias option deletes an Alias from the Alias Table. (Confirm with Show Alias.)

```
Enter:
  alias ID number, alias name
> bmCast
```

"bmCast" is used on LAN 1

(Prevents blanket removal when an alias is in use: carefully check usage of the alias with Show Pattern and then, if removal of the alias is still desired, use the Remove Pattern option first to remove all occurrences of the alias in the Filter Pattern table, then use the Remove Alias option).

4 - Show Pattern

The Show Pattern option displays the filter masks that have been defined with the Add Pattern option:

```
Enter:
  all, global, lan, remote site id or alias
>
```

global

```
Global IPX Pattern Filters

Id      Pattern
---      -
1       12-600x
3       LAT
```

Vancouver (Remote Site alias)

```
IPX Pattern Filters to Vancouver

Id      Pattern
---      -
2       0-010203040506&12-809B
```

all

Summary of all IPX Pattern Filters		
Type	Id	Pattern
Global	1	12-600x
	3	LAT
Vancouver	2	0-010203040506&12-809B

5 - Add Pattern

The Add Pattern option allows the definition of a filter mask and adds it to the filter table. *Filter masks are checked against the frame in the order of their index numbers, so those that are most likely to be encountered should have the lowest index numbers.*

```
Enter:
  global, lan, Remote site id or alias
> Vancouver

Enter:
  filter pattern (up to 80 characters)
> 9-600x

Enter:
  pattern ID number (from 1 to 64)
> 2
```

A **global** filter pattern will be applied to all IPX routed data.

A **lan** filter pattern will be applied to all IPX routed data being sent to the local LAN.

A **Remote Site Id or Alias** filter pattern will be applied to all IPX routed data being sent to the specified remote site only. The Remote Site Alias specified must be defined on this device.

6 - Remove Pattern

The Remove Pattern option deletes a previously created filter mask (in this case, a filter mask with the pattern ID of 2). (Confirm the removal with Show Pattern.)

```
Enter:
  all, pattern ID number
>2
```

7 - Help

The Help option provides Help screens describing the creation of Filter Masks.

To move between the Help screens, type: [s]tart, [n]ext, or [p]rev. (You must use lower-case letters)

Statistics Menu

STATISTICS MENU		
Option	Value	Description
1. Statistics set-up	menu	- Define statistics operation
2. LAN statistics	menu	- Access LAN statistics
3. WAN statistics	menu	- Access WAN statistics

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **STATISTICS MENU** provides paths to Menus for access to complete router statistics.

1 - Statistics Set-Up

The Statistics Set-up option takes you to the Statistics Set-Up Menu, where the interval and the range of reported statistics may be set. All statistics counts may also be reset from this menu.

2 - LAN Statistics

The LAN Statistics option takes you to the LAN Statistics Menu, where statistics can be examined to evaluate LAN performance.

3 - WAN Statistics

The WAN Statistics option takes you to the WAN Statistics Menu, where statistics can be examined to evaluate WAN performance.

Statistics Set-Up Menu

STATISTICS SET-UP MENU		
Option	Value	Description
1. Extended statistics	[disabled]	- Enable/disable extended statistics
2. Interval	[60 sec]	- Set display interval
3. Clear all statistics		- Reset all statistics

Enter option number, "=" - main menu, <TAB> - previous menu

>

1 - Extended Statistics

Choosing the Extended Statistics option enables extended statistics causing additional statistics to be calculated and reported.

When extended stats are [disabled], the following statistics displays are unavailable:

- **Frame Size**, LAN Statistics Menu

When extended stats are [disabled], limited information is available from:

- **Link Status**, WAN Statistics Menu (throughput section is not available).
- **Bridged Traffic**, LAN Statistics Menu (only the total column is available).
- **IP Traffic**, LAN Statistics Menu (only the total column is available).
- **IPX Traffic**, LAN Statistics Menu (only the total column is available).
- **Total LAN Traffic**, LAN Statistics Menu (only the total column is available).

Default: [disabled]

Considerations:

Enabling this option will decrease router performance, as additional processing is required. You must confirm a change by entering `yes` at the prompt.

2 - Interval

The Interval option sets the timer that updates the statistics.

Default: [60 sec]

Range: 10 to 3,600 seconds.

Considerations:

Lowering the time interval will require more router processing power while increasing the time interval will require less.

3 - Clear All Statistics

The Clear All Statistics option clears ALL of the statistics and resets all fields to zero.

LAN Statistics Menu

LAN STATISTICS MENU	
Option	Description
1. Bridged traffic	- Summary of Bridge traffic
2. IP traffic	- Summary of IP Router traffic
3. IPX traffic	- Summary of IPX Router traffic
4. Total LAN traffic	- Summary of LAN traffic
5. LAN error	- View LAN errors history
6. Frame size	- View frame size history
7. Clear LAN statistics	- Reset LAN statistics
8. Clear LAN errors	- Reset LAN errors

Enter option number, "=" - main menu, <TAB> - previous menu

>

1 - Bridged Traffic

The Bridged Traffic option displays a summary of Bridged LAN traffic since the statistics were last reset.

2 - IP Traffic

The IP Traffic option displays a summary of IP Router LAN traffic since the statistics were last reset.

3 - IPX Traffic

The IPX Traffic option displays a summary of IPX Router LAN traffic since the statistics were last reset.

4 - Total LAN Traffic

The Total LAN Traffic option displays a summary of Total LAN traffic since the statistics were last reset.

5 - LAN Error

The LAN Error option displays a summary of LAN and router errors since the statistics were last reset.

6 - Frame Size

The Frame Size option displays a summary of the distribution of LAN Frame Sizes since the statistics were last reset.

Considerations:

This option is available only if Extended Stats in the Statistics Set-Up Menu is Enabled.

7 - Clear LAN Statistics

The Clear LAN Statistics option clears all statistic fields in the LAN statistics to zero.

8 - Clear LAN Errors

The Clear LAN Errors option clears all error fields in the LAN statistics to zero.

Menus Reference Manual: LAN Statistics Menu

Bridged Traffic Summary Display (Option 1)

This screen displays Bridged LAN traffic statistics gathered since the statistics were last reset and reports statistics generated within the current statistics interval.

Bridged Traffic Summary				
Statistic	Total	Average Rate	Recent Rate	Highest Rate
Frames from LAN	4348699	228	416	840
Bytes from LAN	278317248	14616	26667	53785
Frames filtered from LAN	132982	6	0	840
Frames to LAN	4215689	221	416	441
Bytes to LAN	269806208	14171	26667	28236
Frames from WAN	4169752	219	416	441
Bytes from WAN	268464916	14024	26667	28250
Frames filtered from WAN	0	0	0	0
Frames to WAN	215689	121	416	441
Bytes to WAN	2696208	14171	26667	28236

Type: [s] to redraw, [=] main menu, any other key to end.

Column Analysis

- Total** Indicates the total number of occurrences since the statistics were last reset. (Available with extended statistics disabled.)
- Average Rate** Indicates the average rate of occurrences per second since the statistics were last reset.
- Recent Rate** Indicates the averaged rate of occurrences per second of the last statistics interval.
- Highest Rate** Indicates the highest recent rate encountered since the statistics were last reset or a re-powering of the router occurred.

Bridged Traffic Summary Statistics Definitions

Frames from LAN	All bridge data frames successfully received from the local LAN.
Bytes from LAN	All bridge data bytes successfully received from the local LAN.
Frames filtered from LAN	All bridge data frames received from the local LAN and filtered by the router. This includes frames filtered because the frame meets pattern filtering criteria or the frame was unsuccessfully received because of an error.
Frames to LAN	All bridge data frames successfully placed upon the local LAN.
Bytes to LAN	All bridge data bytes successfully placed upon the local LAN.
Frames from WAN	All bridge data frames successfully received from partner routers.
Bytes from WAN	All bridge data bytes successfully received from partner routers.
Frames filtered from WAN	All bridge data frames received from the partner routers and filtered by the router. This includes frames filtered because the frame meets pattern filtering criteria or the frame was unsuccessfully received because of an error.
Frames to WAN	All bridge data frames successfully sent to partner routers.
Bytes to WAN	All bridge data bytes successfully sent to partner routers.

Menus Reference Manual: LAN Statistics Menu

IP Traffic Summary Display (Option 2)

This screen displays IP Routed LAN traffic statistics gathered since the statistics were last reset and reports statistics generated within the current statistics interval.

LAN Tokyo Routed Traffic Summary				
Statistic	Total	Average Rate	Recent Rate	Highest Rate
Frames from LAN	4348699	228	416	840
Bytes from LAN	278317248	14616	26667	53785
Frames filtered from LAN	132982	6	0	840
Frames to LAN	4169752	219	416	441
Bytes to LAN	268464916	14024	26667	28250
Frames from WAN	9802916	14024	26667	28250
Bytes from WAN	4169752	219	416	441
Frames filtered from WAN	1982	6	0	840
Frames to WAN	269	14	27	28
Bytes to WAN	270	15	28	29
ARP Discards	0	0	0	0
Redirect Sent	269	14	27	28
Unreachable Sent	0	0	0	0

Type: [s] to redraw, [=] main menu, any other key to end.

Column Analysis

- Total** Indicates the total number of occurrences since the statistics were last reset. (Available with extended statistics disabled.)
- Average Rate** Indicates the average rate of occurrences per second since the statistics were last reset.
- Recent Rate** Indicates the averaged rate of occurrences per second of the last statistics interval.
- Highest Rate** Indicates the highest recent rate encountered since the statistics were last reset or a re-powering of the router occurred.

<u>IP Traffic Summary Statistics Definitions</u>	
Frames from LAN	All IP frames successfully received from the local LAN.
Bytes from LAN	All IP bytes successfully received from the local LAN.
Frames filtered from LAN	All IP frames received from the local LAN and filtered by the router. This includes IP frames filtered because the frame meets pattern filtering criteria or the frame was unsuccessfully received because of an error.
Frames to LAN	All IP frames successfully received from partner routers and placed upon the local LAN.
Bytes to LAN	All IP bytes successfully received from partner routers and placed upon the local LAN.
Frames from WAN	All IP frames successfully received from the local LAN and forwarded to partner routers.
Bytes from WAN	All IP bytes successfully received from the local LAN and forwarded to partner routers.
Frames filtered from WAN	All IP frames received from partner routers and filtered by the router. This includes IP frames filtered because the frame meets pattern filtering criteria or the frame was unsuccessfully received because of an error.
Frames to WAN	All IP frames successfully forwarded to partner routers.
Bytes to WAN	All IP bytes successfully forwarded to partner routers.
ARP Discards	Data frames discarded because local LAN stations not responding to an ARP request. This occurs when an IP frame destined for this LAN is received from a partner router, but there is no entry in the ARP table for that IP address, and the station does not respond to an ARP request.
Redirect Sent	The number of ICMP Redirect messages generated.
Unreachable Sent	The number of ICMP Destination Unreachable messages generated.

NOTE: The IP frames and bytes in the above table refer to frames properly routed to this router. A properly routed frame will be MAC addressed to the router and IP addressed for a station on another network or sub-network.

Menus Reference Manual: LAN Statistics Menu

IPX Traffic Summary Display (Option 3)

This screen displays IPX Routed LAN traffic statistics gathered since the statistics were last reset and reports statistics generated within the current statistics interval.

LAN Tokyo IPX Traffic Summary				
Statistic	Total	Average Rate	Recent Rate	Highest Rate
Frames from LAN	4348699	228	416	840
Bytes from LAN	278317248	14616	26667	53785
Frames filtered from LAN	132982	6	0	840
Congestion discards from LAN	0	0	0	0
Frames to LAN	269806208	14171	26667	28236
Bytes to LAN	4169752	219	416	441
Frames from WAN	268464916	14024	26667	28250
Bytes from WAN	4169752	219	416	441
Frames filtered from WAN	1982	6	0	840
Frames to WAN	269	14	27	28
Bytes to WAN	270	15	28	29

Type: [s] to redraw, [=] main menu, any other key to end.

Column Analysis

- Total** Indicates the total number of occurrences since the statistics were last reset. (Available with extended statistics disabled.)
- Average Rate** Indicates the average rate of occurrences per second since the statistics were last reset.
- Recent Rate** Indicates the averaged rate of occurrences per second of the last statistics interval.
- Highest Rate** Indicates the highest recent rate encountered since the statistics were last reset or a re-powering of the bridge/router occurred.

IPX Traffic Summary Statistics Definitions

Frames from LAN	All IPX frames successfully received from the local LAN.
Bytes from LAN	All IPX bytes successfully received from the local LAN.
Frames filtered from LAN	All IPX frames received from the local LAN and filtered by the router. This includes IPX frames filtered because the frame meets pattern filtering criteria or the frame was unsuccessfully received because of an error.
Congestion Discards from LAN	IPX Data frames discarded because of internal congestion between the LAN and the IPX module
Frames to LAN	All IPX frames successfully placed upon the local LAN.
Bytes to LAN	All IPX bytes successfully placed upon the local LAN.
Frames from WAN	All IPX frames successfully received from partner routers.
Bytes from WAN	All IPX bytes successfully received from partner routers.
Frames filtered from WAN	All IPX frames received from partner routers and filtered by the router. This includes IPX frames filtered because the frame meets pattern filtering criteria or the frame was unsuccessfully received because of an error.
Frames to WAN	All IPX frames successfully forwarded to partner routers.
Bytes to WAN	All IPX bytes successfully forwarded to partner routers.

Menus Reference Manual: LAN Statistics Menu

Total LAN Traffic Summary Display (Option 4)

This screen displays statistics gathered since the statistics were last reset and reports statistics generated within the current statistics interval.

LAN Tokyo Total Traffic Summary				
Statistic	Total	Average Rate	Recent Rate	Highest Rate
Frames from LAN	4348699	228	416	840
Bytes from LAN	278317248	14616	26667	53785
Frames filtered from LAN	132982	6	0	840
Adapter discards	0	0	0	0
Congestion discards from LAN	0	0	0	0
Frames forwarded	4215689	221	416	441
Bytes forwarded	269806208	14171	26667	28236
Congestion discards to WAN	0	0	0	0
Frames to LAN	4169752	219	416	441
Bytes to LAN	268464916	14024	26667	28250
Congestion discards to LAN	0	0	0	0

Type: [s] to redraw, [=] main menu, any other key to end.

Column Analysis

- Total** Indicates the total number of occurrences since the statistics were last reset. (Available with extended statistics disabled.)
- Average Rate** Indicates the average rate of occurrences per second since the statistics were last reset.
- Recent Rate** Indicates the averaged rate of occurrences per second of the last statistics interval.
- Highest Rate** Indicates the highest recent rate encountered since the statistics were last reset or a re-powering of the router occurred.

<u>Total LAN Traffic Summary Statistics Definitions</u>	
Frames from LAN	All frames successfully received from the local LAN.
Bytes from LAN	All bytes successfully received from the local LAN.
Frames filtered from LAN	All frames received from the local LAN and filtered by the router. This includes frames filtered because the router is in Learn mode, the destination address resides on the same LAN, the source address is specified for filtering, or the frame meets pattern filtering criteria.
Adapter Discards	All incoming frames lost because of an overflow error, receive buffer congest, missed frame detection, CRC errors, or framing errors. This is a case where LAN traffic exceeds the processing capability of the router, primarily because the router is engaged in other functions such as filtering.
Congestion Discards from LAN	This occurs when the router has to discard frames from the LAN because too many frames are waiting for processing inside the router and buffer space is unavailable.
Frames Forwarded	All frames successfully forwarded to partner routers.
Bytes Forwarded	All bytes successfully forwarded to partner routers.
Congestion Discards to WAN	This occurs when the router has to discard frames destined for the WAN because too many frames are waiting for processing inside the router and buffer space is unavailable.
Frames To LAN	All frames successfully placed upon the local LAN.
Bytes To LAN	All bytes successfully placed upon the local LAN.
Congestion Discards to LAN	This occurs when the router has to discard frames destined for the local LAN because too many frames are waiting for processing inside the router and buffer space is unavailable.

Menus Reference Manual: LAN Statistics Menu

LAN Error Display (Option 5)

LAN Calgary Error Summary			
Device Errors		LAN Errors	
Loss of Carrier	: 0	CRC Errors	: 0
Transmit Babble Errors	: 0	Framing Errors	: 0
Underflow Errors	: 0	Single Collision	: 0
Overflow Errors	: 0	Multiple Collisions	: 0
Receive Buffer Congest	: 0	Transmit Retry Failures	: 0
Receiver Misses	: 0	Late Collisions	: 0
Transmit Buffer Errors	: 0	Heartbeat Failure	: 0
Memory Errors	: 0	Oversized frames received	: 0

Type: [s] to redraw, [=] main menu, any other key to end.

<u>Device Errors</u>	
Loss of Carrier	This usually indicates a problem with the LAN hardware either on the Router or in the transceiver.
Underflow Errors	This is a hardware error. The LAN hardware could not read the contents of a frame to be transmitted from memory.
Transmit Babble Errors	
Overflow Errors	The software could not supply a receive buffer in time to receive frames because of congestion.
Receive Buffer Congest	The router missed a frame; because of congestion, the software did not supply sufficient receive buffers to the LAN hardware fast enough to receive all segments of a frame.
Receiver Misses	The router missed the frame because there were no receive buffers available for storing the frame. Note that this statistic counts only this specific case whereas the Traffic Summary Receiver Misses statistic counts two additional receive buffer errors and combines them into one statistic.
Transmit Buffer Errors	This is a hardware or software error. The transmit buffers are corrupted or the memory could not be read by the LANCE chip.
Memory Errors	This reports errors occurring with the router's memory.

<u>LAN Errors</u>	
CRC Errors	A frame was received with a bad CRC and was discarded.
Framing Errors	A frame was received that did not contain an integral number of bytes (some bits were missing).
Single Collision	The number of times exactly one retry was needed to transmit a packet.
Multiple Collisions	The number of times more than one retry was needed to transmit a packet.
Transmit Retry Failures	The LAN transceiver has made 16 attempts to transmit a packet and has been blocked each time because of collisions. The transmission is aborted.
Late Collisions	A collision should only be seen when the transceiver transmits the first 64 bytes of a packet. The likely cause is a faulty transceiver that has started transmitting after this point.
Heartbeat Failure	This is also called an SQE error. As a check for LAN presence, the transceiver is supposed to test the collision presence circuit whenever a transmission is made. The LANCE is complaining that this did not happen. Ethernet Version 1 does not support Heartbeat, so Heartbeat should be disabled when the router is connected to Version 1.
Oversized frames received	

Frame Size Display (Option 6)

LAN Calgary Frame Size Distribution				
Range	From LAN	To LAN	From WAN	To WAN
64 - 127	11331	11331	9980	9764
128 - 255	0	0	0	0
256 - 383	0	0	0	0
384 - 511	0	0	0	0
512 - 639	0	0	0	0
640 - 767	0	0	0	0
768 - 895	0	0	0	0
896 - 1023	0	0	0	0
1024 - 1151	0	0	0	0
1152 - 1279	0	0	0	0
1280 - 1407	0	0	0	0
1408 - 1518	0	0	0	0
1519 up	0	0	0	0

Type: [s] to redraw, [=] main menu, any other key to end.

This screen displays a breakdown of the sizes of the frames processed by the router for the indicated LAN since the statistics were last reset.

The first column is the range of frame sizes in bytes;

The second, frames received from the local LAN;

The third, frames forwarded across the router to the other LAN;

The fourth, frames received from the other LAN.

WAN Statistics Menu

```

                                WAN STATISTICS MENU

Option                          Value      Description
1. Remote site stats            menu      - Remote site statistics
2. Remote site summary          - Summary of remote sites
3. Learned summary              - Summary of learned DLCI's
4. Call summary                  - Call summary of remote sites
5. Clear remote site stats      - Reset remote site statistics
6. Link stats                    - Detail statistics of a link
7. Link summary                  - Summary statistics of all links
8. Clear link statistics        - Reset link statistics

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

1 - Remote Site Status

The Remote Site Status option takes you to the Remote Site Status Menu, where statistics for a particular remote site can be examined.

2 Remote Site Summary

The Remote Site Summary option gives a listing of remote sites and the parameters associated with each site..

```

* - Up      @ - Suspended          Total Remote Site Entries: 8
E - Enabled  D - Disabled  NA - Not Available

Id  Alias                FR  AC  MP  Pri/Sec  DLCI  BRG  IP  IPX  CCP  CMCP  BACP
-----
  1  Auckland              NA  D  E    ISDN/none  NA    E   E  E   E   E   D
  2  LEASED1               NA  E  E   Link02/none  NA    E   E  E   E   NA  E
  3  mix1                  NA  D  E   Link01/ISDN  NA    E   E  E   E   NA  E
  4  isdn_x2               NA  D  E    ISDN/ISDN  NA    E   E  E   E   D   E
  5  isdn_x1               NA  D  E    ISDN/none  NA    E   E  E   E   D   D
 41  ISDN_TEMPLATE         NA  D  E    ISDN/ISDN  NA    E   E  E   E   D   E
 43  LEASED_TEMPLATE       NA  D  E    none/none   NA    E   E  E   E   NA  E
```

3 - Call summary

The Call Summary option displays the ISDN dial-up remote site connections available in the remote site table.

* - Up		@ - Suspended	Total Call Site Entries: 5		
Id	Alias	ISDN Numbers	Wildcard	Callback Enabled	Group
1	Branch1	16613349876 16613349877	none	Yes	1
4	Branch2	14184336789 14184337890	none	Yes	1
7	SOHO	7665667	none	No	1
9	Remote1	1234567890	none	No	2
10	TEST1	6543210	none	No	2

Note: this option will only appear if the Logical ISDN type is set to ISDN on this router.


4 - Clear Remote Site Statistics

The Clear Remote Site Statistics option clears all fields in all of the remote site statistics displays to zero.

5 - Link Stats Display

```
Enter:
Link to display (1 or 2)
```

The link Stats display will vary to reflect the WAN module configuration for that link (leased or ISDN). The display screen below shows the statistic elements common to all types of module. The XX d areas under Interface State indicate where the variable statistics will go. Displays particular to each configuration are listed on following pages.



State :

This displays the current state of the link: Enabled/Disabled, Idle / Opening / Up/ Down / Establish / Authenticate / Network / Terminate, Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

Remote Site :

This displays the name of the current remote site to which this link is connected.

Speed :

This displays the speed at which the link is operating. The speed will be as set by the connection. If the link is disconnected, no speed (0) will be shown.

Type :

The interface type is identified in this display.

Frame Counts

Bytes :

This indicates the total number of bytes received/transmitted across the link.

Frames :

This indicates the total number of frames received/transmitted across the link.


Frame Errors

These frames are considered invalid because they do not conform to valid frame checking parameters. These frames usually result from a hardware error on either the LAN or the router.


- Cgt Disc** Congestion Discards This is generated when a frame is discarded due to congestion.
- CRC** Cyclic Redundancy Check This often indicates a problem with the transmitting hardware and/or communications line (a modem, noisy line, router link problem) that has been detected by the receiver.
- Rcv abort** Receiver Abort This reports that an incoming frame has been aborted. This results when the transmitter doesn't receive all of a frame to be sent, and it sets an abort flag at the point this is discovered in the transmission. The receiver notes this as a statistic and discards the frame.
- Overrun** The link controller could not empty the link FIFO into common memory before the next frame from the link is written to the FIFO. This indicates a problem with the memory inside the router.
- Rcv miss** Receiver Miss This reports that an incoming frame has been aborted. This results when the frame is missed because of a lack of receive buffers. The remote router will retransmit the frame.
- Too large** This reports that an incoming frame has been discarded because the frame exceeded the maximum length. This may be caused by a frame being overrun by another frame on the link, so that the router thinks both frames are one frame.
- Misaligned** This reports that frames detected on this link have a number of bits not exactly divisible by eight.
- Underrun** The link controller could not read the rest of the frame from common memory before the link FIFO emptied. This indicates a problem with the memory inside the router.

Throughput

Both receive and transmit call utilization are displayed by the two bar graphs. Utilization describes the total bytes received or sent (including protocol overhead) divided by the total bytes possible based on the call speed. For each statistic, the numerical percentage is printed along with its equivalent baud rate and the bar graph.



ISDN display:



Circuit :

This identifies the type of ISDN call. The call may be Incoming, Outgoing, or Cleared .


State :

This identifies the current state of the ISDN call. The state may be one of Idle, Proceeding, Disconnecting, or Connected .

Partner Number :

This identifies the ISDN number of the remotely connected PPP ISDN router.

Leased display:



CD

The state of the Carrier Detect signal.

6 Link Summary

Link Summary					
Link ID	Link Type/State	Remote Site Alias	Throughput Kbps (Rcv/Xmt)	% (Rcv/Xmt)	Frame Errors
1	ISDN/Up	DEV012345	0.0/0.0	0/0	0
2	Leased/Down	TEST10	0.0/0.0	0/0	0

Link ID :

The link numbers (1 or 2).

Link Type/State :

The link module types and states of each link.

Remte Site Alias :

The names assigned to the remote sites currently associated with each link.

Throughput :

The received and transmitted throughput rates for each link in kilobits per second.

% :

The received and transmitted throughput as a percentage of .the available link speed.

Frame Errors :

The number of invalid frames received on each link since the last `Clear link statistics` command..

7 - Clear Link Statistics

The Clear Link Statistics option clears all fields in the Link statistics to zero.

Remote Site Statistics Menu

```

                                REMOTE SITE STATS MENU

Option                           Description
1. Protocols status              - Display protocols status
2. Protocols statistics          - Display protocols statistics

Enter :
    Remote site id or alias  (up to 16 characters)

>
```

The above display is the first level of the **REMOTE SITE STATUS MENU**. Once the remote site id is entered, the id specified is added to the menu title bar and the Options are as shown below:

```

                                REMOTE SITE STATS Montreal MENU

Option                           Description
1. Protocols status              - Display protocols status
2. Protocols statistics          - Display protocols statistics
3. Calls status                  - Display call(s) statistics
4. Circuit quality               - Display link(s) quality data
5. Usage information             - Display usage information

Enter option number, "=" - main menu, <TAB> - previous menu

>
```

1 - Protocol Status

The Protocol Status option displays the state of the various connection protocols for this remote site.

2 - Protocol Statistics

The Protocol Statistics option displays a summary of the protocol statistics for this remote site since the statistics were last reset.

3 - Calls Status

The Call Status option displays a summary of the LCP parameters and the frame counts and errors for the connection to the chosen remote site since the statistics were last reset.

4 - Circuit Quality

The Circuit Quality option displays a summary of the Circuit Quality parameters for the primary and secondary ISDN calls to the chosen remote site since the statistics were last reset.

5 - Usage Information

The Usage Information option displays a summary of the link usage and number of outgoing calls for the chosen remote site since the statistics were last reset.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Protocol Status (option 1)

Protocol Status is displayed on a series of screens. To navigate from one display to another, enter **n** to go to the next screen, **p** to go to the previous screen, **s** to go to the starting screen or any other key to return to the Remote Site Stats Menu. The display will vary depending on the type of connection to the selected remote site; the status of more than one protocol option may be displayed on a screen.

Protocol Status ISDN Link

Protocol Status								RMS	3-Milan	
* - Up		E - Enabled		D - Disabled		NA - Not Available				
FR	AC	MP	Pri/Sec	DLCI	BCP	IPCP	IPXCP	CCP	BACP	CMCP
D	D	E	Link04/none	NA	E	E	E	E	D	NA
Multilink state: Down										
Bundle state : Idle										

Protocol Status Leased Line

Protocol Status								RMS	3-Milan	
* - Up		E - Enabled		D - Disabled		NA - Not Available				
FR	AC	MP	Pri/Sec	DLCI	BCP	IPCP	IPXCP	CCP		
D	D	E	Link04/none	NA	E	E	E	E		
Multilink state: Down										
Bundle state : Idle										
Operational Status										
BCP : Initial										
IPCP : Initial										
IPXCP : Initial										
CCP : Initial										
Compression : enabled										

AC :

Auto-call enabled / disabled for this remote site.

MP :

Multipoint enabled / disabled for this remote site.

Pri/Sec :

The Primary and Secondary (if applicable) links for this remote site.

DLCI :

The DLCI assigned for this remote site (Not Applicable for this router).

BCP :

Bridge Control Protocol enabled / disabled status.

IPCP :

IP Control Protocol enabled / disabled status.

IPXCP :

IPX Control Protocol enabled / disabled status.

CCP :

Compression Control Protocol enabled / disabled status.

BACP :

Bandwidth Allocation Control Protocol enabled / disabled status.

CMCP :

Connection Management Control Protocol enabled / disabled status (if this is an ISDN connection, otherwise Not Applicable).

Multilink State :

This displays the current state of Multilink operation for this remote site connection: Up. / Down

Bundle State :

This displays the current state of the PPP link bundle: Idle / Opening / Up / Stopping / Closing.

Protocol Status Operational Status

Operational Status ISDN Link

Protocol Status		RMS	3-Milan
Operational Status			
BCP	: Initial		
IPCP	: Initial		
IPXCP	: Initial		
CCP	: Initial		
Compression	: enabled		
BACP	: Initial		
CMCP	: Suspended		

Operational Status Leased Line

Protocol Status		RMS	3-Milan
Operational Status			
BCP	: Initial		
IPCP	: Initial		
IPXCP	: Initial		
CCP	: Initial		
Compression	: enabled		

BCP :

Displays the current state of Bridge Control Protocol for this remote site connection: Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

IPCP :

Displays the current state of PPP IPCP for this remote site connection: Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

IPXCP :

Displays the current state of PPP IPXCP for this remote site connection: Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

CCP :

Displays the current state of PPP CCP for this remote site connection: Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

Compression :

Displays whether compression is enabled or disabled for this remote site connection.

BACP :

Displays the current state of the Bandwidth Allocation Control Protocol for this remote site: Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Protocol Status BCP

Status	Local	BCP	Remote
802.3/Ethernet	: disabled		disabled
Tinygram Compression	: disabled		disabled
MAC Address	: 00-00-00-00-00-00		00-00-00-00-00-00

BCP

802.3/Ethernet:

This displays the resulting bridging state for this protocol after the advisory notices are sent by the local and remote bridges. The advisory notices indicate what frame types are supported by the device.

This may display disabled if the partner bridge sends a configure reject for the advisory notice for this frame type. When this happens, the device that originally sent the advisory notice will continue to send bridge frames in the frame formats originally reported in the advisory notice.

Tinygram Compression:

This displays the negotiated state of Tinygram Compression for the local and remote devices.

MAC Address:

This displays the MAC addresses of the local and remote devices which are used for bridging data between the devices.

Protocol Status IPCP

Status	Local	IPCP	Remote
IP Address	: 0.0.0.0		0.0.0.0
Subnet Mask Size	: 0		0
Link IP type	: unNumbered		
VJ Compression	: none		none
Max slot id	: 0		0
Slot id Comp	: disabled		disabled

IPCP

IP Address :

This displays the current IP addresses for this end of the IPCP link connection as well as the IP address for the remote end.

Subnet Mask Size :

This displays the current subnet mask size for this end of the IPCP link connection as well as the subnet mask size for the remote end.

Link IP Type :

This displays the type of IP link connection between this IOLINK SOHO and the remote site router, either numbered or unnumbered.

VJ Compression :

This displays the negotiated type of compression protocol for this end of the IPCP link connection as well as the compression protocol for the remote end: none, VJ TCP.

Max Slot Id :

This displays the negotiated value for the Van Jacobson max slot identifier for this end of the IPCP link connection as well as the value for the Van Jacobson max slot identifier for the remote end.

Slot Id Comp :

This displays the negotiated state of the Van Jacobson slot identifier compression for this end of the IPCP link connection as well as the state of the Van Jacobson slot identifier compression for the remote end.

Protocol Status IPXCP

Status	Local	Remote
	IPXCP	
IPX Routing Protocol	: RIP/SAP	
Force RIP Updates	: disabled	
IPX Network Number	: 0	
IPX Node Number	: 00-00-00-00-00-00	00-00-00-00-00-00

IPXCP

IPX Routing Protocol:

This displays the IPX routing protocol negotiated over the link. The possible routing protocols are RIP/SAP, Static, Demand RIP/SAP.

Force RIP Updates:

This displays the state of the force RIP updates option on the link connection. This display is only applicable when the IPX Routing Protocol is RIP/SAP.

IPX Network Number:

This displays the IPX network number negotiated for the link. The network number will be 0 if the interface is unnumbered.

IPX Node Number:

Local :

This indicates the IPX node number negotiated for this end of the link. The node number will be 0 if the interface is unnumbered.

Remote :

This indicates the IPX node number negotiated for the remote site end of the link. The node number will be 0 if the interface is unnumbered.

Protocol Status CCP

Status	Local	CCP	Remote
Protocol	: None		None
Histories	: 0		0
Check mode	: None		None
Restarts	: 0		
Resyncs	: 0		

CCP

Protocol :

This displays the current compression protocol for this end of the CCP link connection as well as the compression protocol for the remote end.

Histories :

This displays the current number of histories which have been negotiated for both the local end and the remote end of the connection.

Check Mode :

This displays the compression check modes which have been negotiated for both the local end and the remote end of the connection.

Restarts :

This displays the number of times that compression has been restarted by renegotiating CCP on the connection.

Resyncs :

This displays the number of times that CCP has been successfully resynchronized on the connection.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Protocol Status BACP

Status	Local	Remote
	BACP	
Magic Number	: 1850971031	1851377123
Call Mode	: Partner	

BACP:

Magic Number:

This displays the control code numbers passed between the two routers. The router with the lower magic number will have control of setting up and tearing down the connection.

Call Mode:

This displays the selected origination of the secondary call to this remote site.

Protocol Status Multilink

Status	Local	Remote
	Multilink	
MRRU	: 1800	1800
SSNHF	: normal	normal
Local EPD	: class MAC 00-00-d0-00-d1-1a	
Remote EPD	: class MAC 00-00-d0-00-af-1f	

Multilink:

MRRU :

This displays the negotiated MRRU (Maximum Receive Reconstructed Unit) value for this end of the link connection as well as the MRRU value for the remote end.

SSNHF :

This displays the negotiated SSNHF (Short Sequence Number Header Format) value for this end of the link connection as well as the SSNHF value for the remote end: normal / short.

EPD :

This displays the negotiated EPD (End Point Discriminator) value for this end of the link connection and the EPD value for the remote end.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Protocol Status CMCP

Status	Local	Remote
	CMCP	
Callback number 1	: 6681048	2447072
Callback number 2	: 9954321	3435566

CMCP:

Callback number n:

This displays the callback ISDN numbers used by each interface and by the remote site connected to that interface.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Protocol Statistics (option 2)

Protocol Statistics are displayed on a series screens. To navigate from one display to another, enter **n** to go to the next screen, **p** to go to the previous screen, **s** to go to the starting screen or any other key to return to the Remote Site Stats Menu.

Note: Statistics will only be displayed for functions which are shown as enabled (E) in the status display (forth line) of the screen shown below. Because of this, the display screens will vary depending what options are enabled for this remote site.

Protocol Statistics ISDN Link

Protocol Statistics										RMS	3-Milan
	* - Up	E - Enabled	D - Disabled	NA - Not Available							
FR	AC	MP	Pri/Sec	DLCI	BCP	IPCP	IPXCP	CCP	BACP	CMCP	
---	---	---	-----	---	---	---	---	---	---	---	
D	D	E	Link01/none	NA	E	E	E	E	D	NA	
Multilink state: Down											
Bundle state : Idle											

Protocol Statistics Leased Link

Protocol Statistics										RMS	3-Milan
	* - Up	E - Enabled	D - Disabled	NA - Not Available							
FR	AC	MP	Pri/Sec	DLCI	BCP	IPCP	IPXCP	CCP			
---	---	---	-----	---	---	---	---	---			
D	D	E	Link02/none	NA	E	E	E	E			
Multilink state: Down											
Bundle state : Idle											

FR :

Frame Relay enabled / disabled for this remote site.(always disabled on this router)

AC :

Auto-call enabled / disabled for this remote site.

MP :

Multipoint enabled / disabled for this remote site.

Pri/Sec :

The Primary and Secondary (if applicable) links for this remote site.

DLCI :

The DLCI assigned for this remote site (always Not Applicable on this router).

BCP :

Bridge Control Protocol enabled / disabled status.

IPCP :

IP Control Protocol enabled / disabled status.

IPXCP :

IPX Control Protocol enabled / disabled status.

CCP :

Compression Control Protocol enabled / disabled status.

BACP :

Bandwidth Allocation Control Protocol enabled / disabled status.

CMCP :

Connection Management Control Protocol enabled / disabled status (if this is an ISDN connection, otherwise Not Applicable).

Multilink State :

This displays the current state of Multilink operation for this remote site connection: Up. / Down

Bundle State :

This displays the current state of the PPP link bundle: Idle / Opening / Up / Stopping / Closing.

Protocol Statistics BCP

Protocol Statistics			RMS	3-Milan
Statistics	Frame Counts (Rcv/Xmt)	Frame Errors		
		BCP		
BCP	: 0/0	Rcv BPDU Discards: 0		
BPDU	: 0/0	Xmt BPDU Discards: 0		
Bridge	: 0/0	Rcv Brg Discards : 0		
		Xmt Brg Discards : 0		

BCP

Frame Counts

BCP :

This indicates the total number of BCP frames received/transmitted across the link.

BPDU :

This indicates the total number of BPDU (Bridge Protocol Data Unit) frames received/transmitted across the link. If this device is not running STP and receives STP frames from the peer device, the BPDU frames will be counted as received and then silently discarded.

Bridge:

This indicates the total number of non-compressed bridge frames received/transmitted across the link.

Frame Errors

Rcv BPDU Discards :

This is generated when an incoming BPDU frame is discarded due to congestion or BCP not being open.

Xmt BPDU Discards :

This is generated when an outgoing BPDU frame is discarded due to congestion.

Rcv Brg Discards :

This is generated when an incoming bridge frame is discarded due to congestion.

Xmt Brg Discards :

This is generated when an outgoing bridge frame is discarded due to congestion.

Protocol Statistics IPCP - ISDN

Statistics	Frame Counts (Rcv/Xmt)	Frame Errors
IPCP		
IPCP	: 0/0	VJ : 0
IP	: 0/0	Rcv Discards : 0
VJ Comp	: 0/0	Xmt Discards : 0
VJ Uncomp	: 0/0	
Triggered RIP (Rcv/Xmt)		
RIP Response	: 0/2	Retries : 0
RIP Ack	: 2/0	
RIP Request	: 0/0	Retries : 0

Protocol Statistics IPCP Leased Line

Statistics	Frame Counts (Rcv/Xmt)	Frame Errors
IPCP		
IPCP	: 0/0	VJ : 0
IP	: 0/0	Rcv Discards : 0
VJ Comp	: 0/0	Xmt Discards : 0
VJ Uncomp	: 0/0	

IPCP

Frame Counts

IPCP :

This indicates the total number of IPCP frames received/transmitted across the link.

IP :

This indicates the total number of non-compressed IP frames received/transmitted across the link.

VJ Comp :

This indicates the total number of compressed TCP frames received/transmitted across the link.

VJ Uncomp :

This indicates the total number of uncompressed TCP frames received/transmitted across the link.

Frame Errors

VJ :

This is generated when an incoming compressed TCP frame is discarded, possibly due to error detection.

Rcv Discards :

This is generated when an incoming IP frame is discarded due to congestion.

Xmt Discards :

This is generated when an outgoing IP frame is discarded due to congestion.

Protocol Statistics Triggered RIP

Statistics	Frame Counts (Rcv/Xmt)	Frame Errors
Triggered RIP	(Rcv/Xmt)	
RIP Response :	0/2	Retries : 0
RIP Ack :	2/0	
RIP Request :	0/0	Retries : 0

Triggered RIP (Rcv/Xmt)

RIP Response:

The responses received or transmitted as a result of a RIP request

RIP Ack:

Acknowledgements sent or received following a RIP response.

RIP Request:

Requests for RIP information transmitted or received.

Retries:

Number of retries after no RIP Response to a RIP Request or no RIP Acknowledgement of a RIP Response.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Protocol Statistics IPXCP

Statistics	Frame Counts (Rcv/Xmt)	Frame Errors
	IPXCP	
IPXCP	: 0/0	Rcv Discards : 0
IPX	: 0/0	Xmt Discards : 0

IPXCP

Frame Counts

IPXCP :

This indicates the total number of IPXCP frames received/transmitted across the link.

IPX :

This indicates the total number of IPX frames received/transmitted across the link.

Frame Errors

Rcv Discards :

This is generated when an incoming IPX frame is discarded due to congestion.

Xmt Discards :

This is generated when an outgoing IPX frame is discarded due to congestion.

Protocol Statistics CCP

Statistics	Frame Counts (Rcv/Xmt)	Frame Errors
	CCP	
CCP	: 0/0	Compress : 0
Reset Req	: 0/0	Decompress : 0
Reset Ack	: 0/0	Rcv Discards : 0
Comp Frames	: 0/0	Zero Pad : 0
Raw Bytes	: 0/0	
Comp Bytes	: 0/0	
Comp Ratio	: -- / --	
Recent Ratio	: -- / --	

CCP

Frame Counts

CCP :

This indicates the total number of CCP frames received/transmitted across the link.

Reset Req :

This indicates the total number of Reset Requests received/transmitted across this link.

Reset Ack :

This indicates the total number of Reset Acknowledgments received/transmitted across this link.

Comp Frames :

This indicates the total number of compressed frames received/transmitted across this link.

Raw Bytes :

This indicates the total number of bytes before compression received/transmitted across this link.

Comp Bytes :

This indicates the total number of compressed bytes received/transmitted across this link.

Comp Ratio :

This indicates the received/transmitted average compression ratio since the last time statistics were cleared.

Recent Ratio :

This indicates the received/transmitted compression ratio in the last display period.

Frame Errors

Compress :

This is generated when an error occurred during compression.

Decompress :

This is generated when an error occurred during decompression or a compression sequence number was not received.

Rcv Discards :

The number of discards due to an incorrect compression sequence number or discards when a compressed frame is received before the Ack is received.

Zero Pad :

This number indicates the number of frames with zero pad compression received. This acts as a flag for frames received which have been compressed with an unsupported compression technique.

Protocol Statistics BACP

Statistics	Frame Counts (Rcv/Xmt)	Frame Errors
		BACP
BACP	: 4/4	Rcv BAP Discards : 0
BAP	: 4/4	Xmt BAP Discards : 0

BACP

BACP:

This displays the total number of BACP frames received/transmitted across the link.

BAP:

This displays the total number of BAP frames received/transmitted across the link.

Rcv BAP Discards:

This displays the number of discarded BAP frames received

Xmt BAP Discards:

This displays the number of discarded BAP frames transmitted

Protocol Statistics Multilink

Frame Counts		Fragment Counts	
		Multilink	
Rcv	: 126440	Rcv	: 126440
Xmt	: 8602	Xmt	: 8602
Header Error	: 0	Header Error	: 0
Discard	: 0	Discard	: 0
Unknown Protocol	: 0		

Frame Counts (Rcv/Xmt)

Frame Counts

Rcv :

Receive This indicates the number of MP frames that have been received. This is counted after reconstruction of the Multilink frame.

Xmt :

Transmit This indicates the number of MP frames that have been transmitted. This is counted after reconstruction of the Multilink frame.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Header Error :

This indicates the number of MP frames that have been discarded due to an error in the header. This is counted after reconstruction of the Multilink frame.

Discard :

This indicates the number of MP frames that have been silently discarded due to the frame not belonging within a MP frame, i.e. LCP frames. This is counted after reconstruction of the Multilink frame.

Unknown Protocol :

This indicates the number of MP frames that have been discarded due to the frame being an unknown or unsupported protocol type, i.e. IPXCP or BDP. This is counted after reconstruction of the Multilink frame.

Rcv :

Receive This indicates the number of MP frame fragments that have been received. This is counted before reconstruction of the Multilink frame.

Xmt :

Transmit This indicates the number of MP frame fragments that have been transmitted. This is counted before reconstruction of the Multilink frame.

Header Error :

This indicates the number of MP frame fragments that have been discarded due to an error in the header. This is counted before reconstruction of the Multilink frame.

Discard :

This indicates the number of MP frame fragments that have been discarded due to the remaining portion of the MP frame not being received.

Protocol Statistics CMCP

Statistics	Frame Counts (Rcv/Xmt)	Connection Counts
		CMCP
CMCP	: 9/9	Connections : 1
		Terminations : 0
		Suspensions : 7
		Resumptions : 6

Frame Counts

CMCP :

This indicates the total number of CMCP frames received/transmitted across the link.

Connection Counts

Connections :

This indicates the total number of CMCP link connections to this remote site.

Terminations :

This indicates the total number of CMCP link terminations to this remote site.

Suspensions :

This indicates the total number of CMCP link suspensions to this remote site.

Resumptions :

This indicates the total number of CMCP link resumptions to this remote site.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

Calls Status (Option 3)

Call Status is displayed on two screens. To navigate from one display to another, enter **n** to go to the next screen, **p** to go to the previous screen, **s** to go to the starting screen or any other key to return to the Remote Site Stats Menu. Note that the display will vary depending on the type of connection to the selected remote site.

Calls Status ISDN Link

Calls Status		RMS	1-Nairobi
P - Primary S - Secondary NA - Not Available			
Multilink state	:	Up	
Auto-call	:	Enabled	
Link (P/S)	:	1/2	
Operational Status (P)	:	Network, Opened	
Operational Status (S)	:	Network, Opened	
	Local LCP (P/S)	Remote LCP (P/S)	
MRU	:	1800/1800	1800/1800
ACCM	:	0x00000000/0x00000000	0x00000000/0x00000000
Quality	:	none/none	none/none
Quality Period	:	0/0	0/0
Magic Number	:	948283990/169237683	727743965/1137737807
PFC	:	disabled/disabled	disabled/disabled
ACFC	:	enabled/enabled	enabled/enabled
FCS size	:	16-bit FCS/16-bit FCS	16-bit FCS/16-bit FCS
SDP	:	0/0	0/0

Calls Status Leased Line

Calls Status		RMS	1-Nairobi
NA - Not Available			
Multilink state	:	Up	
Auto-call	:	Enabled	
Link	:	3	
Operational Status	:	Network, Opened	
	Local LCP	Remote LCP	
MRU	:	1800	1800
ACCM	:	0x00000000	0x00000000
Quality	:	none	none
Quality Period	:	0	0
Magic Number	:	1071949471	1501563008
PFC	:	disabled	disabled
ACFC	:	enabled	enabled
FCS size	:	16-bit FCS	16-bit FCS
SDP	:	0	0

Multilink state:

This displays the current state of Multilink operation for this remote site connection: Up / Down.

Auto-Call :

This displays the current state of Auto-Call status for this remote site connection: Enabled / Disabled.

Link :

This displays the link numbers being used by the primary and secondary (if applicable) calls to this remote site.

Operational Status:

This displays the current state of the PPP LCP module for this link of the remote site connection: Dead / Establish / Authenticate / Network / Terminate, Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

MRU :

This displays the negotiated MRU (Maximum Receive Unit) value for this end of the link connection as well as the MRU value for the remote end.

ACCM :

This displays the negotiated ACCM (Asynchronous-Control Character-Map) Configuration value for this end of the link connection as well as the ACCM value for the remote end.

Quality :

This displays the negotiated quality protocol type for this end of the link connection as well as the quality protocol type for the remote end.

Quality Period :

This displays the negotiated quality period for this end of the link connection as well as the quality period for the remote end.

Magic Number :

This displays the negotiated magic number value for this end of the link connection as well as the magic number value for the remote end.

PFC :

This displays the negotiated PFC (Protocol Field Compression) state for this end of the link connection as well as the PFC state for the remote end.

ACFC :

This displays the negotiated ACFC (Access and Control Field Compression) state for this end of the link connection as well as the ACFC state for the remote end.

Menus Reference Manual: Remote Site Statistics - Remote Site Statistics Menu

FCS Size :

This displays the negotiated FCS size (Frame Check Sequence) for this end of the link connection as well as the FCS size for the remote end.

SDP :

This displays the negotiated SDP value (Self-Describing-Padding) for this end of the link connection as well as the SDP value for the remote end. A value of 0 indicates no padding is being added.

Calls Status screen 2

Calls Status		RMS	1-Nairobi
Frame Counts	(Rcv/Xmt)		
Bytes :	4967/4848		
Frames :	346/345		
LCP :	315/315		
LQR :	0/0		
PAP :	2/2		
CHAP :	0/0		
MP :	29/28		
	Frame Errors		
	Header :	0	
	Rcv Discards :	0	
	Pad :	0	
	Unknown Prot :	0	

Note: there will be displays for both the primary and secondary connections if this remote site is configured with a secondary link.

Frame Counts

Bytes :

This indicates the total number of bytes received/transmitted across this link.

Frames :

This indicates the total number of frames received/transmitted across this link.

LCP :

This indicates the total number of LCP (Link Control Protocol) negotiation frames received/transmitted across this link.

LQR :

This indicates the total number of LQR (Link Quality Report) frames received/transmitted across this link.

PAP :

This indicates the total number of PAP (Password Authentication Protocol) frames received/transmitted across this link.

CHAP :

This indicates the total number of CHAP (Challenge-Handshake Authentication Protocol) frames received/transmitted across this link.

MP :

This indicates the total number of MP (Multilink Protocol) frames received/transmitted across this link.

Frame Errors

Header :

This is generated when an incoming frame is discarded due to a bad header.

Rcv Discards :

This is generated when an incoming frame is discarded due to the frame being destined for a bundle before this link has been bound to a bundle.

Pad :

This is generated when an incoming frame is discarded due to a problem trimming off the SDP padding.

Unknown Prot :

Unknown Protocol This is generated when an incoming frame is discarded due to the frame being an unknown or unacceptable protocol type, i.e. BDP or IPXCP.

Circuit Quality (Option 4)

Circuit Quality is displayed on two screens. To navigate from one display to another, enter **n** to go to the next screen, **p** to go to the previous screen, **s** to go to the starting screen or any other key to return to the Remote Site Stats Menu. Note that the display will vary depending on the type of connection to the selected remote site.

Circuit Quality screen 1 ISDN Link

Circuit Quality			RMS	1-Nairobi
P - Primary S - Secondary NA - Not Available				
Multilink state	:	Up		
Auto-call	:	Enabled		
Link (P/S)	:	13/14		
Operational Status (P)	:	Network, Opened		
Operational Status (S)	:	Network, Opened		
		Local LQM (P/S)		Remote LQM (P/S)
LQM	:	none/none		none/none
Quality Period	:	0/0		0/0

Circuit Quality screen 1 Leased Line

Circuit Quality			RMS	1-Nairobi
NA - Not Available				
Multilink state	:	Up		
Auto-call	:	Enabled		
Link (P/S)	:	2		
Operational Status	:	Network, Opened		
		Local LQM		Remote LQM
LQM	:	none		none
Quality Period	:	0		0

Multilink :

This displays the current state of Multilink operation for this remote site connection: Up / Down.

Auto-Call :

This displays the current state of Auto-Call status for this remote site connection: Enabled / Disabled.

Link :

This displays the link numbers being used by the primary and secondary (if applicable) calls to this remote site.

Operational Status:

This displays the current state of the PPP LCP module for this link of the remote site connection: Dead / Establish / Authenticate / Network / Terminate, Initial / Starting / Closed / Stopped / Closing / Stopping / Req Sent / Ack Rcvd / Ack Sent / Opened.

LQM :

This displays the negotiated LQM (Link Quality Mode) for this end of the link connection as well as the LQM for the remote end: LQR / none.

Quality Period :

This displays the negotiated quality period value for this end of the link connection as well as the quality period value for the remote end.

Circuit Quality screen 2

Circuit Quality			RMS	1-Nairobi
Recent	(Rcv/Xmt)	LQR		
Lost Packets:	0/0	Lost Outbound LQRs	: 0	
Lost Octets :	0/0	Outbound LQRs in Pipeline	: 0	
		Change in Peer InDiscards	: 0	
Total		Change in Peer InErrors	: 0	
Lost Packets:	0/0			
Lost Packets:	0/0			
Lost Octets :	0/0			
LQRs :	0/0			

Note: both primary and secondary links will be displayed if this remote site is configured to have a secondary link.

Recent Counts

Lost Packets :

This indicates the number of packets lost while receiving / transmitting across this link during the previous quality period.

Lost Octets :

This indicates the number of octets lost while receiving / transmitting across this link during the previous quality period.

Total Counts

Lost Packets :

This indicates the total number of packets lost while receiving / transmitting across this link.

Lost Octets :

This indicates the total number of octets lost while receiving / transmitting across this link.

LQRs :

This indicates the total number of LQR packets received / transmitted across this link.

LQR

Lost Outbound LQRs :

This indicates the total number of LQR packets sent to the remote site that have been lost.

Outbound LQRs in Pipeline :

This indicates the total number of LQR packets sent to the remote site that have not been received by the remote site.

Change in Peer InDiscards:

This indicates the number of times the remote site has discarded packets due to congestion.

Change in Peer InErrors :

This indicates the number of times the remote site has discarded packets due to invalid packets.

Usage Information (Option 5)

		Usage	Remote Site 2-Murmansk	
Multilink state: Down				
Bundle state : Idle				
Auto-call : disabled				
Day of Week	Usage	Outgoing Calls		
Sunday	: 0 min	0	calls	
Monday	: 0 min	0	calls	
Tuesday	: 0 min	0	calls	
Wednesday	: 0 min	0	calls	
Thursday	: 0 min	0	calls	
Friday	: 0 min	0	calls	
Saturday	: 0 min	0	calls	
Current	: 0 min	0	calls	

Note: The day-of-weeks are the 24-hour time intervals starting from 7:00 the same day.

Multilink :

This displays the current state of Multilink operation for this remote site connection: Up / Down.

Bundle State :

This displays the current state of the PPP link bundle: Idle / Opening / Up / Stopping / Closing.

Auto-Call :

This displays the current state of Auto-Call status for this remote site connection: Enabled / Disabled.

Usage :

This displays the total number of minutes of line usage and number of calls to this remote site for the indicated day of the week.

Outgoing Calls :

This displays the total number of outgoing calls to this remote site for the indicated day of the week.

Diagnostics Menu

DIAGNOSTICS MENU		
Option	Value	Description
Option	Value	Description
1. Soft reset		- Reset device (retain configuration)
2. Full reset		- Reset device (use factory defaults)
3. Heartbeat	[enabled]	- Report transceiver heartbeat failures
4. WAN trace	menu	- Trace link frames

Enter option number, "=" - main menu, <TAB> - previous menu

>

1 - Soft Reset

Selecting the Soft Reset option resets the router software and restarts the router. The current configuration is retained.

Note that a hardware (and software) reset may be performed by unplugging the unit and plugging it in again.

2 - Full Reset

Selecting the Full Reset option resets the router configuration to factory default settings and restarts the router. The factory default settings include the terminal type and password.

CAUTION: Use this option with caution. All configuration settings will be lost.

3 - Heartbeat

The Heartbeat option enables or disables reporting of transceiver heartbeat failures. This failure is not a router fault but a transceiver fault. As a check for LAN presence, the transceiver should ensure that the collision-presence circuit is working whenever a transmission is made. When Heartbeat is enabled, the router will report these failures. Ethernet Version 1 does not support Heartbeat, so all transceivers should have Heartbeat Disabled on these Version 1 Ethernet networks.

Considerations:

Enabling this option can help in determining transmission line performance, although it will decrease router performance, since additional processing must be done by the router to report these errors. (Disable for Version 1 Ethernet.)

4 - WAN trace

The WAN diagnostics option takes you to the WAN Trace Menu, where trace operations can be [enabled] or [disabled] for each link in order to evaluate link performance.

WAN Trace Menu

WAN TRACE MENU		
Option	Value	Description
1. Trace link	[1]	- Enter the link to be traced
2. Real time	[disabled]	- Display frames in real-time
3. Capture	[enabled]	- Capture frames in buffer
4. End	[disabled]	- End capture at link down
5. Data display	[hex] [single_line]	- Set frame display format
6. Time	[disabled]	- Add time to display
7. Show		- View capture buffer

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **WAN TRACE MENU** can be used to monitor the link with features such as statistics capture, frame and packet level tracing, and link-utilization and efficiency histograms. Note that these features will hamper the performance of the bridge/router; therefore, the tracing functions should only be [enabled] when needed.

1 - Trace Link

Enable the trace for the specified link after the other options below are set. These options also determine which link is displayed with the Show option.

2 - Real Time

Enable this option when the display of frames in real-time is desired. When [enabled], the trace starts immediately and scrolls off the bottom of the screen. Return to the menu by entering 2 to disable real-time (You will have to wait 7-8 seconds or more for this to take effect).

3 - Capture

Enabling this option allows for frame capture and display after the buffer is allocated. Use Option 7, Show, to display the capture.

4 - End

With this option [enabled], if the link goes down while a trace is underway, the Capture function will end and the data from the trace can be examined up until the point of failure. If this option is [disabled], the Capture function will end when the allocated capture buffer is full.

If the link goes down and then comes back up, the recovery can be examined with End [disabled].

Menus Reference Manual: WAN Loopback Menu

5 - Data display

Three possibilities are offered for the display of data. Data may be displayed in **hex** or **ASCII**, or, since in most cases the data being sent doesn't itself need to be examined, **off** may be chosen, which will display only the protocol frame information. Note that command completion may be used (i.e. only the first letter(or letters) need to be entered for recognition). After a data from a trace is captured, you may move from off to ASCII or hex, as this information resides in the background.

```
Enter:
  ascii, hex, off
>

Enter:
  all_lines, single_line
>
```

6 - Time

[Enable] this option to add time to the trace display in thousands of a second (h.mm.ss.xxx). Time is always available and does not need to be enabled to capture data during a trace (i.e. may be enabled after the data from the trace is captured). Time is relative to the time of power-up.

7 - Show

This option appears once the buffers are allocated

This option displays the frames captured by the Trace and stored in the capture buffer. (BOB = Beginning of Buffer; EOB = End of Buffer.) The trace shown below is with the data display in the `off` mode.

BOB	This Bridge/Router	Partner Bridge/Router
	rRR 0	expects 0
xI 4,0 122	expects 4, sends 0	gets 0
	rRR 1	expects 1
xRR 5	rI 1,4 68	still expecting 1, sends 4
	expects 5	
	rI 1,5 68	still expecting 1, sends 5
xI 5,1 122	still expecting 5, sends 1	gets 1
xRR 6	expects 6	
	rRR 2	expects 2
xI 6,2 236	still expecting 6, sends 2	gets 2
	rRR 3	expects 3
	rI 3,6 68	still expecting 3, sends 6
xRR 7	gets 6	
	expects 7	
	rI 3,7 68	still expecting 3, sends 7
xI 7,3 144	gets 7	gets 3
xRR 0	still expecting 7, sends 3	
	expects 0	
	rRR 4	expects 4
xI 0,4 122	still expecting 0, sends 4	gets 4
	rRR 5	expects 5
	rI 5,0 68	still expecting 5, sends 0
xRR 1	gets 0	
	expects 1	
	rI 5,1 68	still expecting 5, sends 1
xI 1,5 122	gets 1	gets 5
xRR 2	still expecting 1, sends 5	
	expects 2	
	rRR 6	expects 6
xI 2,6 258	still expecting 2, sends 6	gets 6
	rRR 7	expects 7
	rI 7,2 68	still expecting 7, sends 2
xRR 3	gets 2	
	expects 3	
	rI 7,3 68	still expecting 7, sends 3
xI 3,7 68	gets 3	gets 7
xRR 4	still expecting 3, sends 7	
	expects 4	
	rRR 0	expects 0
EOB		

Menus Reference Manual: WAN Loopback Menu

Format:

Receive frames (r) are indented.

Transmit frames (x) are not.

Valid frames are as follows:

I	-	Information
RR	-	Receiver Ready
RNR	-	Receiver Not Ready
REJ	-	Reject
SABM	-	Set Asynchronous Balance Mode
DM	-	Disconnect Mode
DISC	-	Disconnect
UA	-	Unnumbered Acknowledgment
FRMR	-	Frame Reject

Information (I) Frame traces will be displayed with the following:

Link (L1/L2)(x/r)I N(r), N(s) Data Field Length Data Field (hex)

As much of the Data Field as will fit on one line will be displayed if hex or ASCII format is specified. If **off** is specified, only the Data Field Length is given.

Supervisory (S) frame traces will be displayed with the following:

Link (L1/L2)(x/r)(RR / RNR / REJ) N(r)

Unnumbered (U) frame traces will be displayed with the following:

Link (0/1) (x/r) (SABM / DM / DISC / UA / FRMR)

Any illegal or unknown frame will be completely dumped in hex. Note that any frame with a CRC error will not be displayed and a Level 2 error will be output.

LAPB control field formats:

Three types of Link Access Procedures (Balanced) **LAPB** control field formats are used to perform:

- 1) numbered information transfer (**I** format),
- 2) numbered supervisory functions (**S** format) and
- 3) unnumbered control functions (**U** format).

The numbered **I** format is used to perform information transfer.

The numbered **S** format is used to perform data link supervisory control functions such as:

- acknowledge **I** frames,
- request transmission of **I** frames, and
- to request a temporary suspension of **I** frames.

The unnumbered **U** format is used to provide additional data link control functions.

INFORMATION FRAMES:

I Information

The **(I)** statistic indicates a transfer of a sequentially numbered frame containing an **(I)** information field.

To allow the sending of an Information frame a Receive Ready (**RR**) supervisory frame is sent by the remote bridge/router requesting the connection.

SUPERVISORY FRAMES:

RR Receiver Ready

A Receive Ready (**RR**) supervisory frame is sent by the bridge/router in order to:

- 1) indicate that it is ready to receive an **I** frame;
- 2) acknowledge previously received **I** frames numbered up to and including $N(R) - 1$.

An **RR** frame may be used to indicate the clearance of a busy condition reported by the earlier transmission of an **RNR** frame by that same bridge/router.

RNR Receiver Not Ready

The **RNR** statistic is generated by either remote bridge/router to indicate a busy condition. A busy condition essentially indicates a temporary inability to accept incoming **I** frames. **I** frames numbered up to and including $N(R) - 1$ are acknowledged.

I frame $N(R)$ and any subsequent **I** frames received, are not acknowledged; the acceptance state of these unacknowledged frames will be indicated in subsequent exchanges.

REJ REJect

The **REJ** supervisory frame is generated when a remote bridge/router requests transmission of **I** frames starting with the frame numbered $N(R)$. **I** frames numbered $N(R) - 1$ and below are acknowledged. Additional **I** frames (pending initial transmission) may be transmitted following the retransmitted **I** frame(s).

Only one **REJ** exception condition for a given transfer direction may be established at any time. This **REJ** exception condition is reset (cleared) upon the receipt of an **I** frame with an $N(S)$ equal to the $N(R)$ of the **REJ** frame. An **REJ** frame may be used to indicate the clearance of a busy condition that was reported by the earlier transmission of an **RNR** frame by that same bridge/router.

UNNUMBERED FRAMES:

SABM Set Asynchronous Balanced Mode

The **SABM** unnumbered command is generated to place the addressed bridge/router into an asynchronous balanced mode information-transfer phase, where all command/response control fields will be one octet in length.

The transmission of a **SABM** statistic indicates the clearance of a busy condition that was reported by the earlier transmission of an **RNR** frame and statistic by that same bridge/router.

The receiving bridge/router confirms acceptance of the **SABM** by the transmission, at the first opportunity, of a **UA** response.

Previously transmitted **I** frames that are unacknowledged when a **SABM** command is generated remain unacknowledged. It is the responsibility of a higher level (e.g. TCP, XNS, LAT) to recover from the loss of the contents (packets) of such **I** frames.

DISC **DISC**onnect

The **DISC** statistic is generated when the bridge/router sending the **DISC** informs the other bridge/router that it (the sending bridge/router) is suspending its own operation.

Before the **DISC** is acted upon, the bridge/router receiving the **DISC** confirms its acceptance of the **DISC** command by the transmission of a **UA** response. The bridge/router sending the **DISC** enters the disconnected phase when it receives the acknowledged **UA** response.

Previously transmitted **I** frames that are unacknowledged when **DISC** is generated remain unacknowledged. It is the responsibility of a higher-level protocol (e.g. TCP, XNS, LAT) to recover from the possible loss of the contents (packets) of such **I** frames.

UA **U**nnumbered **A**cknowledgment

A **UA** response and statistic is generated to acknowledge the receipt and acceptance of the mode-setting commands. Received mode-setting commands are not acted upon until the **UA** response is transmitted. The transmission of a **UA** response indicates the clearance of a busy condition that was reported by the earlier transmission of an **RNR** frame by that same bridge/router.

DM **D**isconnected **M**ode

The **DM** unnumbered response and statistic is generated to report a status where the bridge/router is logically disconnected from the link, and is in the disconnected phase.

- 1) The **DM** may be sent to indicate that the bridge/router has entered the disconnected phase without having received a **DISC** command.
- 2) If sent in response to the reception of a mode-setting command, the **DM** is sent to inform the other bridge/router(s) that this bridge/router is still in the disconnected phase and cannot execute the Set Mode command.

A bridge/router in the **DM** phase will monitor received commands and will react to a **SABM** command. It will send a **DM** response with the F bit set to 1 in response to another command received with the P bit set to 1.

FRMR **FR**aMe **R**eject

The **FRMR** statistic is generated by the bridge/router to report an error condition not recoverable by the retransmission of an identical frame. This may result from at least one of the following conditions:

- 1) the receipt of a command or response control field that is undefined or not implemented;
- 2) the receipt of an I frame with an information field that exceeds the maximum established length;
- 3) the receipt of an invalid N(R); or
- 4) the receipt of a frame with an information field that is not permitted or the receipt of a supervisory or unnumbered frame with incorrect length.

An undefined or not implemented control field is any control field encoding not identified in Table 5, LAPB commands and responses.

A valid N(R) must be within the range from the lowest send sequence number N(S) of the still unacknowledged frame(s) to the current logical DCE send state variable, inclusive.

An information field that immediately follows the control field, and consists of 3 to 5 octets, is returned with the **FRMR** and provides the reason for the **FRMR** response.

Network Events Menu

NETWORK EVENTS MENU	
Option	Description
1. Acknowledge alarm	- Clear alarm status display
2. Show events	- View event history
3. Clear events	- Clear event history
4. Show security log	- View security failure log
5. Clear security log	- Clear security failure log
6. Show resumption log	- View resume event log
7. Clear resumption log	- Clear resume event log

Enter option number, "=" - main menu, <TAB> - previous menu

>

The **NETWORK EVENTS MENU** allows the display and management of alarm histograms.

Event and Security Logs are listed and explained in the Reference Manual file on the accompanying disk.

1 - Acknowledge Alarm

The Acknowledge Alarm option clears the screen ALARM display for the current alarm.

2 - Show Events

The Show Events option displays the 199 most recent events and alarms since the router was last powered up or Cleared with option 3. A listing of events and alarms is available in Appendix A of the IOLINK SOHO Reference Manual. Alarms are indicated by an asterisk (*).

```
#1 1999-01-26 13:39:05   SNMP is running
#2 1999-01-26 13:39:06 * IP Routing is enabled
#3 1999-01-26 13:39:07   Configuration restored
#4 1999-01-26 13:39:08   Running in OPERATIONAL mode
#5 1999-01-26 13:39:09 * LAN connection established
#6 1999-01-26 13:39:35 * LAN started forwarding
time is 1999-01-26 14:24:32, 8 items since last clear.
```

Type: [s]tart, [n]ext, [p]rev, [=] main menu, any other key to end.

The format of the time stamp for each event is: year-month-day hour:minute:second

These will be according to the date and time set in the Device Set-Up menu.

Menus Reference Manual: Network Events Menu

3 - Clear Events

The Clear Events option removes all events from the table.

4 - Show Security Log

The Show Security Log option displays the 99 most recent security logs since the router was last powered up or Cleared with option 5.

```
#1 1999-01-26 16:26:53 Link 1 PAP failed for one (5551313)
#2 1999-01-26 16:28:19 Link 1 CHAP failed for one (5551313)
time is 1999-01-26 16:28:19, 2 items since last clear.
```

Type: [s]-to redraw, [=] main menu, any other key to end.

The format of the time stamp for each security log entry is: year-month-day hour: minute: second

These will be according to the date and time set in the Device Set-Up menu.

5 - Clear Security Log

The Clear Security Log option removes all ISDN security logs from the table.

6 - Show Resumption Log

The Show Resumption Log option displays the 100 most recent connection management link resumption logs since the router was last powered up or Cleared with option 7. The entries in the log indicate the device that the call was resumed to, the protocol that caused the resumption, the source and destination addresses within the frame that caused the resumption, and a hex dump of the frame that caused the resumption. The hex dump of the frame may be used for debugging purposes when the link is being resumed incorrectly.

```
#1 1999-01-26 14:53:27 Resume event to DEV000d05 (IPX)
#2 1999-01-26 14:53:27 Dst 0000411b:000000000001:0451 Src
+ 00001515:00001b02446b:4003
#3 1999-01-26 14:53:27 Length = 46 - ff ff 00 29 01 11 00 00 41 1b 00 00 00
+ 00 00 01 04 51 00 00 15 15 00 00 1b 02 44 6b 40 03 22
+ 22 17 03 01 00 16 00 02 15 01 01 00 01 bf bf
#4 1999-01-26 15:06:10 Resume event to DEV000d05 (IP)
#5 1999-01-26 15:06:10 Dst 192.168.95.196 Src 198.169.1.149
#6 1999-01-26 15:06:10 Length = 335 - 45 00 01 4f 00 00 00 00 1f 29 b1 db c6
+ a9 01 95 c0 a8 5f c4 02 54 48 45 20 51 55 49 43 4b 20
+ 42 52 4f 57 4e 20 46 4f 58 20 4a 55 4d 50 53 20 4f 56
+ 45 52 20 54 48 45 20 4c 41 5a 59 20 44 4f 47 20 31 32
time is 1999-01-26 15:06:16, 9 items since last clear.
```

Type: [s]-to redraw, [=] main menu, any other key to end.

The format of the time stamp for each alarm is as follows: year-month-day hour: minute: second

These will be according to the date and time set in the Device Set-Up menu.

7 - Clear Resumption Log

The Clear Resumption Log option removes all connection management link resumption logs from the table.